







# PHILIPS

## Quick Start Guide

### 8 Motion Effects LED C9 Lights


#### What's included

Faceted C9 Light String with control box	Remote Control	Spare Bulbs (4)	Spare Fuses (2)	Safety Instructions	Quick Start Guide
					

#### What's next

- Read enclosed Safety Instruction Sheet and Operating Instructions before starting.
- Carefully remove plug from opening on side of the spool.
- Unwrap the lights, pull out plastic tab from remote, and test before decorating.
- Decorate your home with the light string.
- Plug light string into an 110V-125V wall receptacle, lights will turn on. Press power button on remote if they do not turn on when first plugged in.
- Remote control and button on control box allows you to select from 8 different effects:

- |                |                  |                     |              |
|----------------|------------------|---------------------|--------------|
| 1. Combination | 3. Slow Flashing | 5. Slow Fade In/Out | 7. Pulsating |
| 2. Steady On   | 4. Fast Flashing | 6. Fast Fade In/Out | 8. Step Fade |




- Push the button marked "MODE" on remote or on control box to advance to next function (after lights are turned on).
- When plugging in more than one of the same 8 Function LED light string with remote, the units can be synchronized so that each is performing the same function at the same time.



- While both sets are illuminated, push the " " button on the remote to synchronize both sets to the same function, then push the "MODE" button to select the next function.
- At end of holiday season, wrap the lights back on the spool in the reverse order by replacing the end connector into the opening on the side of the spool first.

#### Remote Control Battery Installation

1. Open the battery cover on the bottom of the remote by pulling out from the bottom.
2. Clean the battery contacts and also those of the device prior to battery installation.
3. Use only same type CR2032 3V Lithium battery for replacement, use of other batteries may damage remote.
4. Install battery following the polarity shown on the battery compartment.
5. Close battery cover by sliding back into place.





## WARNING

- Do not expose remote to moisture. Use indoors or outdoors when not raining or snowing.
- Small parts, keep away from children.
- Remove batteries when not used for an extended period of time, or when depleted. Batteries may leak and cause permanent damage to unit.
- Do not use rechargeable batteries.
- Do not recharge included batteries or expose to temperatures above 140° F (60° C).
- Do not open batteries, expose to water, put in backwards, or short circuit (store each battery in a separate plastic bag).
- Dispose of lithium batteries in accordance with local, state, or federal regulations. Do not dispose of batteries in fire.

## Troubleshooting Tips

1. If one bulb is not functioning – replace bulb with one of the spare bulbs provided by following the USER SERVICING INSTRUCTIONS on the Safety and User Instruction sheet
2. If all lights are out –
  - a. Make sure there is power to the outlet or extension cord by plugging another product into that outlet, and make sure if the outlet is controlled by a switch or timer that it is turned on. If connected to an outlet protected by a GFCI, reset the GFCI outlet or breaker.
  - b. Remove fuses and replace with the provided spare fuses by following USER SERVICING INSTRUCTIONS on the Safety and User Instruction sheet.
  - c. Make sure all bulbs in that section are fully inserted.
  - d. Starting at one end, replace a non-working bulb with one of the spare bulbs by following USER SERVICING INSTRUCTIONS on the Safety and User Instruction Sheet. Keep repeating with the spare bulb in each unlit socket until entire set lights.
  - e. Make sure wires are in position at bottom of each bulb (see figure 1 for example) to make contact with brass contacts inside lampholder.

Figure 1



Call Customer Service at 1-800-763-6177 Monday-Friday 9:00am – 5:00pm CST with any additional questions.

**3 Year Limited Guarantee** - Subject to the exclusions contained below, Seasonal Specialties LLC, at its option, will at no charge repair, replace (with same or equivalent product), or refund the purchase price if this product fails to light due to defects in material or workmanship within three (3) years from the date of purchase. To obtain service, ship the product prepaid along with the Original UPC & Original dated legible proof of purchase to Seasonal Specialties, L.L.C., 11455 Valley View Road, Eden Prairie, MN 55344, Attn: Customer Service. Allow six to eight weeks for handling. We are committed to making high quality products. Returning the product to us helps us to monitor and improve product quality.

**Exclusions** - This product is intended for residential seasonal use only (90 days maximum per year), and was pre-tested and date coded prior to shipment. This limited guarantee extends only to the first consumer purchaser, and is not transferable. This guarantee does not include: 1) commercial use, 2) normal wear and tear, 3) products not used in accordance with directions provided on or with the product, 4) burnout of bulbs or LEDs, 5) batteries, 6) products that have been subjected to unauthorized repair, and/or modification, or 7) damage caused by shipping, improper handling, alterations, misuse, or accidents.

ANY IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED TO THE DURATION OF THIS LIMITED WARRANTY. OTHERWISE THE REPAIR, REPLACEMENT, OR REFUND AS PROVIDED UNDER THIS EXPRESS LIMITED WARRANTY IS THE EXCLUSIVE REMEDY OF THE CONSUMER, AND IS PROVIDED IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED. IN NO EVENT SHALL SEASONAL SPECIALTIES, LLC BE LIABLE, WHETHER IN CONTRACT OR TORT (INCLUDING NEGLIGENCE) FOR DAMAGES IN EXCESS OF THE PURCHASE PRICE OF THE PRODUCT, OR FOR ANY INDIRECT, INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES OF ANY KIND, ARISING OUT OF OR IN CONNECTION WITH THE USE OF THE PRODUCT TO THE FULL EXTENT THESE DAMAGES MAY BE DISCLAIMED BY LAW.

Some states and jurisdictions do not allow the limitation or exclusion of incidental or consequential damages, or limitation on the length of an implied warranty, so the above limitations or exclusions may not apply to you. This limited guarantee gives you specific legal rights, and you may also have other rights that vary from state to state or from one jurisdiction to another.

When shipping product back to us, please include your return address, contact phone, and e-mail address in addition to the other requested information.

Please contact us at 1-800-763-6177 or visit our website at [www.seasonalspecialties.com](http://www.seasonalspecialties.com) for additional information.

The Philips trademark and the Philips Shield Emblem are registered trademarks of Koninklijke Philips N.V. used under license.

This product has been manufactured by and is sold under the responsibility of Seasonal Specialties LLC, and Seasonal Specialties LLC is the warrantor in relation to this product.

**FCC WARNING**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.