



Functions and buttons

	Button/Port	Function
	Mute Button	Press to mute/unmute the microphone.
1	Mute LED	Solid red LED: Microphone is muted.
		No LED Display: Microphone is unmuted.
2	Multifunctional Button	Press to pause/play audio; Press and hold the button for 5 seconds to activate the voice assistant.
3	Volume +	Press to increase the volume.
4	Call Answer/End	Press to answer/end the call. Press and hold the button for 3 seconds to reject the call.
5	Power ON/OFF	Press and hold the button for 3 seconds to power on or off. Press the button to show the battery remaining (#10).
	Power ON/OFF LED	Solid white LED: Battery full or enough to use \$1000
		Solid red LED: Battery charging
		Flashing red LED: Battery low
6	Volume -	Press to decrease the volume.
	Bluetooth Button	Pair/connect Bluetooth-enabled devices or disconnect.
7	Bluetooth LED	Solid blue LED: Bluetooth device is connected (Pairing successful)
		Flashing blue LED: Bluetooth pairing
8	USB-C Charge Port	USB-C port, plug the USB cable to this port.
9	3.5mm Aux Port	Connect the audio device with 3.5mm plug to the port.
	LED Indicator	
	Red LED	Solid red LED: Microphone is muted.
		Flashing red LED: Battery low
	Blue LED	Flashing blue LED: Bluetooth pairing
10		Blue LED lights up for two seconds: Bluetooth device is connected.
		Blue LED lights up in a clockwise direction: volume +
		Blue LED lights up in a counter-clockwise

	Green LED	Green LED illuminates for two seconds in a clockwise direction: power on.
		Green LED illuminates for two seconds in a counter-clockwise direction: power off.
10		Green LED illuminates for two seconds in part: battery remaining.
		Flashing green LED: incoming call
11	USB Cable	Connect the USB port of \$1000 to PC.

Installation Instruction

1. Turn on/off S1000

1. Turn on/off \$1000

51000 turns on automatically without using the Power ON/OFF button (#9) when it connects to power.

Press and hold Power ON/OFF #91 for 3 seconds to turn \$1000 on or off when it does not connect to any power. It will turn off automatically if there is no Bluetooth connection in 5 minutes. You hear "power on" and the LED indicator (#10) will light up green for 2 seconds in a chockwise direction when it turns on. You hear "power off" and the LED indicator (#10) will light up green for 2 seconds in a counter-clockwise direction when it turns off.

2. Connect to power and charge \$1000
Plug the USB Cable (#11) to USB Port (#8) of \$1000, and then, connect the other end of the USB Cable (#11) into any USB port of your PC or USB power adapter (not included) to charge the battery.



The indicator of Power ON/OFF (#5) is solid red when charging. The indicator or Power UNIVER* (#5) is solid red when charging. It turns solid white when it is fully charged. Press Power ON/OFF (#5), and green LED (#10) illuminates for two seconds in part to show battery remaining.

3. Connect to Bluetooth-enabled mobile devices

Press Bluetooth button (#7) into Bluetooth pairing mode. You hear "pairing" and the LED indicator (#10) flashes blue. Enable Bluetooth on your device and search new devices. Select "ADDA-S1000" as Bluetooth device. "ADDA-\$1000" as Bluetooth device.
When pairing is successful, you hear "Your device is connected."
and the LED indicator (#10) turns solid blue for two seconds and
then, turn off. The LED indicator (#7) turns solid blue.
Now you can take calls or stream media.
*** \$1000 will connect with the last successfully connected
Bluetooth device automatically.

4.Connect to PC through USB cable



Usage Instruction

Answer/end or reject a call
Press the call answer/end button (#4) to answer/end the call.
Press and hold the button(#4) for 3 seconds to reject the call.
The LED indicator (#10) flashes green when there is an incoming call.

Mute/unmute the microphone

Press the mute button (#1) to mute the microphone.
The mute indicator (#1) and the LED indicator (#10) will show

olid red.
Press again to unmute the microphone.

Adjust the volume
Press the volume + (#3) button to increase the volume and the blue LED indicator (#10) lights up in a clockwise

Press the volume - (#6) button to decrease the volume and the blue LED indicator (#10) lights up in a counter-clockwise

Activate the voice assistant on your mobile phone

Press the multifunctional button(#2) for 5 so the voice assistant of your mobile phone.

Activate voice prompt
Voice prompt will be activated automatically when \$1000 is powered on.

Trouble Shooting

1.When S1000 is connected to PC, there is no sound from the speakerphone. -Make sure to choose ADDA S1000 as defau**l**t p**l**ayback and recording device in the audio settings of your PC system.

Usage Attention:

Make sure to store the speakerphone when it is powered off. The speakerphone is not waterproof. Don't put it in humid environments. Extreme temperatures may affect the battery life and

Accessories

S1000 Speakerphone X1 USB Charging Cable X1 User Manual X1 Warranty Card X1







- Twombult the dealer or an experienced radio/ly technician for help.

 This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.
- transmitter.

 6. This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance of 20 cm between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

RED:

1. RF information

Bluetooth; 2402-2480MH;

- 2, CAUTION : RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.
- 3. Charger description: The product does not come with a charger as standard. It is recommended that the user can use the charger specification (5V 1A charger); The maximum operating temperature of the product, please refer to: Ideal temperatures: 0° C to 45° C for operating 4. The device complies with RF specifications when the
- device used at 20 cm form your body.