



TG 660



BECKER









VIDEO OUT (S-VIDEO)

VIDEO OUT (PAL/NTSC)

VIDEO OUT (SECAM)

VIDEO IN (S-VIDEO)

VIDEO IN (PAL/NTSC)

VIDEO IN (SECAM)

VIDEO IN (S-VIDEO)

VIDEO IN (PAL/NTSC)

VIDEO IN (SECAM)

VIDEO IN (S-VIDEO)

VIDEO IN (PAL/NTSC)

VIDEO IN (SECAM)

VIDEO IN (S-VIDEO)

VIDEO IN (PAL/NTSC)

VIDEO IN (SECAM)

VIDEO IN (S-VIDEO)

VIDEO IN (PAL/NTSC)

VIDEO IN (SECAM)


VIDEO IN (S-VIDEO)

VIDEO IN (PAL/NTSC)

VIDEO IN (SECAM)



Vor Öffnen des Gehäuses
Netzstecker ziehen.
Before opening
disconnect mains.
Avant d'ouvrir l'appareil
retirez la fiche môle.





TG660 Front View



TG660 Rear View

Änd. Index	Änderungs-Mitteilung	Datum	Name	Tag	Name	Benennung	Besteht aus
				Bearb.		Main Unit TG660	Blatt
				Gepr.			
				Freig.			
						Zeichnungs-Nr.	Blatt – Nr.
						33277-0100.000	
						Artikel – Nr.	Part.-No.
						0964.413-285	

BECKER
AVIONICS