


Model NO. 23594293



PINK Mini Dog Bluetooth Speaker

Style No.	AF17-AC-130
Size	5.86 x 3.97 x 1.73 inches Approx.
Weight	165g
Connect	Wireless
USB Charge Cord	11 Inches
Bluetooth Version	4.2
Frequency	150~20KHz
Input	DC 5V/500mA, 3.7V
Power Source	USB
Battery Type	UL Certified CLY 602030 li-polymer battery
Capacity	300mAh
Playing Time	2hrs
Charging Time	2hrs
Signal-to-Noise	75dB
Bluetooth Distance	32 Feet
Power On/Off	Hold Down the Power Button on the Bottom of the Dog

PINK Mini Dog Bluetooth Speaker

- ① Insert the Male USB port into a UL Certified USB Wall adapter or PC. *Using a non UL certified wall adapter IS NOT recommended
- 2 Plug Micro-USB cable into the Micro-USB Charging Port located on the bottom of the Dog.
- 3 It is recommended that the speaker is fully charged before its first use/pairing.
- A red light will illuminate, indicating the device is charging. ⑤ A full charge takes up to 2 hours.
- 6 When the red light turns off, the speaker is fully charged.

PINK Mini Dog Bluetooth Speaker

- Power On: Hold down the power button until you hear "Power on" voice prompt. You will then see a flashing blue light. This indicates the device is looking to pair with a phone.
- Pairing: Under your phone's Bluetooth settings, pair with the device named "PINK Mini Dog Speaker." When pairing is successful, the blue light will become solid and vou will hear "Connected" voice prompt.
- Playing Music: Choose a song and enjoy! The blue light will flash slowly when music is playing.
- Volume: Use the controls on your phone to raise and
- Play and Pause: Press the play and pause button on your phone
- Power Off: Hold down the power button until you hear "Power Off" voice prompt

PINK Mini Dog Bluetooth Speaker

- Phone Call: If you are receiving a phone call while the music is playing, the blue light will turn solid and the music will stop. When the call has ended, the music will resume. When you make a call, the music will stop
- NOTE: You cannot hear the person you are talking to through the speaker.
- Text Message: When you receive a text message while the music is playing, the music will continue to
- Notifications: When you receive a notification while the music is playing, the music will continue to play.

PINK Mini Bluetooth Speaker

Make sure the speaker is charged. If the speaker does not pair with your phone, power off the speaker and power it back on. If the issue persists, turn off your device and restart your phone. Check these further steps if you cannot resolve the issue:

- ① Make sure Bluetooth is enabled on your phone.
- ② Check that the speaker is not connected to another device.
- 3 Make sure you are within 32 feet of the speaker with no barriers (walls, other large electronics) between the device and your phone.

For further troubleshooting steps, please visit www.electronicinquiries.com

PINK Mini Dog Bluetooth Speaker Important Safety Instructions

IF USED IMPROPERLY, RISK OF ELECTRIC SHOCK COULD RESULT IN SERIOUS INJURY OR DEATH.

- Read these instructions.
- Keen these instructions
- Please pay careful attention to all warnings.
- Follow all instructions.
- 5. Only use the UL Certified Cord supplied by the
- 6. Unplug this device when unused for long periods of time.

PINK Mini Dog Bluetooth Speaker

When using electronic products, basic precautions should always be followed:

- DANGER: To prevent fire or shock hazards, do not expose to rain or moisture
- DANGER: A wet or contaminated micro-USB connector may cause excessive heat or melting and may lead to fire damage or personal injury. Always charge your speaker with a clean, dry micro-USB connector that is included with the product.
- CAUTION: Charge the Bluetooth Speaker by using only the original USB cable included with the speaker. Using another USB cable may damage the device.
- DO NOT use alcohol or any type of abrasives to clean the speaker. You may use a soft dry cloth.
- **DO NOT** attempt to disassemble the speaker. This may lead to damaging the speaker permanently or cause serious injury.

PINK Mini Dog Bluetooth Speaker WARNINGS/PRECAUTIONS - CONTINUE

- DO NOT expose the speaker to contact with sharp objects as this will cause scratching and damage.
- **DO NOT** stick anything inside the speaker as this may damage internal components and cause serious injury.
- DO NOT carry this unit by its cord or use the cord as a handle. **DO NOT** expose device to temperatures greater than 98°F (37°C). Lithium ion batteries contain flammable electrolytes that may vent.
- ignite, and produce sparks when subjected to high temperature **DO NOT** store the Bluetooth Speaker in any vehicle.
- DO NOT listen to the speaker while operating a vehicle. This may impair your ability to drive.
- Avoid severe physical shocks (ex. dropping).

 Never allow children to play with the speaker. Small parts may be a choking hazard.

PINK Mini Dog Bluetooth Speaker WARNINGS/PRECAUTIONS - CONTINUED

- WARNING: If you do not intend to use the device for a certain period of time, the power cable should be unplugged from the unit to prevent fire, damage, or corrosion.
- Store the speaker in a cool dry place.
- DANGER!: If the speaker is cracked or damaged, do not attempt to charge. This may cause electric shock or electrocution
- **DISPOSE OF THE DEVICE PROPERLY** at a recycling center

Questions or Inquiries? Visit www.electronicinquiries.com

MADE IN CHINA / FAIT EN CHINE / HECHO EN CHINA REYNOLDSBURG, OHIO, 43068, USA

ECC ID: 2AHXO1 THIS DEVICE COMPLIES WITH PART 15 OF THE ECC RULES DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE. (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRED OPERATION. CALITION: CHANGES AND/OR MODIFICATIONS NOT APPROVED BY VICTORIA'S SECRET PINK COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT

FACTORY ADDRESS: IXIN GLOBAL TRADE DONG TIAN PLAZA, SUITE 603, 19 HAIAN ROAD, GUANGZHOU CHINA 51062



NOTE: This equipment has been tested and found to comply with 13 the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- o Reorient or relocate the receiving antenna.
- o Increase the separation between the equipment and receiver.
- o Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- o Consult the dealer or an experienced radio/TV technician for help.

- The apparatus shall not be exposed to dripping or splashing and that objects filled with liquids, such as vases, shall not be placed on apparatus
- The batteries (battery pack or batteries installed) shall not be exposed to excessive heat such as sunshine, fire or the like.
- © Correct Disposal of this product. This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.
- No naked flame sources, such as lighted candles, should be placed on the apparatus.
- Attention should be drawn to environmental aspects of battery disposal
- The product is designed to use in moderate climates