Mobile phone use manual

Catalog

1. Basic knowledge of

1.1. Introduction

Thank you choose our mobile phones. You can read this manual, a comprehensive understanding of the cell phone use, appreciate the perfect function and simple operation method.

This color screen mobile phone is designed for network environment, this phone is dual SIM card to stay alone, in addition to the basic functions, the machine gives you also include number belongs to, handwritten input, touch screen, predictive Chinese input, phone book, scene mode, information, audio player, alarm clock, calculator, time, date and so on a series of practical function, in order to facilitate your work and leisure activities. In addition, the machine adopts the personalized man-machine interface design, the perfect function can meet your different needs.

The machine color screen mobile phone in line with the GSM technical specifications, and obtain certification authority.

The company reserves without any prior notice of the right to modify the contents in this manual

1.2. Safety requirements

If your phone is lost or stolen, please immediately notify the telecommunications sector or outlets, in order to disable the SIM card. This will protect you from the economic loss brought by the others take a call.

When you contact the telecommunication department or outlets, they need to know your phone's IMEI number (printed in the label on the rear of the phone, remove the battery can be found).Please send the copy number and properly keep, for future need.

In order to make you more secure use of mobile phones, please take preventive measures, such as: Set up mobile phone SIM card PIN code, PIN can prevent your SIM card is used by others without permission.
When you leave the car, please don't put the mobile phone is easy to see, had better carry or locked in the trunk.

1.3 Safety warnings and precautions

The use of mobile phones, please read carefully before these considerations to ensure proper use of mobile phones.

1.3.1. General considerations

On the plane, and the hospital to ban the use of mobile phones, please turn off the phone, otherwise it will affect the

normal work of the electronic equipment and medical instruments. Where the use of mobile phones, please comply with the related provisions of the place.

Please strictly abide by the laws and regulations related to drive you home of mobile phone use. If you are using a cell phone while driving, please observe the following rules: concentrate on driving, pay attention to the road conditions; If the phone has a hands-free function, please use the hands-free way; If driving conditions are bad, please stop, and then call or answer the phone.

Near the store fuel oil, chemicals or explosives and other places, please abide by the laws, regulations and the relevant symbol.

Please put the phone, batteries and chargers in the children's reach, lest it as a toy, cause personal injury.

Your phone can only use the company designated batteries, chargers and other accessories, in order to avoid damage to phone. The use of other batteries, chargers may cause battery leakage, overheating, explosion, fire, etc.).

Do not use near the weak signal or precision electronic equipment. Radio wave interference may cause the wrong operation of electronic equipment.

Please do not hit so hard, vibration or throwing mobile phones, to avoid handset malfunction or fire.

Please do not put batteries, cell phone, charger in the microwave or high voltage equipment, otherwise may cause circuit damage or accidents such as fire.

Do not use where there is flammable and explosive gas cell phone, otherwise the phone may result in failure or cause a fire.

Please do not placed the phone in high temperature, high humidity, or there is a lot of dust, otherwise may cause the phone fault.

Do not use mobile phone in a rough or unstable place, prevent fall cause failure or damage.

Please use only the original or approved by the company of the antenna. Approval of an antenna, modified, or added attachments may damage the phone. Do not touch the antenna during calls. Touch antenna will influence call quality and phone power higher than the normal use of the power required. In addition, the use of unauthorized antennas may be in violation of the provisions of the your country.

1.3.2. The cautions of the use of mobile phones

Do not remove or modified mobile phone, otherwise it will cause damage to phone, leakage and circuit failure.

Do not for LCD hard knocks or use it to knock something else, otherwise it will cause the breakage of the LCD panel and liquid crystal liquid leakage. If the LCD liquid into the eyes will there is a risk of blindness. Then rinse with water immediately eyes (don't rub the eyes), and immediately to the hospital.

In rare cases, mobile phone when used in some models of the car may have a bad effect on the vehicle electronic equipment. Then please do not use mobile phone in order to avoid loss of security.

If your vehicle is equipped with air sac, please don't mobile phones from the top of the balloon or balloons unfolds can hit area, in order to avoid air expands, mobile phone is very strong outside force, may cause serious damage to the owner.

Please do not use a needle to common in contact with sharp objects, such as keys, otherwise it will damage the mobile phone or wrong operation.

If the antenna is damaged, please do not use a mobile phone, otherwise it may cause harm to the person.

Avoid cell phone too close to magnetic objects, such as magnetic card, mobile phone radiation wave may remove the floppy disk, stored-value CARDS, credit CARDS to store information.

Please put away from an earpiece pins and other small metal place. Speaker magnetic at work, will attract these small metal, thus may cause harm to the person or damage to the cell phone.

Avoid mobile phone be affected with damp be affected with damp and water or other liquid into the mobile phone, mobile

phone short circuit, leakage or other defects.

Please as far as possible away from fixed-line phone , radio, and office automation equipment where cell phone use, so as not to affect the use of these devices and mobile phones.

1.3.3. Use the matters needing attention of the battery

Please do not remove or modified battery, otherwise it will cause battery leakage, overheating, burst or catch fire.

Don't throw old batteries into general household waste. Shall be specified in the waste battery treatment of place please instructions in accordance with the relevant provisions.

Do not throw the battery into the fire, otherwise it will lead to a battery fire or explosion.

When installing the battery, do not forcibly pressure, otherwise it will cause battery leakage, overheat, burst or burst into flames.

Please do not use wires, needles and other metal battery short circuit; Don't put battery and necklace metal together, otherwise it will cause battery leakage, overheating, burst or catch fire.

Do not weld battery contact, otherwise it will lead to leakage, overheat, burst, or a fire.

If the battery fluid into the eyes will have the risk of blindness, please don't rub your eyes at this moment, want to wash, and then go to hospital immediately.

Do not by the fire or high temperature place such as a heater use or place the battery, otherwise it will cause battery leakage, overheating, burst or catch fire.

If the battery in the process of use, charging or save the abnormal phenomenon such as heating, discoloration, deformation, please stop using and replace new battery.

If the battery leakage liquid met on skin, clothing, this may cause skin burns, immediately rinse with water, if necessary, please go to a doctor immediately.

If the battery liquid leakage or strange smells, please put it away from the fire, immediately to avoid fire or explosion.

Please do not make the battery be affected with damp be affected with damp, otherwise it will cause the battery overheat, smoke, or corrosion.

Do not use in direct sunlight and high temperature place or put battery, otherwise it will lead to leakage of liquid or overheating, may reduce performance, shorten service life.

Please do not charge for more than 24 hours.

Please put the battery from the sun, a cool, ventilated place.

The use of mobile phone battery life is limited. In frequent charging battery time gradually shortened. The multiple charging is invalid, the battery life is, should replace the specified type of new battery.

1.3.4. Use the charger

Please do not remove or modified charger, otherwise it will cause personal injury, electric shock, fire or damage of the charger.

Please use 220 v alternating current (ac).The use of other voltage will cause leakage, fire and cause damage to the cell phone and charger.

Prohibit short-circuit charger, otherwise it will cause electric shock, smoke and damage to the charger.

Please do not use the charger in the case of the power cord damage, otherwise it will cause a fire or get an electric shock.

Please clean the dirt on the power socket.

Please don't take such as containers of water are placed next to the charger, in order to avoid water splashing out charger circuit, leakage or other problems.

If the charger comes into contact with the water or other liquid, to cut off the power immediately, to prevent short circuit, fire, electric shock or the charger failure.

Please do not use the charger in the bathroom where high humidity, otherwise it will cause electric shock, fire or damage of the charger.

Please don't use wet hand contact chargers, cables and power socket, otherwise it will cause electric shock.

Don't put the weight on the power cord or modified wire, otherwise it will cause electric shock or fire.

Before cleaning and maintenance please pull out the charger plug from the power outlet.

Unplug to hold the charger, pull the power cord damage wires, cause electric shock or fire.

Please don't charging in the following places: direct sunlight and high temperature; Damp, dusty places or vibration can cause (failure).

1.3.5. Cleaning and maintenance

Do not use in the bathroom where high humidity cell phones, battery and charger, also want to avoid being wet.

With a soft dry cloth to clean your mobile phone, battery and charger.

Please do not use alcohol, thinner or benzene chemical reagents such as wipe the phone.

Have dirt can lead to poor contact, power socket, so that can't charge, please clean regularly.

1.4. Install the SIM card and memory card

1.4.1. The SIM card

You must before the use of mobile phones in the mobile phone to insert valid SIM card (user identity recognition module).SIM card provided by the network provider.

That are closely related to establish a network connection information is recorded in the SIM card chip, recorded in the card together with you in a SIM card phone book store name, telephone number, and short messages.SIM card can be removed from your mobile phone, into the arbitrary a GSM mobile phone use (novice the opportunity to automatically read the SIM card).

In order to prevent loss or damage the information in the SIM card, should avoid to touch the metal contact surface, and put a SIM card from electric, magnetic place.SIM card once damaged, you will not be able to normal use of mobile phones.

Note: be sure to turn off your phone before take out the SIM card. Absolutely prohibited in the case of the power supply is connected insert or remove the SIM card, otherwise may damage the SIM card and cell phones.

1.4.2. Insert and take out the SIM card

SIM card metal contact surface, it's easy to damage. Removed before assembly, must be careful.

Turn off the phone, remove the back cover, battery or other external power source;

In accordance with the instruction of the SIM card slot above, hold the SIM card into the direction of the arrow with his fingers moving into the card slot.

The installation of SIM card 1/2 the same operation.

Take out the SIM card, direct to gently pull can take out the SIM card.

Note: in this article shows that if there are no special instructions, all is according to insert 2 SIM CARDS to illustrate, if you only put 1 SIM CARDS, so some may not display the menu.

1.4.3. The memory card (SD card/T - Flash card)\

Remove the back cover and battery, storage card slot above follow the instructions given by the fingers holding the memory card to the direction of the arrow into the can.

Note: if the memory card down, please check whether the correct placement and good metal contacts.

1.5. The battery

1.5.1. Install batteries

Remove the phone back cover.

Aim the batteries with one end on the surface of the metal in the mobile phone battery connector.

Again with your fingers gently press down the battery the other side can install batteries.

Note: please correct operation in case of damage to the battery connector.

1.5.2. The charging

Use the charging line of form a complete set, insert the USB port of charging line is located in the first cell phone side the charging interface, and then insert the plug of the charging line power supply interface.

If the boot state, after insert the plug, the battery strength ICONS at the top right of the screen stripe has begun rolling said charge, when the stripe is full of the whole icon and stop scrolling, said the battery has been completed; Charging is completed in accordance with the charger on both sides of the button to pull the plug. If turned off, the screen display full screen scroll figure, when rolling figure into the battery is full of reminders, battery charging process is complete.

When the battery is low, there will be a warning message, at the same time, the battery is empty. Power is too low, the phone will automatically power off. Please do not make the battery for a long time in a state of battery is low, otherwise you will damage the battery quality and longevity. Please do not charge for a long time.

Note: to ensure that mobile phone to work properly, please be sure to use the designated charger.

2. The quick start guide

2.1 features

Your cell phone, except has the basic function of the mobile phone also support rich, practical, efficient features, brief introduction is as follows:

Contacts (phone book) : mobile phone can store up to 300 records; Support sending SMS in the phone book, supports replication between SIM CARDS and mobile phones phonebook records.

Scene mode: according to different events from the definition of the cellular phone or environment, including the bell set, volume, ring type, the system hint sound, the sound, switch machine.

Call records: your phone will automatically store information about phone records to see; Support call phone number of call records; Support will call records to keep phone number in the phone book; Support to the call records of the telephone number send text messages, and other functions.

Multimedia: audio player, FM radio functions.

Camera: your phone support a camera. You can be personalized according to need to use the camera to camera Settings.

Settings: you can undertake personalized Settings, according to the need of mobile phone including network Settings, mobile phone sets, security Settings, etc.

Input method: your mobile phone can use the keyboard input. Support for multiple input mode for you to enter English, letters, Numbers, characters, symbols, etc. Support more language input method

2.2. Make a phone call

1. Dial

There are several different ways for you to make a phone call:

Under the standby interface, manually by clicking on the keyboard can dial into the interface, the dial interface can manually enter the digital telephone number after dialing.

After extracted from receive text messages number allocated.

Dial the phone records of telephone number.

Dials the phone number of the stored in the phone book.

After the call or call the wrong number, if you want to hang up the phone, click the red button to hang up.

2. Call other functions of the operation:

Answering the phone

When you have a telephone, cell phone sends out the corresponding prompt (such as ring, etc.), if the network support, the Phone's screen will display the caller's name or number, you can press dial key to call at this time.

Decline a call

When you have to manually click the red button can decline a call.

Make an international call

Want to make an international call, please press the * key to display the number + (+ on behalf of the international code) before a dial-up, and then enter the country code, area code and phone number, press the dial key to dial the number.

Query the IMEI number

Standby mode, * # 06 # key input, query the IMEI number.

End calls

After the call, you can press red key to end call.

2.3. Call and its operation

In the process of calling, can make the following operations:

Hands-free calls: click ok button to go hands-free calls.

Switch: keep chatting on a phone, call on another phone.

The phone book, enter the phone book (directory) menu. Specific please refer to "address book". This function allows you to find the phone number in the call state for each other.

Information: this allows you to send information to a third party in the process of conversation.

Call records: this lets you enter the call records in the process of call.

Mute: will call voice mute.

2.4. The extension speed dial

If you want to enter the extension number after entering the number, please press "*" button to switch, and the "P" on the display screen will enter your extension number.Dial the phone and dial the extension.

2.5. To turn it off, key definitions

In the standby mode long press hang up (red key) can shut down your mobile phone.

The key definition and description	
Left soft key	Depends on the text button above the screen display
The right soft key	Depends on the text button above the screen display
The direction key	To scroll through menu name, phone number, etc. In standby mode, Left to write information, right for the situation mode, on the music player, next for the alarm clock
Key dialing 1	To use SIM1 calls and answering calls. Click this button to enter under standby SIM1 call records.
Hang up the key	End the current call, can also be used to exit from the menu to return to standby mode. Long press this button can switch machine
0-9 number keys	Standby press 0-9 number keys to enter dialing interface
* key	Standby short press the * key switch +, p, w characters
# key	To be the captain press the # key to enable or cancel the

	mute mode

3. The function menu

3.1 Contacts

This feature allows you to browse contacts, store, edit, and delete the name and phone number of phone and SIM card.SIM card storage capacity depending on the different CARDS, this machine is the largest storage capacity of 300.

Interface according to the address book icon into the phonebook list, click add contact after, you can set the contact name and phone number, click save to complete the new.

Phone book records is not null, the record list interface, press "options", you can carry out the following operations:

Note: the following records stored in the SIM card 1, for example.

3.1.1.New

Create new contacts on your SIM card or phone

3.1.2. Write message

Send text messages

You can send text messages to the current number.

Send MMS

You can send MMS to the current number

3.1.3. Call

Call the number, can direct dialing.

3.1.4. Delete

You can delete the current record.

3.1.5. Delete multiple

You can check the record you want to delete

3.1.6. Import/Export

You can perform replication import and export operations

3.1.7. Send vCard

You can send this record via SMS MMS Bluetooth

3.1.8 Others

1. Speed dial; Can set up 2-9 number keys speed-dial function

2. Own number; You can add the native number here

3. Memory status: Query "SIM card", "mobile phone" memory address book usage status

You can also create new groups:

System by default has family, friends, business, classmates

3.2 Messaging

3.2.1. Write message

SMS

You can use this function to write short messages. Input you want to send information, you can send and add the contact information, save the operation.

-- send: information in the edit interface, when editing information is complete, if you are recovery information directly to the recipient, entering a number of recipients display interface, then click send; If new information, send into the phonebook choose number.

-- save to draft: keep this message to the draft box.

3.2.2. Inbox

Option 1 the SMS/MMS, you can reply, delete, contact the sender, and so on.

check list in your inbox interface, in the cursor click the SMS/MMS reading SMS/MMS content.

-- delete: delete change message information.

-- reply: reply message or multimedia message to the sender.

-- Forward: send this message to other contacts

-- Call the sender: call the sender's phone number.

-- Add sender to: You can add this record to the contact

-- Details: You can view the sending date and location of this information

3.2.3. Outbox

Send storage failure messages. Message list at the back of the icon indicates the message is stored in the SIM card or stored on the phone.

Option 1 the SMS/MMS, you can for Resend, delete, lock, mark, sort,

-- Resend: which sent SMS/MMS.

-- Delete: delete this message.

-- Lock: This information will be locked and will not be deleted

-- Mark: After check, you can delete the lock or other operation for this information

3.2.4. Drafts

Store edited text. Message list at the back of the icon indicates the message is stored in the SIM card or stored on the phone.

Option 1 text messages, you can view, delete, edit, lock, mark, sort, and so on.

Delete: delete this message.

-- edit: edit this message.

-- view: view information content.

-- send: to resend this message.

3.2.5. Sentbox

Store sent successfully. Message list at the back of the icon indicates the message is stored in the SIM card or phone.

Option 1 the SMS/MMS, you can delete, forward, mark, sortand so on.

-- Delete: delete this message.

-- forward: send this message to other contacts.

-- Mark: After check, you can delete the lock or other operation for this information

Open a message, you can call forwarding, delete, call and etc.

-- forward: please forward this message to others.

-- Delete: delete this message.

-- Call: call the recipient.

3.2.6.Templates

You can select the information template to send or edit what you want

3.2.7. Broadcast message

This feature requires SIM card support

3.2.8. Voice mail server

This feature requires SIM card support

Messaging   set

-- card information center number: show the SMS center number SIM card 1.

-- card information center number: display the SMS center number SIM card 2.

-- the validity of information: you can set the information is valid for 1 hour, small six

When, 1 hours, 6 hours,24 hours, 72 hours, 1 week, maximum.

Note: the time associated with the service of network operators.

-- a status report: can choose to open or close a status report. Open the work

Can be later, when you successfully send text messages, you will receive SMS status report.

-- save the sending information: there are "open" and "off" for you to choose.

Prompt the user to choose: before send text messages, will let you select send and save, send a.

Save: automatically save you send text messages of success.

Don't save: save you send text messages of success.

Message   capacity

You can view the capacity of each message

3.3 Call logs

3.3.1.Missed calls

Displays a list of phone Numbers that you haven't received recently.The operation is with the telephone.

3.3.2.Dialled calls

Show you dial the phone number list recently.

In the dial the telephone list interface, press "options" to enter options list interface, the interface you can undertake the following list of options.

Details: You can view the details of this record, such as: number, date, time

Call: call the number directly.

Saved in the phone book: the number added to the SIM card or mobile phone.

Send SMS/MMS: you can send SMS/MMS to this number.

Add to blacklist: This record can be added to the blacklist

Delete: delete which have dial the phone.

Delete all: delete all the records

Mark: This record can be marked

3.3.3. Received calls

Displays a list of phone Numbers that you have recently received.The operation is with the telephone.

3.3.4. Rejected calls

Displays a list of phone Numbers that you have recently rejected.The operation is with the telephone.

Call setup

3.3.5.Delete all

You can delete all calls, incoming calls, incoming calls and incoming calls at the same time.

3.3.6. Call timers

Display all call times

3.3.7. GPRS counter

Displays the traffic information used on the SIM card

3.4 Settings

3.4.1.Call settings

   Call forwarding: call forwarding functions after open, according to a set of transfer conditions, under the condition of the corresponding electric transfer to voicemail or other number in the future.

-- unconditional jump - all the call will be transferred to voicemail or you to set the phone number.

-- when busy transfer: when your phone is busy, the call will be transferred to voicemail or you to set the phone number.

   Transfer - no answer: when you have not answer your phone, the call will be transferred to voicemail or you to set the phone number.

-- can't reach the transfer: if your phone cannot be reached, such as shutdown or not in service area, the call will be transferred to voicemail or you to set the phone number.

   Cancelled - transfer: you can cancel all transfer Settings.

   N call limit: limited allocated, limit call, cancel all, change the password for your choice.

-- limit set aside: open this function, will exhale phone is prohibited.

   After -- limit calls: open this function, all calls will be banned.

-- the cancellation of all: speak to cancel all restrictions.

-- change password: talk about the password, you can consult your network operator.

   Call waiting: you can open or close the function, call waiting function is turned on, when you on the phone, the other a phone call can be reached.

   Others

- IP prefix: IP number can be set

- Call time minute reminder: Set the time you need to remind

- auto redial: can open closed

-Vibration when connected: can open closed

-Auto record voice call: can open closed

Note: the above function need network support, if you want to use this function, need to network operators.

3.4.2. Phone setting

   Date of time: you can set the date and time of the phone.

   Language settings: you can choose the language of the mobile phone.

   Shortcut settings: can be up and down or so key function

   Auto power on/off: can set the switch machine time

   Power management: Check the battery capacity

   Restore factory Settings:

Privacy protection password recovery factory setting, can restore to factory setting default value.The privacy of the default password is 1234

3.4.3. Display

 -Power on/off Display: You can set up all kinds of on-off maneuver drawings you want

 - Wallpaper Settings: You can set different wallpaper.

  -Idle display settings: You can open or close

 -Contrast: Sets different backlight brightness for the screen

-Keypad backlight time: Set different backlight times for the keyboard

-Auto keypad lock: Sets different backlight brightness for the screen

3.4.4. Security

PIN: You can open and close the PIN code or modify the PIN code. When opening or closing PIN must enter the correct PIN. If launched the PIN test, every time open the phone, need to input PIN. If you lose three times wrong PIN, SIM card will be locked. Need a PUK1 unlocked. If you need a PUK1 code, please contact the network operator. The default PIN number is 1234. PIN2 code: you can modify the PIN2 code. For details, please contact the network operator.

Phone locked: you can open and close this password or change this password. When to start the "password" function, you need to enter a password every time you boot.

Privacy: You can enter a password to set up the privacy protection menu

Lock screen by end-key: To open this function, press the red button in the standby interface to lock the screen

Blacklist: Add the number you want to reject to this list and open it, and you can choose to block incoming calls or text messages

3.4.5. Profiles

Scene mode have Normal/mute/meeting/indoor/outdoor model.

You can to start each model, individual set, reset, and so on. In normal Settings, you can make the following operations:
The ring set

You can set the ringing phone ring and information.
Volume

You can adjust the phone ring, such as information the bell, the sound volume.
Ring type

You can set the ring type
Other alert rings

You can set the key tone. Battery low alert, Power ringtone, Dial tone

3.4.6 Connections

Can choose data connection SIM card and account

3.5 Multimedia

3.5.1. Camera

Photo set

Enter the picture preview interface, you can watch through the screen image.

According to the options menu for the following:

-- photo album: see pictures of photograph.

--DV mode: Enter camera mode and start recording

--Effect: Different effects can be set

-- camera Settings: can set the following functions: the shutter sound compared to avoid flash exposure compensation, the delay. The above Settings feature is set by default, you can also be set automatically according to need.

Photo Settings:

-- photo size: 160 * 120, 640 * 480.360 * 400

-- photo quality: Low ,Normal and Advanced

--Banding : Can set 50/60Hz

--Shutter sound: Can open or close

--Auto save; Can open or close

--Preferred storage: You can choose to store it on your phone or SD card

Note: when taking pictures, please comply with all local laws and regulations about taking pictures. Please don't illegal to use this feature

3.5.2.DV

Your phone support functions of video footage. The default avi video format, through the video player play the video you recorded the menu.

3.5.3.Image

Can be carried out on the album view browsing send way used to rename delete sorting storage location Image information

3.5.4.Audio

This cell phone can play MP3 audio file in memory card, and support MP3 background play.

Each icon, click the play interface can be the following:

OK button: play or pause switch.

Left/right navigation key: one or the next.

Up/down navigation keys: adjust the volume

Progress bar: long press left and right navigation key to choose songs.

Note:

The MP3 files should be on the phone memory or the SD card in my audio folder.

3.5.5.Video

Go to video, press OK to start playing or stop, default AVI video format.

3.5.6.FM radio

You can also through the options menu to achieve the following:

Auto search and save: Automatically search and save the search to the channel list

Channel list: Automatically save the search channel or manually enter the channel

Manual search: manual input channel.

Open speaker: The speaker can be turned on or off

Background play: on and off.

Record: Audio recording

Scheduled recording: Automatic recording time, channel, etc

Record file list: You can view the recording list file and operate it

Storage: You can choose to store it on your phone or SD card

Help: See your mobile phone for instructions

Note: Insert headphone before using FM

3.5.7.Sound recorder

Through this menu the file to be recorded, need to insert memory card record.

3.6 Games

The machine has built-in small games for your entertainment

3.7 My files

This feature allows you to view files stored on your phone and an SD card

Music (my music)：

Save the MP3 file audio files. If you saved the valid documents, click on the audio list, select the audio files (also available in "multimedia" audio player menu to preview the files in this folder), click on the "options" can be carried out the following operations: a new folder, play, send files, used for telephone, rename, copy, delete, move, etc.

Note: within the resource manager, if you are in: file management - > options - > format - "formatting an SD card, will delete the entire contents of the SD card, but will be automatically generated over the empty folder.

3.8 Tools

3.8.1. SOS setting

Mode setting: Only call, only SMS, call and SMS mode Settings

Number setting: Enter the SOS menu to manually set up three groups of distress Numbers. After setting the SOS number, the status setting is set to be turned on, and the waiting interface will press OK key to execute the call.

Sms setting: When launching the SOS function, the machine will ring the alarm sound and call the setting of the SOS number, and automatically send the text message to the assigned first aid number;

3.8.2.Calculator

This feature allows you to mobile phone become a calculator, carry on some simple arithmetic

3.8.3. World clock

Can be viewed or edited

3.8.4.Alarm

You can edit the alarm clock time, prompt type, repeat mode.

Alarm clock editing interface, when the cursor is positioned on the items that you want to set up, according to determine the key to enter select the Settings you want.

3.8.5.Calendar

This function allows you to view the calendar. In the calendar interface, you can for the following operation.

1. Add new schedule

2. View schedules

3. All schedules

4. Clear today's schedules

5. Clear all

6. Go to date

7. Weekly

8. Daily

3.8.6.Unit conversion

All kinds of conversion can be done

3.8.7.Memo

It's convenient for you to record things

3.8.8.Bluetooth

You can use the bluetooth switch to query the matching device, the search device and the setting of the relevant bluetooth functions

3.9. Internet

You can manually enter the web page you want to browse

Note: the effective SIM card will be inserted before using the web service, and the GPRS flow will be generated

4. The input method is introduced

Your mobile phone provides multiple input mode for you in the new, edit phonebook records and write a short message with calendar functions such as input data or text.

Note: click to enter text area into the input, the input screen will be automatically displayed in the input mode of the region input method.

5. Maintenance and maintenance

Battery maintenance

•This phone is a rechargeable battery as a power source. When power weak, please send the battery. To maintain battery life, the best will run out the battery before charging.

•When the battery charger is not used, please with the power supply source separation. Do not connect the charger with battery more than a week, over charge will shorten the battery life.

•Temperature affects the limits of the battery to charge. So, before charging the battery may need to be cool or warm. If the battery more than 40 degrees Celsius temperature, the battery can't charge.

• please put the battery on its original use, avoid to cause the battery to short circuit. When the conductive material is connected directly to battery cathode will cause a short-circuit.

•Do not use the damaged cells.

• put the battery in extremely cold or hot place can lead to shorten the battery life, battery exposed to cold or hot place may lead to can't normal mobile phone function, even if the battery is the electricity as well.

• please don't put battery in the fire! Please according to the local regulation to deal with waste batteries.

Mobile phone maintenance

The following Suggestions will help you to take care of your mobile phone:

•All mobile phones and accessories, far from where the children can touch.

•Please keep the body dry, liquid can cause metal corrosion circuit.

• please take the body away from high temperature, high temperature will shorten the service life of electronic devices, melt plastic and damage to the battery.

•please do not attempt to open the cabinet or cell phone, non-professional disassembly may cause damage of the body.

•do not use strong acid or alkaline detergent to clean the body.

Only use a mobile phone original accessories. Violation of these may lead to warranty.

6. The security information

When using your mobile phone, must abide by the environment and to protect the user from safety regulations.

The traffic safety

•unless there is an emergency, if not installed to ensure the safety and freedom of hands-free devices, please do not use cell phone when driving, to ensure that you concentrate on driving, please put the car to a safe place to use a mobile phone. Please abide by relevant laws and regulations.

•Without enough protection, car of some electronic system may be affected by your phone launch waves.

• it is recommended that you only use of mobile phones in cars with external antenna.

• only qualified technicians can install your cell phone in your car.

The safety of the flight

Before boarding the plane, please close your mobile phone, because it affect the operation of the flight and the cellular

network. Aircraft on cell phone use is illegal, in violation of these safety regulations will be prosecuted or denial of service caused by GSM network.

Environmental safety

• remember that in any place to comply with the current specific rules and regulations, where the ban on the use of mobile phones, or may cause interference or danger, be sure to turn it off.

•the use of any wireless transmission equipment, including cellular phones, is likely to interfere with some improper protection of medical equipment. If you have any questions, in this regard can contact the doctor or medical equipment manufacturers.

• your mobile phone is likely to interfere with some hearing AIDS, pacemakers and other medical electronic equipment. Please comply with the doctor or medical equipment manufacturers to provide advice.

•Anywhere in the likely to cause explosion, such as gas stations, chemical plant, suggest users to turn off the phone.

To comply with the requirements of the limitations about the use of wireless devices.

7. The technical specification

The range of the network: GSM900MHz/DCS1800MHz

The actual situation of mobile phone use and the local network environment situation, SIM CARDS and users to use.

Instructions: if involves the version upgrade, without prior notice. The company has finally of this manual The power of interpretation.

Warning: due to the user does not comply with the above Suggestions or consequences caused by the improper use of mobile phones, manufacturers disclaim all responsibility.

•**Environmental friendliness**

Part name	Poisonous and harmful substances or elements					
	lead（Pb）	mercury (Hg)	cadmium (Cd)	Hexavalent chromium (Cr(VI))	Polybrominated biphenyls (PCBS)(PBB)	pbdes (PBDE)
The host	×	○	○	○	○	○
The charger	×	○	○	○	○	○
The battery	×	○	○	○	○	○
The headset	○	○	○	○	○	○
cable	○	○	○	○	○	○
Memory card	○	○	○	○	○	○
Packaging materials	○	○	○	○	○	○
○: it means the material in the part all the content in homogeneous material in the SJ/T11363-2006 standard of set limit to request the following.						
×: it means the material is at least the part of a homogeneous material content beyond the SJ/T11363-2006 standard of set limit to prescribed requirements.(this product conforms to the eu ROHS environmental protection requirements: at present there is no international mature technology can replace or reduce electronic ceramics, optical glass, steel and copper alloy of lead)						

FCC RF Exposure Information and Statement

This device meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The

standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health. The SAR limit of USA (FCC) is 1.6 W/kg averaged. Device types: 3G Mobile Phone (FCC ID: 2AI3KCM8SA) has also been tested against this SAR limit. SAR information on this and other pad can be viewed on‐line at http://www.fcc.gov/oet/ea/fccid/. Please use the device FCC ID number for search. This device was tested simulation typical 10mm body. To maintain compliance with FCC RF exposure requirements, use accessories should maintain a separation distance between the user's bodies mentioned above, the use of belt clips, holsters and similar accessories should not contain metallic components in its assembly, the use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.