

SAFETY INFORMATION



MEATER PRO XL

Charger Battery Type	Lithium
Charger Battery Nominal Voltage	3.7V
Charger Battery Size	14 x 50mm (AA) Per cell
Charger Battery Quantity	1
Charger Model Number	MT-MX201, MT-CX20
Probe Model Number	MT-PR21, MT-PR24
Probe Battery Nominal Voltage	2.4V
Probe Capacity	3mAh
Operating Frequency	2402 - 2480 MHz
WLAN Frequency	2412 - 2462 MHz
Importer Name & Address	Apption Labs , 66 Commercial Square, Leicester, LE2 7SR, UK MEATER , 3779 Cahuenga Blvd Studio City, CA 91604 United States Apption Labs GmbH, Frei-Otto-Straße 4, 80797 München, Deutschland

Read All Instructions Before Using

Please read this entire manual before using your MEATER product. Failure to follow these instructions could result in property damage, bodily injury, or even death. If you are assembling this product for someone else, provide this manual for the owner to read and save for future reference.



WARNING

Burn Hazard

Failure to follow the warnings below may cause the MEATER probe to explode and lead to serious injury or burns.

Always insert the MEATER probe past the safety notch (the minimum insertion point) to avoid product damage and personal injury.

DO NOT place MEATER Pro XL (charger) on or near a hot surface.

DO NOT remove MEATER Pro Probe while Probe is exposed to heat. MEATER Pro Probe must be inserted and removed from food away from all heat sources.


If the MEATER Pro Probe falls into the fire or direct heat source, close the lid of the grill/cooking appliance and turn off the grill or cooking appliance immediately. Allow the MEATER Pro Probe time to cool completely before removing.

DO NOT allow MEATER Pro Probe to come in contact with hot charcoal or coals.

MEATER Pro Probe will be hot during and after use. Use heat-resistant gloves when handling probes.

Foodborne Illness Hazard

Consuming raw or undercooked meats, poultry, or seafood can lead to a serious risk of foodborne illness. Always cook your food to USDA safe temperatures.



CAUTION

Product Damage Hazard

Always insert the MEATER probe past the safety notch to avoid damage.

DO NOT use the probe in a microwave or pressure cooker.

DO NOT place probe charging dock on any hot surface.

DO NOT drop the probe onto hard surfaces.

DO NOT use cleaning products containing alcohol, ammonium, benzene, or abrasives, all of which could damage the device.

DO NOT run the probe under cold water immediately after cooking. Let the probe cool down prior to washing.

DO NOT exceed probe internal sensor limits of 221°F (105°C) or probe ambient sensor limits of 300°F (150°C). Temperatures above these maximums may damage probe.

Store the probe in a dry, cool place when not in use. This product is only designed for use in food. Use it only for its intended purpose.

This product is only designed for use in food. Use it only for its intended purpose.

Sharp Point Hazard




Always keep the MEATER probe pointed away from fingers and body. Contact may result in injury. Keep out of reach of children.

Electrical Shock Hazard

Keep probe charging dock away from water and liquids. Failure to do so may cause electrical shock. Ensure the probe is completely dry before placing it back in the charging dock.

Getting Started

Before using your MEATER 2 Plus, ensure the product has been charged and you have reviewed the important safety information on this page.




If you need any assistance using your MEATER device or have any questions, please check out our Support Wizard and FAQ. If you need to speak to a member of our dedicated support staff, you can use the Support Wizard to help navigate you to the correct team.




Support

Step-by-step troubleshooting and customer support



FAQ

Answers to our most common concerns



Contact Us

Business enquiries, press and influencers



What is the maximum temperature MEATER can be used at?

The maximum temperature the ambient tip of the MEATER probes can withstand is 1000°F (550°C).

The maximum temperature the internal temperature sensor can withstand is 221°F (105°C).

To ensure the safety of the probe, the MEATER app will alert you when you get too close to these limits.

Make sure to always insert the MEATER probe into your meat past the safety notch to avoid damage to the internal sensor.




To reset the MEATER Pro XL, press and hold the reset pin on the back of the unit for a few seconds.

The back panel of the MEATER Pro XL is not removable, to locate serial number and compliance information please press the retractable tray located underneath the MEATER Pro XL stand. This will cause the tray to release. Press it back in to close.

Important Safety Information

Charcoal Grill Cooking



Always insert the MEATER probe past the safety notch.

Ensure the probe is firmly inserted and not loose before cooking.

DO NOT cook with MEATER if the probe can't be inserted past the safety notch.


Always wash your hands after handling raw meat.



Place the meat over indirect heat on your grill.


DO NOT remove the probe while it is exposed to heat. The probe must be inserted in and removed from meat away from all heat sources.

Always use eye protection when removing a probe that has exceeded the maximum temperature or come in contact with hot charcoals or direct flames.




Carefully remove the meat from the grill when prompted by the MEATER app.

DO NOT remove the probe from the meat while on the grill.




Allow your meat to rest until the app tells you it is ready.

Once ready you can reverse sear your steak over direct heat (above the coals) on your grill, for a delicious finish.



Once rested (and seared) you must wait for the ambient temperature to reduce to safe levels before removing the MEATER probe.

If the probe is difficult to remove, pull and twist the ambient end. Do not bend the probe against the meat.



Once your meat is seared, serve and enjoy!

General Information

Information for the User

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

MEATER Charger Model Number: MT-MX201, MT-CX20
MEATER Probe Model Number: MT-PR21, MT-PR24

Patents: meater.com/patents

MEATER Pro Probe
MT-PR21 - MT-PR24 FCC ID: 2A16MTP2
MT-MX201, MT-CX20 IC: 24713-MTP2
CAN ICES-3 (B) / NMB-3 (B)

MEATER Pro XL
MT-MX201, MT-CX20 FCC ID: 2A16JMTX2
MT-MX201, MT-CX20 IC: 24713-MTX2
CAN ICES-3 (B) / NMB-3 (B)

Herby, Apption Labs Ltd declares that the radio equipment type MEATER Pro XL (MT-MX201, MT-CX20) & MEATER Pro Probe (MT-PR20 - MT-PR24) is in compliance with Directive 2014/53/EU.

The product complies to the Radio Equipment Directive and applicable standards, as well as the food contacting requirements LFGB.

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Cet équipement est conforme aux limites d'exposition aux rayonnements EM établies pour un environnement non contrôlé. Cet équipement doit être installé et utilisé avec un minimum de 20 cm de distance entre la source de rayonnement et votre corps.

Declaration of conformity
We, Apption Labs GmbH, declare under our sole responsibility that the product mentioned above complies with the essential requirements of the stated EU Directive. The EU Declaration of Conformity can be found here - <https://meater.com/ce-declaration/>

Disposing of the packaging
Dispose of the packaging separated into single type materials. Dispose of cardboard and carton as waste paper and film via the recyclable material collection service.

Disposing of the product
(Applicable in the European Union and other European states with systems for the separate collection of reusable waste materials)
Old devices must not be disposed of with household waste! If the product can no longer be used, all users are required by law to dispose of old devices separately from their household waste, e.g. at a collection point in their community/borough. This ensures that old devices are recycled in a professional manner and also rules out negative consequences for the environment. For this reason, electrical equipment is marked with the symbol shown here.

Batteries and rechargeable batteries must not be disposed of in the household waste! As the end user you are required by law to bring all batteries and rechargeable batteries, regardless of whether they contain harmful substances or not, to a collection point run by the communal authority or borough or to a retailer, to allow them to be disposed of in an environmentally friendly manner.

Bring the product (including the battery or rechargeable battery) to your collection point and make sure that it is in an uncharged state.
Labelled with: Cd - cadmium, Hg - mercury, Pb - lead

More information
<https://support.meater.com/contact-us>

Limited Warranty and Return Policy

Apption Labs hereby warrants that the MEATER product is free from defects in parts, materials, and workmanship under normal use and maintenance for a period of two (2) years if purchased in the EU, Great Britain, Canada, Australia, and New Zealand, and one (1) year in the USA and all other countries from the date of original purchase. This warranty does not include shipping charges associated with any warranty parts or products.

Apption Labs shall not be liable under this or any implied warranty for incidental or consequential damages. This warranty gives the retail customer specific legal, rights and the customer may have other rights which vary by state and country.

This warranty shall be void if the MEATER product is not assembled or operated in accordance with the provided user instructions: the product is resold or traded to another owner; components or accessories not compatible with the product have been used; the product has been used in commercial or food service application; or the user has abused or otherwise failed to maintain the product.


To process a warranty claim, Apption Labs may require proof of your purchase. You should retain your sales slip or invoice.

Full warranty and return policy can be found on our online website: meater.com/warranty-returns.

Full company policies can be found on our online website, meater.com/support and supersedes any information found in this user guide.

Should any repairs or servicing under this warranty be required by you during the limited warranty term, please contact the Customer Happiness Team at meater@apption.com.

Recycling and WEEE



The below section details MEATER's compliance with WEEE disposal of waste electrical and electronic equipment.

Austria

EU-Recht in nationales Recht umgesetzt.
Die Umsetzung stellt sicher, dass Elektro- und Elektronikgeräte aus privaten Haushalten kostenlos an öffentlichen Sammelstellen zurückgegeben werden können.

Elektro- und Elektronik-Altgeräte dürfen nicht mehr im gemischten Siedlungsabfall entsorgt werden, sondern müssen bei den dafür vorgesehenen Sammelstellen abgegeben werden. Funktionale Geräte können wiederverwendet oder wertvolle Komponenten aus defekten Geräten recycelt werden. Dies soll zu einer effizienteren Ressourcennutzung und damit zu einer nachhaltigeren Entwicklung beitragen. Zudem können nur durch die getrennte Sammlung gefährliche Bestandteile der Geräte (wie FCKW oder Quecksilber) adäquat behandelt und somit negative Auswirkungen auf die Umwelt und die menschliche Gesundheit vermieden werden. Sie haben kostenlose Rückgabe- und Sammelmöglichkeiten für Ihre privaten Altgeräte bei den Kommunen und den Herstellersystemen. Einen Überblick über die bestehenden Sammelstellen erhalten Sie auf folgender Website: <https://secure.umweltbundesamt.at/eras/registerabfrageAGSammelstelleSearch.do>

Alle elektrischen und elektronischen Geräte für den Haushalt sind mit dem Symbol einer durchgestrichenen Mülltonne gekennzeichnet. Diese Geräte können bei allen unter dem Link aufgeführten Sammelstellen abgegeben werden und dürfen nicht über den Hausmüll entsorgt werden.

Germany

Verpackungsregister-Lucid: DE1636919034729

Batterieregistrierung: DE9905416

Elektro- und Elektronikgeräte
Informationen für private Haushalte
Das Elektro- und Elektronikgerätegesetz (ElektroG) enthält eine Vielzahl von Anforderungen an den Umgang mit Elektro- und Elektronikgeräten. Die wichtigsten sind hier zusammengefasst:

1. Getrennte Erfassung von Altgeräten
Elektro- und Elektronikgeräte, die die Abfall werden sind, werden als Altgeräte bezeichnet. In den Haushalten haben diese einen besonderen Status. Sie müssen getrennt von anderen Abfällen gesammelt werden.

2. Rücknahme von Elektro- und Elektronikgeräten
Besitzer von Elektro- und Elektronikgeräten können diese bei den Sammelstellen der öffentlich-rechtlichen Entsorgungsträger oder bei den von Herstellern oder Vertriebern im Sinne des ElektroG eingerichteten Rücknahmestellen unentgeltlich abgeben.

3. Möglichkeiten der Rückgabe von Elektro- und Elektronikgeräten
Rücknahmepflichtige sind Geschäfte mit einer Verkaufsfläche von mindestens 400 m² für Elektro- und Elektronikgeräte sowie diejenigen Lebensmittelgeschäfte mit einer Gesamtverkaufsfläche von mindestens 800 m², die mehrmals pro Jahr oder dauerhaft Elektro- und Elektronikgeräte anbieten und auf dem Markt bereitstellen. Dies gilt auch bei Vertrieb unter Verwendung von Fernkommunikationsmitteln, wenn die Lager- und Versandflächen für Elektro- und Elektronikgeräte mindestens 400 m² betragen oder die gesamten Lager- und Versandflächen mindestens 800 m² betragen. Vertrieber haben die Rücknahme grundsätzlich durch geeignete Rückgabemöglichkeiten in zumutbarer Entfernung zum jeweiligen Endnutzer zu gewährleisten.

4. Die Rücknahme von Elektro- und Elektronikgeräten
Die Möglichkeit der unentgeltlichen Rückgabe eines Altgerätes besteht bei rücknahmepflichtigen Vertriebern unter anderem dann, wenn ein neues gleichartiges Gerät, das im Wesentlichen die gleichen Funktionen erfüllt, an einen Endnutzer abgegeben wird. Wenn ein neues Gerät an einen privaten Haushalt ausgeliefert wird, kann das gleichartige Altgerät auch dort zur unentgeltlichen Abholung übergeben werden; dies gilt bei einem Vertrieb unter Verwendung von Fernkommunikationsmitteln für Geräte der Kategorien 1, 2 oder 4 gemäß § 2 Abs. 1 ElektroG, nämlich „Wärmeüberträger“, „Bildschirmgeräte“ oder „Großgeräte“ (letztere mit mindestens einer äußeren Abmessung über 50 Zentimeter). Zu einer entsprechenden Rückgabe-Absicht werden Endnutzer beim Abschluss eines Kaufvertrages befragt. Außerdem besteht die Möglichkeit der unentgeltlichen Rückgabe bei Sammelstellen der Vertrieber unabhängig vom Kauf eines neuen Gerätes für solche Altgeräte, die in keiner äußeren Abmessung größer als 25 Zentimeter sind, und zwar beschränkt auf drei Altgeräte pro Gerätart.

5. Datenschutz-Hinweis
Altgeräte enthalten häufig sensible personenbezogene Daten. Dies gilt insbesondere für Geräte der Informations- und Telekommunikationstechnik wie Computer und Smartphones. Bitte beachten Sie in Ihrem eigenen Interesse, dass für die Löschung der Daten auf den den entsorgenden Altgeräten jeder Endnutzer selbst verantwortlich ist.

6. Bedeutung des Symbols „durchgestrichene Mülltonne“
Das auf Elektro- und Elektronikgeräten regelmäßig abgebildete Symbol einer durchgestrichenen Mülltonne weist darauf hin, dass das jeweilige Gerät am Ende seiner Lebensdauer getrennt vom allgemeinen Siedlungsabfall zu entsorgen ist.

Denmark

Elektrisk og elektronisk udstyr (EEE) indeholder materialer, komponenter og stoffer, der kan være farlige og skadelige for menneskers sundhed og for miljøet, når affaldet af elektrisk og elektronisk udstyr (WEEE) ikke bortskaffes korrekt.
Produktet, der er mærket med nedensidende overkrydsede skraldespand, er elektrisk og elektronisk udstyr. Den krydsede skraldespand symboliserer, at affald af elektrisk og elektronisk udstyr ikke må bortskaffes sammen med usorteret husholdningsaffald, men skal indsamles særskilt.

Til dette formål har alle kommuner etableret indsamlingsordninger, hvor affald af elektrisk og elektronisk udstyr gratis kan afleveres af borgerne på genbrugsstationer eller andre indsamlingssteder eller hentes direkte fra husholdningerne. Nærmere information skal indhentes hos kommunens tekniske forvaltning.

Brugere af elektrisk og elektronisk udstyr må ikke bortskaffe affald af elektrisk og elektronisk udstyr sammen med husholdningsaffald. Brugere skal benytte de kommunale indsamlingsordninger for at mindske den miljømæssige belastning i forbindelse med bortskaffelse af affald af elektrisk og elektronisk udstyr og øge mulighederne for genbrug, genanvendelse og nyttiggørelse af affald af elektrisk og elektronisk udstyr.

Ireland

PRL Number - 03364WB

Waste Electrical and Electronic Equipment (WEEE) is taken back free of charge on a one-for-one, like-for-like basis. Waste batteries including rechargeable batteries are taken back free of charge. You are not obliged to make any purchase when returning old batteries. Each local authority must also accept household WEEE and small batteries free of charge at its recycling facilities. All WEEE and waste batteries must be recycled and should not be placed in any of your household wheeled bins. Make sure you always recycle all your old electrical goods and batteries.

Recycle IT

Unit 14/2 Craig Terrace, Clondalkin Industrial Estate, Clondalkin, Dublin D22 TK37

Website: <https://www.recycleit.ie/location-map.html>

Tel: +353 14578221

E: info@recycleit.ie

Opening Hours: Monday-Thursday 8.30am-4.30pm — Friday 8.30am-3.30pm