

Remote Controller Instructions



Button	Function
1H One hour timing function	One hour timing function. The light flashes once as a reminder to indicate successful timing. Note: Except for the power function key, press other keys to not cancel the timing function, and then press the timing key to start timing again
() ON/OFF	ON/OFF (controlling 3 lights), memory function required
■ Color temperature-	Color temperature reduction, short press, four step adjustment: 6500K/5000K/4000K/2700K
≦ ► Color temperature+	Color temperature reduction, short press, four step adjustment: 6500K/5000K/4000K/2700K
BRT- Brightness-	Brightness increase, short press and adjust in 10 levels: 10%/20%/30%/40%/50%/60%/70%/80%/90%/100%
♣ _{BRT+} Brightness+	Brightness reduction, short press and adjust in 10 steps: 100%/90%/80%/70%/60%/50%/40%/30%/ 20%/10%
M One click recovery	One key restores the brightness to 4000K 50%, and the lights can be operated at the same time
1 Control the first lamp	Short press: to control the switch of the first lamp. After turning off the lamp, it needs memory function. Long press: the lamp flashes once, indicating that the brightness and color temperature

of the lamp can be adjusted



FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna.
- · Increase the separation between the equipment and receiver.
- · Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- · Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.