












front side  
正面

back side  
反面

<h1>HAVIT</h1>  <p>SPACE S1 ADAPTIVE HYBRID ACTIVE NOISE CANCELLING BLUETOOTH HEADPHONE</p> <p><b>USER MANUAL</b></p>	<p><b>Package Content</b></p>  <p>Headphone*1 3.5mm 4-pole Audio Cable*1 Type-C Charging Cable*1</p>  <p>Carry Box*1 User Manual *1 Warranty Card *1</p>	<p><b>Product Overview</b></p>  <ol style="list-style-type: none"> <li>Control knob</li> <li>Power button</li> <li>ANC switch</li> <li>Power indicator</li> <li>Aux in audio port</li> <li>Charging port</li> <li>Charging Indicator</li> <li>Talk MIC</li> <li>FF MIC</li> </ol>	<p><b>Power On/Connection</b></p>  <p>On: press and hold for 3S Off: press and hold for 5S</p> <p>Turn on Bluetooth on your device. Select HAVIT SPACE S1 and connect it.</p> <p>Note: The headphone will be automatically connected to the last paired device as soon as you turn it on.</p>	<p><b>Dual Devices Connection</b></p>  <p>STEP 1: Connect to Mobile 1 and then disconnect it.</p> <p>STEP 2: Connect to Mobile 2 or a notebook.</p> <p>STEP 3: Connect to Mobile 1 again.</p> <p>Note: Now HAVIT SPACE S1 is connected to 2 mobiles (mobile 1 &amp; mobile 2) or connected to 1 mobile &amp; 1 notebook.</p>	<p><b>Function</b></p> 	<table border="1"> <tr> <td>Play/Pause</td> <td></td> <td>Press once</td> </tr> <tr> <td>Previous song</td> <td></td> <td>Turn up</td> </tr> <tr> <td>Next song</td> <td></td> <td>Turn down</td> </tr> <tr> <td>Volume up</td> <td></td> <td>Turn up and hold</td> </tr> <tr> <td>Volume down</td> <td></td> <td>Turn down and hold</td> </tr> <tr> <td>Answer/End the call</td> <td></td> <td>Press once</td> </tr> <tr> <td>Reject the call</td> <td></td> <td>Press and hold for 1S</td> </tr> <tr> <td>Voice assistant</td> <td></td> <td>Press twice</td> </tr> <tr> <td>Switch ANC mode</td> <td></td> <td>Press once</td> </tr> <tr> <td>Adaptive ANC</td> <td></td> <td>Press twice when in ANC mode</td> </tr> <tr> <td>Game mode</td> <td></td> <td>Press thrice</td> </tr> <tr> <td>Spatial audio mode</td> <td></td> <td>Press and hold for 2S</td> </tr> </table>	Play/Pause		Press once	Previous song		Turn up	Next song		Turn down	Volume up		Turn up and hold	Volume down		Turn down and hold	Answer/End the call		Press once	Reject the call		Press and hold for 1S	Voice assistant		Press twice	Switch ANC mode		Press once	Adaptive ANC		Press twice when in ANC mode	Game mode		Press thrice	Spatial audio mode		Press and hold for 2S
Play/Pause		Press once																																								
Previous song		Turn up																																								
Next song		Turn down																																								
Volume up		Turn up and hold																																								
Volume down		Turn down and hold																																								
Answer/End the call		Press once																																								
Reject the call		Press and hold for 1S																																								
Voice assistant		Press twice																																								
Switch ANC mode		Press once																																								
Adaptive ANC		Press twice when in ANC mode																																								
Game mode		Press thrice																																								
Spatial audio mode		Press and hold for 2S																																								
<p><b>Line-in Mode</b></p> <p>Connect the headset to a music player/mobile via 3.5mm 4-pole audio cable (provided as accessory):</p> <ol style="list-style-type: none"> <li>When the headphone is power on, you can use ANC switch/mic function/adjust the volume. (In this mode, the total running time is 42 hours when full charged).</li> <li>When the headphone is power off, you can only listen to the music from the music player/mobile.</li> </ol> 	<p><b>Charging</b></p> <p>Charge the headphone with type C charging cable, preferably from any PC or laptop as compared to a USB charger.</p>  <p><b>Indicator on headphone</b></p> <p> Charging: solid red indicator is on.</p> <p> Full charged: solid white indicator is on.</p>	<p><b>Reset</b></p>  <p>Power off the headphone first. Then press and hold Power button for 8 seconds until the red indicator flashes 3 times. The reset is done. You can do connection again.</p>	<p><b>Safety Tips</b></p> <ol style="list-style-type: none"> <li>Don't expose the product to liquids, moisture or humidity as it has electronics and battery inside.</li> <li>Don't disassemble your product. There are no userserviceable parts inside it.</li> <li>Don't drop the product and keep it away from sharp objects.</li> <li>Charge your product below 5V/1A charger.</li> <li>Don't expose the product to extremely high or low temperature as this may damage the battery or even deform the plastic parts.</li> <li>Listen to the music at high volume is harmful to your ears.</li> <li>Don't throw the product in a fire to dispose it otherwise inside battery may explode.</li> </ol>	<p><b>FCC STATEMENT</b></p> <ol style="list-style-type: none"> <li>This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:             <ol style="list-style-type: none"> <li>This device may not cause harmful interference, and</li> <li>This device must accept any interference received, including interference that may cause undesired operation.</li> </ol> </li> <li>Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</li> </ol> <p>Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that</p>	<p>interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</p> <ol style="list-style-type: none"> <li>Reorient or relocate the receiving antenna.</li> <li>Increase the separation between the equipment and receiver.</li> <li>Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.</li> <li>Consult the dealer or an experienced radio/TV technician for help.</li> </ol> <p><b>RF WARNING STATEMENT</b></p> <p>The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure condition without restriction.</p>	<p><b>BATTERIES:</b></p> <p>A warning that batteries (battery pack or batteries installed) shall not be exposed to excessive heat such as sunshine, fire or the light.</p> <ol style="list-style-type: none"> <li>Replacement of a battery with an incorrect type that can defeat a safeguard.</li> <li>Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion or the leakage of flammable liquid or gas.</li> <li>Leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas.</li> <li>A battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.</li> </ol>  <p>www.havitsmart.com</p> <p>FCC CE </p> <p> <b>RoHS</b></p>																																				

材质: 128g FSC环保双铜纸, 双面印刷, 风琴折  
印刷色号(Printing color number): C:0 M:0 Y:0 K:70  
尺寸(Size): 55 X 77 mm

注意: 单页码数封底由二维码填充

