

# HAVIT

front side  
正面



SK770BT  
GAMING DESKTOP SPEAKER  
USER MANUAL

## Package Content



Speaker\*1



Type C Charging Cable\*1




User Manual \*1



Warranty Card \*1


## Product structure:

1. Power button
2. Volume down/ Previous song
3. Volume up/ Next song
4. Light button
5. Indicator light
6. Type-C charging port



1

## Power On/Connection




### Power button

On: Press and hold the power button for 3s  
Blue indicator is breathing  
Off: Press and hold the power button for 3s



Select HAVIT SK770BT and connect it.



Light button  
Press twice to disconnect.

**Note**  
The speaker will be automatically connected to the last paired device as soon as you turn it on.

4

## Function



Power on/off		Press and hold for 3s
Mode Switch		Press twice
Play/Pause		Press once
Reset (The speaker had crashed.)		Press and hold for 8s
Clear Bluetooth pairing		Press and hold for 3s at same time
Volume down		Press once
Previous song		Press and hold for 2s
Volume up		Press once
Next song		Press and hold for 2s
RGB light switch		Press once
Bluetooth disconnect		Press twice

### Mode Switch

Insert Type-C (provide as accessory) to the speaker then you can press twice power button to switch different mode by turn.

### Sound card mode

After press and hold the power button for 3 seconds to power on, connect the computer with a Type-c data cable, automatically switch the sound card mode, and you can operate the computer sound source device to play music.

### Charging

Charge the speaker with type C charging cable, preferably from any PC or laptop as compared to a USB charger.



### Indicator on speaker

Charging: red indicator is on.  
 Full charged: red indicator is off.

5

## Reset

In the crashed state of the speaker, press power button and hold for 8s until the speaker is reset. Reset is done.  
You can connect to the device again.



## Safety Tips

1. Please follow the instruction to operate the product.
2. Please charge the product with input power below DC 5V/1A to protect the battery
3. Do not immerse this product in any liquid or splash any liquid on this product
4. Please store or use the product in a normal temperature environment.
5. Please keep the product from heat source, such as radiators, hot air regulators, stoves, or other heat generating instruments as it is not anti-high temperature.

6

6. Do not jam the ports of the product, such as charger port, LED port and TF card port
7. In order to protect your hearing and extend the product lifetime, it is not recommended to adjust the volume to the maximum level for a long time.

## Batteries:

A warning that batteries (battery pack or batteries installed) shall not be exposed to excessive heat such as sunshine, fire or the light.  
1. Replacement of a battery with an incorrect type that can defeat a safeguard.  
2. Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion.  
3. Leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas.  
4. A battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.



7

## FCC ID: 2A161-SK770BT

**FCC Requirement**  
Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

**Note**  
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

9

材质: 128g双铜纸 双面印刷, 风琴折

印刷色号(Printing color number): C:0 M:0 Y:0 K:70

尺寸(Size): 55 X 77 mm

back side  
反面