

Mini PC

V6W

User manual

Declaration

The user manual includes all the information of safe and correct operation instruction. To avoid accident and product damaged, please make sure go through all the content carefully before using the product.

Please keep the product away from high temperature, humid and dusty environment.

Do not drop and crash the product.

Do not cut off the device when it is formatting ,or upgrading, otherwise it will cause operation system error.

Do not dismantle the device.Do not clean it by alcohol, thinner and Benzene.

We keep the right to upgrade and modify the product.

Disclaimer: we only take the responsibility to provide the warranty and after service. The user have to take care of their date in the device by themselves.We do not responsible for any date or related lost.

The product is not water-proof.


All the pictures in the instruction are just for reference.

Catalog


About V6W	3
The front.....	3
The Back.....	3
The Side.....	4
Basic operation.....	5
2.1 First time to Start.....	5
2.2 Windows 10 operating Interface.....	5
2.3 Icons.....	6
2.4 How to enter into sleeping mode or power off.....	7
2.5 Wi-Fi Connection.....	8
2.6 Get Start & Setting.....	8
2.7 Audio output.....	9

About V6W


The Front



The Back



The Side



① power	Power on /off
② Camera	Camera video
③ MIC	Speech input
④ Clock	Time Display
⑤ USB3.0 interface	Connect to USB device ,Enjoy Faster speed.
⑥ USB3.0 interface	Connect to USB device ,Enjoy Faster speed.
⑦ LAN Jack	Connect to the ethernet cable
⑧ HDMI Interface	Connect to HDMI input devices, TV or display monitor
⑨ DC-In Jack	Connect to power adapter
⑩ Micro SD slot	Insert and Read the Micro SD card
⑪ Audio Out	Support Audio output to earphone,speaker

Basic Operation

2.1 First time to use

Please Read the quick start guide before turn on the V6.

A, Connect the power adapter to V6 and insert the power to wall socket.

B, Press the button,it will start to enter into the operation system.

C, Power off V6 : Click the bottom left windows icon  → power → power off

2.2 Windows 10 Operating Interface

Windows 10 only has one user interface: Classic wallpaper.


If you want to switch from start to desktop , please choose the following methods:

- Click the start menu under the home screen.
- Press Windows keys on keyboard.


If you want to switch from desktop to start ,please choose the following methods:

- Click  on the left bottom
- Move the cursor to the left bottom, will display shortcut and click it.

2.2.1 Desktop




2.2.2 Start Menu



2.3 Icons

🔍 Search icons

Move the cursor to the left search icons, you are search for any applications, settings and documents.



2.4 How to Turn into sleeping mode or power off

2.4.1 Sleeping Mode

If you don't use the V6 ,you can just let it enter into sleeping mode,please do as the following steps.

- . Press 1 time the button to sleep mode ;

or

- . Click  , then choose  →choose the sleeping mode.

Notice:

Before the power status indicator start to flash(means the V6 enter into sleeping mode),pls it is better to save the data to avoid the data lost.

If you want to active the V6 again,just press the power button to run the system.

2.4.2 Power Off

If you will not use the V6 for a long time, please power off it.

- . Press and hold the power button.

or

- . Click  ,Then click  →power off.

Notice : You can setup the power button by sleep mode or power off mode,it is defaulted to power off mode now.

2.5 Wi-Fi Connection


2.5.1 Start the Wi-Fi setting

If want to enable the Wireless function,please do as the following steps:

- Please check the right bottom wireless icon. 
- Please switch off airplane off mode.

2.5.2 Connect the Wi-Fi

After start wireless function,the V6 will scan and display the Wi-Fi list available. You can click the Wi-Fi account you want to connect and input the right passwords.



2.6 Get start & Setting


If you get more setting for windows 10, please check the get start & setting ,please do as the following methods

- Click , then to choose the setting.
- Press Windows+F1


2.7 Audio output



2.7.1 Please press the sound icon on the bottom right of desk menu and come to the Sound setup as following pictures:



2.7.2 Under the sound menu, you can set the sound playback as follow:



Noted: The system defaulted sound output is usb audio device/Speakers. While it connected to TV/Projector by HDMI and needed to change to TV/Projector sound, please set to them as default device and then click OK.