

For Vehicle Use 3 "AA" Size Batteries (not included)


BATTERY PRECAUTION

1. Only the same battery or equivalent type as recommended can be used.
2. Be sure to insert batteries with correct polarities
3. Do not mix old and new batteries.
4. Batteries should be taken out after a long-term disuse and exhausted battery is to be removed from the toy.
5. The power supply terminals are not to be short-circuited.
6. Vehicle requires 3 pieces of 1.5 volt "AA" batteries; controller requires 2 pieces of 1.5 volt "AA" batteries.
7. After playing, make sure the switch turn to OFF.
8. Only rechargeable battery can be charged under adult's supervision.
9. Alkaline batteries are recommended to be used
10. Do not mix alkaline, standard or rechargeable batteries




PRECAUCIÓN:
CONTIENE PIEZAS PEQUEÑAS QUE PUEDEN
CAUSAR ASFIXIA SI SON TRAGADAS.

محتويات ادواري كودك عن زير 3 ميل
محتويات توسيع ، ذهابي طفلاً كودك ، سنت
لتحذير: غير ملائم لاطفال تحت ثلاثة (3) سنوات بسبب
القطع المضمنة ، الصين



Keep the packaging and instruction manual for future reference since they contain important information.

MADE IN CHINA



HOW TO PLAY

Firstly turn the switch of the vehicle to "ON". Secondly operate the "left" / "right" button on the controller. Left button is forward; right button is backward and turning.

- GB PLEASE RETAIN FOR INFORMATION
- F PRIERE DE CONSERVER A TITRE D'INFORMATION
- N BEWAREN TER INFORMATIE AUB
- D DIESE ANGABE BITTE AUFBEWAHREN
- I CONSERVARE PER FUTURE REFERENZ
- E CONSERVE LA DIRECCION PARA FUTURAS EONSULTAS
- P POR FAVOR GUARDE PARA SUA INFORMACAO
- S SPARA DENNA INFORMATION
- D GEM EMBALLAGEN I TILF AELDE AF EVT SENRE HENVENDELSE
- N EMBALLASJEN BOR OPPBEVARES FOR EVENTUEL SENERE HEVENDELSE
- S SÄILYTA TIEDOT MYÖHEMPÄÄ TARVETTA VARTEN
- GB Because of small parts, not suitable for children under the age of 3 years.
- F Risque d'absorption de petites pièces. Ne convient à pas un enfant de moins de 36 mois.
- NL Niet geschikt voor kinderen jonger dan 36 maanden, bevat kleine onderdelen die kunnen ingeslikt worden.
- D Enthält kleine Teile. Nicht für Kinder unter 3 Jahren geeignet.
- I A causa della presenza di piccole parti, questo giocattolo non è adatto a bambini di età inferiore ai tre anni.



NO:IE22



NO:IE23



NO:IE24



NO:IE25



NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC ID : 2AI9385178666