



For more information please visit:
<http://wearnotch.com/info>



FOLDING LINE DO NOT PRINT

STEADY YOUR AVATAR

Perform the "Steady" pose routine at the beginning of each recording session. Tap "Steady" and stand straight up with your arms by your side. Keep your knees and elbows locked during the Steady routine. Stand as still as possible until the app notifies you that the Steady routine has completed. Tap "Re-Steady" if any of the notches moved between recordings (after re-tightening any loose straps).

RECORD YOUR MOTION

Tap "Capture" and begin the motion you want to record. For best results start recording from a still pose, not when you are already in motion. Continue moving until you are done, then stand still and tap "Stop." Review the motion capture recording after it has downloaded to your device.

FOLDING LINE DO NOT PRINT

Model Number: NSBL1, NSBL2

2017 © Notch Interfaces Inc. | <http://wearnotch.com>
630 Flushing Ave., Brooklyn, NY 11206 USA | +1 (917) 675 4445

FCC ID for NSBL1: 2AI9F-NSBL1
FCC ID for NSBL2: 2AI9F-NSBL2

FCC Statement:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

Note:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help



Correct Disposal of this product. This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health

FOLDING LINE DO NOT PRINT

from uncontrolled waste disposal, recycle if possible to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.



Quick Start

FOLDING LINE DO NOT PRINT

10