







<div>Mag-SoundMate</div> <div>Mini MagSafe Bluetooth Speaker</div> <div></div> <div>HD-M12</div> <div>User Manual</div> <div>- 01 -</div>	<div>Thank You for Choosing MiLi!</div> <p>It's a great pleasure to share with you the conveniences and benefits brought by MiLi smart lifestyle gadgets. With the prevalence of mobile devices in everyday life, MiLi will adopt the latest charging technology to power your life. Don't forget to register your product on www.mymili.com to activate your warranty!</p> <p>Please read the instructions and warnings carefully before using the product. Misuse harms the product and hurts people. The manual contains the correct usage and necessary safe use information. Please read carefully. The product and accessory pictures are just for reference. Please refer to the actual ones.</p> <div>Important Safety Information</div> <div>- 02 -</div>	<ul style="list-style-type: none">●Please comply with following basic safety instructions to guarantee safe and reliable use of the product.●Comply with all warnings and guide information marked on the product.●Please use charging equipment that can supply 5V of output voltage to avoid damage to the equipment.●The product adopts built-in polymer lithium battery, please shut down when not in use. <div>Caution</div> <p>Removal of the built-in battery invalidates the warranty and may destroy the product.</p> <div>Note</div> <p>Rechargeable batteries have a limited number of charge cycles. Battery life and number of charge cycles vary by</p> <div>- 03 -</div>	<p>use and settings.</p> <div>Warning</div> <ul style="list-style-type: none">●Never operate when the product is wet, or drop or spill any liquid on the product.●Never place the product close to high temperature heat source, or dry or blow the product at high temperature.●Never apply great pressure on the product. <div>Product Specification</div> <p>Product Model : HD-M12 Bluetooth version : 5.0+EDR Input : 5V=1A Loudspeaker : 3W Wireless Bluetooth Range : 10m Time of use : 6~8hours Charging time : 1.5hours Case material : ABS+PC Capacity : 420mAh Weight : 80g</p> <div>- 04 -</div>	<div>What's in the box</div> <div></div> <div>Mag-SoundMate*1 Steel ring*2</div> <div>USB-C Cable*1 User manual*1</div> <div>Product Configuration</div> <div></div> <div>Dust-proof mesh cloth cover Loudspeaker</div> <div>Silicone plug PCB</div> <div>Lithium polymer battery OFF/NO</div> <div>Bottom magnet Non-slip silicone pad</div> <div>- 05 -</div>	<div>How to Use This Product</div> <div></div> <div>Type-C Power button/indicator</div> <div>Charge the built-in battery</div> <p>The speaker is powered by a built-in rechargeable battery.</p> <div>Note:</div> <ul style="list-style-type: none">●Before use, Please fully charge the built-in battery.●while power on, if Bluetooth is interrupted or disconnected for 5 minutes, the device will power off automatically. <div>- 06 -</div>	<p>1. Keep pressing the power button for 3s to turn on and off the device, followed by a voice alert, and the same operation for the Bluetooth connection and disconnection.</p> <p>2. While music playing, press the power button once to pause/play;</p> <p>3. After the Bluetooth connection succeeds, the device's power status will display on your phone's screen.</p> <div>How to get into TWS mode for 2 Speakers?</div> <p>1. Power on one Speaker and get it connected with your phone via Bluetooth.</p> <div>- 07 -</div>	<p>2. Power on the other one, then double-click it to get into (or out off) TWS mode.</p> <div>Note:</div> <p>in TWS mode, your phone only need to connect one Speaker via Bluetooth.</p> <div>Tips:</div> <p>If you power on two Speakers simultaneously before Bluetooth connected properly, please power off one Speaker first and follow the operation instruction above to get into TWS mode</p> <div>Note:</div> <p>When the device's power is drained below 10%, the indicator will spark blue and will shut down automatically later on, followed by a "power off" voice alert.</p> <div>- 08 -</div>
<div>Use Bluetooth Devices</div> <p>With the speaker, you can listen to audio from a player and make a call through Bluetooth.</p> <div>Note:</div> <ul style="list-style-type: none">●The operational range between this product and a Bluetooth device is approximately 10 meters (30 feet).●Any obstacle between this product and a Bluetooth device can reduce the operational range.●Keep away from any other electronic device that may cause interference. <div>Connect a device</div> <ul style="list-style-type: none">●On your device, search for Bluetooth devices. In the device list, select MiLi SoundMate. The speaker prompt with a voice.●Connecting is ok when connection is established. <div>Disconnect a device</div> <div>- 09 -</div>	<ul style="list-style-type: none">●On your device, disable the Bluetooth connection with this speaker.●The speaker prompt with a voice Bluetooth Exit when is disconnected. <div>Note:</div> <p>Before connecting another Bluetooth device, disconnect the current device first.</p> <div>Reconnect a device</div> <p>For a paired Bluetooth device on which the automatic reconnection is enabled, this product reconnects with it once it is detected. For a paired Bluetooth device that does not support the automatic reconnection, reconnect it with this product manually.</p> <div>Play audio via Bluetooth</div> <p>Note: If there is an incoming call on the connected mobile phone, music play pauses.</p> <div>- 10 -</div>	<div>Trouble Shooting</div> <div>Note:</div> <p>To keep the warranty valid, never try to repair the product yourself.</p> <p>If you encounter problems when using this device, check following points before requesting service.</p> <p>If this not help, you can choose to replace or repair after the failure (not caused by human) is inspected and confirmed.</p> <div>No power</div> <ul style="list-style-type: none">●Recharge your speaker. <div>No sound</div> <ul style="list-style-type: none">●Adjust volume on this product.●Adjust volume on the connected device.●Make sure that your Bluetooth device is within the effective operational range. <div>- 11 -</div>	<div>No response from the speaker</div> <ul style="list-style-type: none">●Restart the speaker.●Apply a needle into the microphone to reset the speaker <div>About Bluetooth device</div> <p>The audio quality is poor after connection</p> <p>Move the device closer to this product or remove any obstacle between them.</p> <div>Cannot connect with the device</div> <p>This product has connected with another Bluetooth device.</p> <p>Disconnect that device and then try again.</p> <div>- 12 -</div>	<div></div> <div>Magnetic adsorption Used as a stand</div> <div></div> <div>Note:</div> <p>The non-magnetic phone or non-metallic objects can be attached to the Speaker with a steel ring packed in the box.</p> <div>- 13 -</div>	<div>MiLi Manufacturer's Product Warranty</div> <div>MiLi 1 Year Limited Warranty</div> <p>Hali-Power's warranty obligations for MiLi products are limited to the terms set forth below: Shenzhen Hali-Power Industrial Co., Ltd. ("MiLi") warrants MiLi products against defects in materials and workmanship for a period of 1 year from the date of original purchase ("Warranty Period"). All products must be registered online within 90 days from the purchase date to qualify 1 year warranty. If a defect arises and a valid claim are received by MiLi within the Warranty Period, at an option, MiLi will</p> <p>(1) Repair the product freely, using new or refurbished replacement parts.</p> <div>- 14 -</div>	<p>(2) Exchange the product with another new product.</p> <p>(3) The freight arose from goods return will be shared by MiLi and Customer together.</p> <p>(customer will have to bear the freight to factory, while, MiLi will bear the freight to customer). For any maintenance and repairs out of service range, customer will have to bear the freight and any relevant charges.</p> <div>Exclusions and Limitations</div> <p>It's a great pleasure to share with you the conveniences and benefits brought by MiLi wireless charging technology. With the prevalence of mobile devices in everyday life, MiLi will adopt the latest charging</p> <div>- 15 -</div>	<p>technology to power your life. Don't forget to register your product on www.mymili.com to activate your warranty! Please read the instructions and warnings carefully before using the product. Misuse harms the product and hurts people. The manual contains the correct usage and necessary safe use information. Please read carefully. The product and accessory pictures are just for reference. Please refer to the actual ones.</p> <div>Contact us!</div> <p>If you have any questions or problems with your product, please don't hesitate to reach us at: Customer Support: cs@hali-pow-er.com Website: www.mymili.com</p> <div>- 16 -</div>

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.

(2) This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.