



Instruction Manual

IMPORTANT SAFETY INFORMATION

1. Read all instructions before using this product.
2. Do not leave this product unattended while connected to the power supply.
3. Do not immerse in water or any other liquids.
4. Do not use if unit has been dropped or damaged in any way.
5. Improper repairs may place user at serious risk.
6. Repairs to electrical equipment should only be performed by qualified personnel.
7. Place unit on sound, even surface, free of vibrations and away from sources of heat.
8. Do not put objects into openings.
9. Do not use this unit for anything other than its intended use.
10. Keep this product out of reach of children.
11. This product is not a toy.
12. Do not play music at excessive levels especially near children, as damage to hearing may occur.

CAUTION:
Risk of Fire and Burns. Do Not Open, Crush, Heat Above (manufacturer’s specified maximum temperature) or Incinerate. Follow Manufacturer’s Instructions.

GETTING STARTED:
Remove the unit from the box. Remove any packaging from the product. Please retain all packaging until you have checked and counted all the parts and the contents against the parts list.

INCLUDES:

- 1 (One) Speaker
- 1 (One) USB Charging Cable
- 1 (One) Instruction Manual
- 1 (One) Warranty Card

FEATURES:

- Wireless connectivity
- Support BLUETOOTH®/FM Radio/TWS
- Rechargeable Lithium battery
- RGB LIGHT

PANEL FUNCTION DECLARATION

Button	Operation and function
	Long press to Power on/off Short press: Play/Pause; In FM mode, Short press to search channel automatically Double press to switch modes(BLUETOOTH®/FM) Triple press to open/off the TWS
	In BLUETOOTH®/FM mode: Short Press: next music/channel; Long Press: volume up Double Press: turn on/off the light
	In BLUETOOTH®/FM mode: Short Press: Previous music/channel; Long Press: volume down
	Charging port

Battery Warning

When charging the unit, please turn off the power button, so as not to damage the battery. Do not constantly use the machine for a long time. In order to keep the battery in good condition, please charge and discharge the battery every 30 days or so.

Specifications

Bluetooth version: 5.3
Speaker size: 2 inch
Distance: 32.8ft
Battery: 500mAh

Charging time: 1-2 hrs
Playing time: 1 hr

Connect to BLUETOOTH®

Turn on the speaker unit and the Mobile or other devices, and search for paring name "BT210 " to pair the two devices. Once paired before, it will automatically connect after the unit is turned on.

FM Radio Function

Short press : to search channel automatically
Double press : to switch modes (BLUETOOTH®/FM)

Short Press : next music/channel
Short Press : Previous music/channel

TWS Function

Two of the same model speakers can be connected to one wireless device at the same time. Firstly, turn the speakers on, triple press "" button on any speaker for several seconds; then you will hear the sound of "BEEP" to indicate that the two units have been paired successfully. Please ensure before pairing that the two units are not connected with other devices.

FCC ID:2AIDL-BT210A

FCC STATEMENT
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.
Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user’s authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.
This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.
If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. In order to avoid the possibility of exceeding the FCC radio frequency exposure limits, this device has been evaluated to meet the general RF exposure requirement.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks is under license. Other trademarks and trade names are those of their respective owners.