




E 200

User Manual



EJEAS®





Volum button	Electricity prompt、Answer/Reject incoming calls、 Hang up call、 Last Code Redial
	Music play / pause、 Last Music、 Music stop
	Set up intercom、 Exit Talkback
Power button	Call volume adjustment、 Voice dialing
	Music volume adjustment、 Next music
	Talkback volume adjustment

Operation method:

- 1、 Power On:** Long Press power button 3 secods,device light shine then headset have invoice tip of "power on".
- 2、 Power off :** Shortly press power button+volume 0.3s, power off quickly.
- 3、 paring with mobile :** Power off situation , long press "power button" 6 seconds until red & blue light shining, voice tip and open mobile bluetooth, search E200 , press connection with mobile ,then pairing successfully .First pairing successfully ,



next time ,don't need connect again , using it and auto-connecting mobile, or unconnected and standby, shortly "volume button" ,E200 automatic connect paired mobile.

4.Connect mobile again :power on and automatic connect , if Connected successfully has voice tip ,if unconnect,press volume button shortly .(In the case of the phone has been paired with the second use)

5.Electricity prompt: in the shutdown state, press the power button to start power prompt.

6.Phone control:

Answer incoming calls: incoming calls automatically (8s later) or call short press start key.

Reject call: call status, double-click the power button.

Hang up call: call state, short press the power button.

Call volume adjustment: long press the volume key to adjust the volume.

Last Code Redial: Double-click the power button.

Voice dialing: connection standby, double-click the volume key.

7.Music control:

Music play / pause: long press the power button 1s.

Music volume adjustment: long press the volume key to adjust to the maximum sound, tone tip within 3 seconds to maintain the maximum sound , and then go to the minimum.

Music Up and down: Double-click the power button/double-click the volume button.

Music stop: long press the power button 1s.

8.pairing &talking:

2pcs E200 connect and talk ,must be paired then talk , 2pcs E200 pair and talk , power on ,long press volume button 2 seconds , red&blue shine ,then shortly press one of E200 "VOLUME BUTTON". E200 automatic search and pair ,only blue light shine of 2 pcs E200 when paired successfully ,voice tip of pairing successfully .

Same 2pcs E200 paired successfully would never be paired again ,just need shortly power button .

9.Talkback control:

Set up intercom: short press the power button

Talkback volume adjustment: long press the volume button to cycle adjust To adjust to the maximum sound , the tone within 3 seconds to maintain the maximum sound, and then go to the minimum , if the maximum ,then release after the sound, then press the volume key to the minimum volume .

Exit Talkback: Short press the power button.

AUX Voice input

Connet with normal walkie talkie through
PPT line (Optional)



TOP
Installation



TOP
Installation



1

Remove the white protect film on the velcro.



2

Put the velcro to the both side of helmet.



3

Gule the both speaker on the velcro,adjust the position.



4

Wear up and check it comfortable.

5

TOP
Accessories



Accessories: E 200+ USB line+ Users manual+ Velcro*2

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

