**WELCOME TO USE**

---

## Key instruction



① Insert the battery
② Insert the T card: Fix T card after taking out the battery
③ USB

**Warm Tips:** Pls ready the followed parts for the first using of our watch:1 Mini SIM card,
1 screw-driver(included in retail package),wireless network ,1 android smartphone

---

## Key instruction



① On/Off
② Home
③ Camera
④ Screen
⑤ Microphone
⑥ Speaker

**Remark:** Keep Pressing"On/Off" button to start the watch
Keep Pressing"On/Off"button to power Off the watch

① Charging dock

① Insert the SIM card

**Warm Tips:** Pls ready the followed parts for the first using of our watch:1 Mini SIM card,
1 screw-driver(included in retail package),wireless network ,1 android smartphone

---

## Hand Gestures



① Menu operation : Slide the screen from left to right
② Returns operation : Slide the screen from right to left
③ The sliding operation:Sliding left or right to switch pages on the screen with your fingers

---

## Screen Unlock/Lock



In the screen lock state, slide towards any direction with the fingers touching the
watch screen that can unlock the screen.And just tap the "power on/off" button tha
can lock the screen.

---

## The Dial Settings



Open the dial setting application, browse
the dial, choose your prefered dial display.
And you can set the dial after tapping your
prefered dial display.After the setting,it will
popup a message to say with success.Then
you can choose to continue browsing or exiting.

### Remark:

Date and time settings: Open "Settings" ->
"System" -> "Date and Time", click "Determine
the date and time automatically", choose to
use the network time, or GPS time, or closed
with manually setting.

---

## Contact list



When first use, please select the way of
import contacts. We support various ways
to add contacts. You can import a phone
card and SD card contacts, or set the
synchronization account, can also direct
new contacts. You can manage the contact
lists in detail by pressing the menu button
at the bottom.

---

## Dial the Number



You can use the virtual keyboard to dial the number directly, also dial by searched
contact list numbers. It support the search contact name by first letter of the name,
part letters of the name,full spelling of the name and also by phone number;The
search results will seqence by matching level.

---

## Sent SMS



When write SMS, you can add to one or more
recipients. Message content support sending
files or insert images, expression, contact
information,audio and video. Long press the
message content, you can choose to lock,
forwarding, copy the text messages, view,
delete information etc.

---

## Write mail



After setting up your e-mail account, you can use the watch to send mail., You
will receive the first time reminder when a new mail in.

---

## Take photos or video



Open the camera program to take photos,which support continuous capture mode
and time-lapse mode. To take video, you only need to slide virtual key to the camera icon.

---

## Gallery



The gallery program support reviewing picture
according to the folder path, you can click the
picture to zoom the selected single picture, you
can also click on the left or right to switch up or
next a picture; And when you click the picture
you can find the showing or hidden menu control
function.

---

## Music



Music program support playing the local
music. If you need to play online music
you can download network music player,
such KuGou,DuomiMusic etc. It can play
music by the song name, artist, album,
playlist of different modes,and also with
variety of sound effects for your choosing.

---

## News and Weather



Open the application,you can acquire newest news information and weather conditions

---

## GPS Navigation



Open the navigation software (Google map or Baidu map), click to choose navigation
way, you can choose: tell the destination "or" input destination ". It will run navigation
operation after positioning.

---

## Change Wallpaper



1. Long press on the blank of the main screen (desktop),there will pop up "the choice of
   wallpaper sources", you can replace your prefered wallpaper here.
2. To replace the wallpaper you can open "setting" -> "equipment "- >" display "- >
   " wallpaper ", and then change the wallpaper.
3. You can also slide in the main screen from the left to right,then find the "wallpaper" ,
   click and change the wallpaper.
4. You can also find directly in the gallery on your perfered piture,and then set it as the
   wallpaper for watch.

---

## Internet



The browser supports double-click or two fingers to zoom webpage
toggle. Intelligent full screen with browsing area in best fitting.

---

## Message Checking



When you have new notification on call or SMS etc , you can slide down to view
the details. There is quick switch button on the top notification bar, and you can
slide to choose more switches.

---

FCC Statement
This equipment has been tested and found to comply with the limits for
a Class B digital device, pursuant to Part 15 of the FCC Rules. These
limits are designed to provide reasonable protection against harmful
interference in a residential installation. This equipment generates
uses and can radiate radio frequency energy and, if not installed and
used in accordance with the instructions, may cause harmful
interference to radio communications. However, there is no guarantee
that interference will not occur in a particular installation. If this
equipment does cause harmful interference to radio or television
reception, which can be determined by turning the equipment off and
on, the user is encouraged to try to correct the interference by one or
more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that
to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is
subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device
must accept any interference received, including interference that may
cause undesired operation.

Changes or modifications not expressly approved by the party
responsible for compliance could void the user's authority to operate
the equipment.

SAR:
The radiated output power of this device is below the FCC radio
frequency exposure limits. Nevertheless, the device should be used
in such a manner that the potential for human contact is minimized
during normal operation.
The exposure standard for wireless devices employs a unit of
measurement known as the Specific Absorption Rate, or SAR. The
SAR limit set by the FCC is 1.6 W/Kg. Tests for SAR are conducted
using standard operating positions accepted by the FCC with the
device transmitting at its highest certified power level in all tested
frequency bands. Although the SAR is determined at the highest
certified power level, the actual SAR level of the device while
operating can be well below themaximum value. This is because the
device is designed to operate at multiple power levels so as to use
only the power required to reach the network. In general, the closer
you are to a wireless base station antenna, the lower the power
output. To avoid the possibility of exceeding the FCC radio frequency
exposure limits, human proximity to the antenna should be
minimized.
To comply with RF exposure requirements, a minimum separation
distance of 10 mm must be maintained between the user's mouth and
this watch during voice communications.
Thia device is restrictd to worn on the wrist operations.