




1201799
User's Guide



RadioShack Bluetooth® Music Receiver



Package Contents

- RadioShack Bluetooth® Music Receiver
- AC Adapter
- 6ft (1.82m) 1/8" (3.5mm) Audio Cable
- 6ft (1.82m) RCA Cable
- User's Guide

We hope you enjoy your RadioShack Bluetooth® Music Receiver. This receiver enables wireless streaming of music from your Bluetooth enabled device to your home audio system. Please read this user's guide before using your receiver.

Setup

1. For analog output:

Connect the 1/8" (3.5mm) plug on the RCA cable (included) into the **AUX OUT** jack on the receiver, then plug the RCA plugs into the **AUX IN** jacks on your amplifier.


OR

Connect one end of the 1/8" (3.5mm) audio cable (included) into the **AUX OUT** jack on the receiver and plug the other end into the line-in jack on your amplifier.

For digital output:

Connect a TOSLINK cable (not included) into the **OPTICAL OUT** jack on the receiver, then connect the other end into the **OPTICAL IN** jack on your amplifier.

2. Connect the adapter into the **DC IN** jack on the receiver then plug the adapter into a wall outlet.



2

Pairing



LED Indicator

Flashes Blue - Standby
Flashes blue and red alternatively - pairing mode
Lights blue steadily - paired

Connect Button

Press and hold to turn on/off
Press twice when receiver is on to enter pairing mode

1. Press and hold the connect button to turn on the receiver. The LED indicator flashes blue.
2. Activate the Bluetooth function on your Bluetooth-enabled music source (see your device's user's guide for details).
3. Press the connect button twice on the receiver to enter pairing mode. The LED indicator flashes blue and red alternatively as the receiver searches for a device.
4. On your Bluetooth music device, select **RadioShack 1201799** from the device list to pair the receiver. When your device is connected, the blue LED indicator stays lit.
5. To turn off the receiver, press and hold the connect button until the blue LED turns off.

Note: If your Bluetooth-enable device was previously paired with the receiver, they will reconnect automatically once the receiver is turned on.

3

4

Changing Bluetooth Devices

To pair a new device, you must disconnect your device's Bluetooth connection with the receiver first. Press the connect button twice, the LED on the receiver flashes blue and red. Follow the instructions in "Pairing" to connect to a new device.

Specifications

Power 5V DC 300mA
Bluetooth Protocol V4.1 + EDR A2DP
Operation Range 33 ft. (10m)

Specifications are subject to change and improvement without notice. Actual product may vary from the images found in this document.

FCC Information

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult your local dealer or an experienced radio/TV technician for help.

If you cannot eliminate the interference, the FCC requires that you stop using your equipment. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

5

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Limited Warranty

Go to www.radioshack.com/help for details.

RadioShack Customer Relations
300 RadioShack Circle, Fort Worth, TX 76102

The Bluetooth® word mark and logos are owned by Bluetooth SIG, Inc. and any use of such marks by General Wireless Operations Inc. is under license.

RoHS Complies with the European Union's "Restriction of Hazardous Substances Directive," which protects the environment by restricting specific hazardous materials and products.



© 2016 General Wireless Operations Inc.
All rights reserved. RadioShack is a registered trademark used by General Wireless Operations Inc. dba RadioShack.
radioshack.com



12A16
1201799
Printed
in China