

# User Guideline

## 1. Charging for “SUNTUNES”

Make sure “SUNTUNES” BT Speaker is fully charged before using it.

A full charge is approximately 4 hours and plays continuously 5 hours then

1. Connect to a USB charging cable to charge
2. When the LED indicator is RED, the “SUNTUNES” speaker is charging
3. The LED indicator goes off when device is fully charged.

NOTE: Do not charge the product while it's wet; please make sure that the product is dry before charging in order to avoid the risk of electric shock

## 2. Turn On your “SUNTUNES”

For first use, press Power ON/OFF key  of any two “SUNTUNES” respectively for 5 seconds until hear a hint sound, the blue LED quick flashing indicates the two “SUNTUNES” speaker enter into the “pairing mode”, then this two speakers will pair automatically, when hear “connected, left channel , right channel “ means this two speakers have been paired to be a couple,

To pair phone, find the Bluetooth name “SUNTUNES” and connect it with your Bluetooth device.

When hear “pairing successful, second device connected”, you can enjoy the music from the Bluetooth device .If connected by mobile phone, it also has hand-free function!

For second use, press the power ON/OFF key for 3 seconds, the two speakers will be paired automatically, and will connect to the last connected device automatically.

Long press “M” button, the Bluetooth speaker will erase the history of connection

## 3. Turn Off your “SUNTUNES”

Press the the Power ON/OFF key  for 3 seconds until you hear "Power Off".

If the “SUNTUNES” is powered on without any operation for 5 minutes, It will shut down automatically.

Bluetooth Mode: short time pressing , Play/Pause, press  is volume down, press  is volume up. Press  is next track, Press  is last track.

## 4. Answering coming call

If you receive a call while listening to music on the “SUNTUNES”, the music will pause, After processing the incoming call, the music will continue to play. double pressing “M”, Refuse the calling or Recalling the previous calling. short time pressing , answer calling.

## 5. Specifications:

- Bluetooth 4.2 version, support hand-free mode
- Built-in Lithium battery : 3.7V, 1000mAh
- Charging Voltage: 5V
- Speaker : 40mm 4Ω 3W
- Frequency: 60Hz-18KHz
- Distortion: ≤0.5%
- Size: D8.8\*4CM
- Effective Distance: 8M (Without any obstacle)
- Waterproof Grade: IPX6

## 6. Troubleshooting

Normal Problem	Reason	How to solve
When charging the speaker, red LED indicator is not on	Whether USB cable is connected correctly	Check USB cable whether it is connected correctly. Check the Power supply is working or not.
Bluetooth speaker blue LED is not shining	Shortage of battery	Please charge the battery!
Blue LED is shining, but no sound come out	Volume is the most small, not connected sucessfully.	Check whether it is connected with original device playing music. Check the sound volume
Bluetooth device can not find the Bluetooth speaker	Is it power on? Effective range is over 10meters	Check the Bluetooth speaker whether it is power on or not; check the distance whether it is in 10meters or not
Can not connect the Bluetooth speaker	Already connected by other Bluetooth device	Dis-connect the device and connect again.

### **FCC Warning**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.