



Multi-function Amplifier speaker

Multi-function Amplifier speaker

GD-PSW1211



Bluetooth®



The lightning flash with the arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of "uninsulated dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to a person.

The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the unit.

Safety Precautions

Warning: To prevent fire or electric shock, do not expose this appliance to rain or moisture.

IMPORTANT SAFEGUARDS

Caution: Please carefully read all of the following important safeguards to ensure safe operation

1. Read Instructions:

All the safety and operating instructions should be read before the appliance is operated.

2. Retain Instructions:

The safety and operating instructions should be retained for future reference.

3. Follow Instructions:

All operating instructions should be followed.

4. Heed Warnings:

All warnings on the unit and the operating instructions should be adhered to.

5. Power Source:

The appliance should be connected based on instructions.

6. Heat:

Keep the unit away from heat sources such as radiators, refrigerators, stoves or other appliances that may radiate heat.


7. Non-use Periods:

The power cord of the unit should be unplugged from the outlet when you do not use it for a long time.

8. Damage requiring service:

The unit should be repaired by qualified service personnel in the following cases:


- a. The power plug or cable has been damaged;
- b. Objects have fallen or liquid has been spilled on the appliance;
- c. The appliance has been exposed to rain;
- d. The appliance is functioning abnormally.



Accessories



REMOTE CONTROL



INSTRUCTION
MANUAL



FM ANTENNA




AUDIO CABLE



Specifications

- Power: 1200W PEAK
- LED information display
- Bluetooth receiver
- USB flash & SD card reader
- FM receiver
- Microphone input 6.3mm x 2
- Equalizer
- Wireless remote control unit
- LED Lighting Effects
- Speakers: 12" +3" x 2
- Resistance: 3 ohm
- Power source: AC-110V-240Vac 50/60Hz +/-10%
-


FRONT PANEL-CONTROLS AND FUNCTIONS



1.STANDBY	12.LED-2
2.Main Volume control	13.MIC INPUT(TO INSERT WIRED MIC)
3.PLAY(PLAY/PAUSE MUSIC)	14.MIC.VOL
4.MODE(SWITCH TO USB/SD/ BLUETOOTH/AUX-IN)	15.MIC.TREBLE
5.PREV(PREVIOUS SONG)	16.MIC.ECHO
6.COLOR	17.BASS
7.LED-1	18.TREBLE
8.USB/SD CARD INPUT	19.AUDIO OUT
9.EQ	20.AUX IN
10.NEXT(NEXT SONG)	21.FM ANTENNA
11.LED-3	22.POWER SWITCH(POWER ON/OFF)
	23.CHARGING INPUT JACK(AC INPUT)



REMOTE INSTRUCTION



USE OF THE REMOTE CONTROL

Please operate the remote control within a distance of 6m and 30° between the remote and the appliance. Aim the remote at the sensor. Remove all obstacles between the remote and the sensor. The remote control might not work properly if the sensor is exposed to strong sunshine.

If the remote control doesn't work properly, please check the batteries.

Dual Bluetooth Speaker



SYSTEM

2 ways to enter or restart BT function

1. Press the "BT" input button on

Speaker is in "Bluetooth" mode

Auto search and connect

Speaker will enter auto search it will search for the last connected device.

Auto connect to the connected device

The unit will automatically connect to the last connected device that Bluetooth is open with 20 metres in few seconds.
(Note: If device cannot be connected automatically, press the buttons "PLAY/PAUSE", "PREVIOUS", "NEXT" to activate Bluetooth and re-connect the device.)

When speaker cannot find the last connected device

Speaker can be connected with new device
USB the new device
search and connect to
"EDISON PS112"





Limited Warranty

This Limited Product Warranty is provided by BriteLite Enterprises. BriteLite warrants to Customer that the product is free from defects in materials and workmanship under normal use during the Warranty Period of 90 days for parts and 1-year labor. If the product fails to conform to the warranty then BriteLite or its authorized service will either repair or replace any nonconforming product, provided that Customer gives notice of noncompliance within the Warranty Period to BriteLite by emailing service@britelife.net or calling 310-363-7110 (Mexico customers can call 0155 4624 0251). Please retain the original dated receipt as evidence of proof of purchase.



Important: Please read this before returning this product

Please do not return the product to the dealer or initial place of purchase.

If you're having difficulties installing or using this product, our support organization can help you regarding installation, set up and missing or replacement parts.

You can contact us:

E-mail- Service@britelife.net

Phone- (888)-604-8881

In Mexico Please Call 0155 4624 0251



FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.