

aiwa

Over-Ear Wireless Headphones



Voice
Assistant



10 Hours
Playtime[†]



Swivel
Earcups



 Bluetooth®

Item: AI5012

Quick Start Guide

WHAT'S INCLUDED



Over-Ear Wireless
Headphones




1X

USB-C Charging Cable




Quick Start Guide

A CLOSER LOOK




CHARGING


Insert one end of the included USB-C charging cable into the charging port on your headphones.



Insert the other end of the USB cable into a suitable USB charging adapter.



The LED Indicator Light turns red while the headphone is charging and will turn blue when fully charged.




POWERING ON/OFF

Press and hold the multifunction button for approximately three to four seconds to turn ON/OFF the headphones.


Note:

It is recommended to fully charge the headphones before first use.




BLUETOOTH PAIRING

Once powered on, your headphones will go into pairing mode. The LED Indicator will alternately flash red and blue.



Go to the Bluetooth settings menu on your phone. Make sure that Bluetooth is turned on. Connect to the device listed as "AIWA AI5012"

After pairing the headphones LED light will slowly flash blue.



CONTROLS

Multifunction Button

- Press and hold for three to four seconds to power ON/OFF.
- Press to play or pause a track.
- Press to accept an incoming call and press again to hang up.
- Press and hold to reject an incoming call.
- Press twice while connected to a compatible device, to activate voice assistant mode.


Volume +

- Press to increase the volume.
- Press and hold to go to the next song.

Volume -

- Press to decrease the volume.
- Press and hold to go to the previous song.

WIRED LISTENING MODE



- Connect one end of an Aux cable (not included) to the Aux In port on your headphones. Connect the other end to the headphone jack on your audio device in order to listen to music using a wired connection.
- You can use your headphones with a wired connection even when they are low on battery power.

NOTE: Bluetooth capabilities are disabled when there is a wired connection.

SPECIFICATIONS

Bluetooth version: v5.3

Transmission Distance: 10m

Playtime: 10 Hours **

**Applicable at 50% of maximum volume.
Results will be lower when volume is higher.

SAFETY PRECAUTIONS

When using the Over-Ear Wireless Headphones, basic safety precautions should always be followed, including:

1. READ ALL INSTRUCTIONS BEFORE USING YOUR DEVICE.
2. Never expose your device to high temperatures, extreme cold, high humidity, moisture, or water.
3. To avoid the risk of electric shock, never attempt to open or repair your device without the assistance of certified professionals.
4. Your device is not to be used by children or the infirm without suitable adult supervision.
5. Always press all buttons carefully. Do not manhandle your device.
6. Do not use your device at temperatures under 32°F (0°C) or over 104°F (40°C).
7. Do not drop your device, throw, or subject to strong impacts or physical trauma.
8. Contact the manufacturer for support if you detect any abnormalities when using your device. In addition, do not continue to use your device if you detect any smoke or fire.
9. Unplug your device when not in use for extended periods of time.
10. When plugged in, do not place your device on flammable materials such as rugs, carpets, or bedding.
11. Please recycle or dispose of your device properly according to your municipality's laws and rules. Contact local recycling facilities and/or the manufacturer for further information.
12. Clean your device using a soft cloth or paper towel. Do not use harsh chemicals when cleaning your device, and never submerge your device in water.



Warning

To prevent possible hearing damage, do not listen at high volume levels for long periods. For your own safety, please be aware of your surroundings when using these headphones.



Battery Warning

- This device is equipped with an integrated lithium ion battery. The battery cannot be replaced. Do not attempt to remove the battery from the device.
- Do not dispose of in fire or expose to excessive heat.
- Do not crush, puncture, incinerate, or short circuit external contacts.
- Please recycle or dispose of the battery properly. Contact your local recycling facilities and/or the manufacturer for further information.

MAINTENANCE AND CARE

- Use a soft cloth or paper towel to clean your device. Never use any harsh chemicals or detergents for cleaning. Make sure your device is dry before charging.
- When your device is unused, it should be stored in a cool, dry place.
- Never tug or yank on a cable connected to your device. Connect and disconnect cables as carefully as possible.
- Never expose your device to high temperatures or extreme cold.

FCC STATEMENT

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

WARRANTY

This warranty covers the original consumer purchaser only and is not transferable.

This warranty covers products that fail to function properly UNDER NORMAL USAGE, due to defects in material or workmanship. Your product will be repaired or replaced at no charge for parts or labor for a period of one year.

What Is Not Covered By Warranty

Damages or malfunctions not resulting from defects in material or workmanship and damages or malfunctions from other than normal use, including but limited to, repair by unauthorized parties, tampering, modification or accident.

To Obtain Warranty Service and Troubleshooting Information:

Call (800) 592-9541 or visit our website at www.aiwa.us.com

To receive Warranty service along with the name and address of an authorized product service center, the original consumer purchaser must contact us for problem determination and service procedures. Proof of purchase in the form of a bill of sale or receipted invoice, evidencing that the product is within the applicable Warranty period(s), MUST be presented in order to obtain the requested service. It is your responsibility to properly package and send any defective products along with a dated copy of proof of purchase, a written explanation of the problem, and a valid return address of the authorized service center at your expense. Do not include any other items or accessories with the defective product. Any products received by the authorized service center that are not covered by warranty will be returned unrepairs.

**CONTACT US**

1-800-592-9541

www.aiwa.us.com

AIWA

Edison, NJ 08817

© 2025 Aiwa Acquisitions LLC. All rights reserved. AIWA and associated marks are owned by Aiwa Acquisitions and used under license. Keep all relevant information for future reference.

The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by Sakar International is under license. Other trademarks and trade names are those of their respective owners.