







n41 SCS=30kHz CP_QPSK BW=20MHz Channel=501204 RB=1@0




n41 SCS=30kHz CP_QPSK BW=100MHz Channel=528000 RB=273@0




n41 SCS=30kHz CP_QPSK BW=20MHz Channel=501204 RB=51@0




n41 SCS=30kHz CP_QPSK BW=20MHz Channel=501204 RB=1@50




n41 SCS=30kHz CP_QPSK BW=100MHz Channel=509202 RB=273@0




n41 SCS=30kHz CP_QPSK BW=100MHz Channel=509202 RB=1@272




n41 SCS=30kHz CP_QPSK BW=100MHz Channel=528000 RB=1@272




n41 SCS=30kHz CP_QPSK BW=100MHz Channel=528000 RB=1@0




n41 SCS=30kHz CP_QPSK BW=20MHz Channel=535998 RB=51@0




n41 SCS=30kHz CP_QPSK BW=50MHz Channel=504204 RB=133@0




n41 SCS=30kHz CP_QPSK BW=20MHz Channel=535998 RB=1@0




n41 SCS=30kHz CP_QPSK BW=20MHz Channel=535998 RB=1@50




n41 SCS=30kHz CP_QPSK BW=50MHz Channel=504204 RB=1@0




n41 SCS=30kHz CP_QPSK BW=50MHz Channel=532998 RB=1@0



n41 SCS=30kHz CP_QPSK BW=50MHz Channel=532998 RB=1@132



n41 SCS=30kHz CP_QPSK BW=50MHz Channel=504204 RB=1@132



n41 SCS=30kHz CP_QPSK BW=50MHz Channel=532998 RB=133@0

