































































ANT	Support Band
ANT0	RX
ANT1	RX
ANT2	GSM850/ WCDMA B5/ LTE B5/12/13/17/26
ANT3	RX
ANT4	GSM1900/ WCDMA B2/4/ LTE B2/4/7/66/38/40/41
ANT12	wifi main ant;bt/ble ant0
ANT13	GPS
ANT14	wifi aux ant;bt/ble ant1