

Bluetooth Speaker User Manual



Specification

Bluetooth version	V4.1
Bluetooth profile	A2DP/ AVRCP/ HFP/HSP
Bluetooth range	10m
Input voltage	DC/5V
Battery capacity	7.4V/2600MAH
Charge time	4 hours
Play time	up to 8 hours

FCC Disclaimer

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

ON/OFF

power on:

In the state of power off, press the “ \diamond ” button for about 1 second, the indicator will turn blue and flashing , you will also hear a notification tone. The speaker is on .

power off:

In the state of power on, press the “ \diamond ” button for about 1 second, the indicator will be off, you will also hear a notification tone. The speaker is off.

Pairing to phone

1. Press the “ \diamond ” button for about 1 second to turn on the speaker, the indicator will turn blue and flashing.
2. Turn on the Bluetooth function of your phone .
3. Search the Bluetooth devices and select “MPOW-064”.
4. Enter the code “0000” if needed .
5. If pairing is successful , the indicator will be turn blue and stop flashing.

Automatic Connect

It will connect to the last connected phone automatically when it turns on. (Please make sure the Bluetooth function of your phone is on before turn on the speaker.)

Music Mode

Play/Pause: Short press the “ $\blacktriangleright\blacksquare$ ” button to play/pause music .

Volume up: Short press the “ $+$ ” button.

Volume down: Short press the “ $-$ ” button.

Next track: Short press the “ $+$ ” button.

Previous track: Short press the “ $-$ ” button.

Aux Function

Some devices (such as MP3/MP4) have no Bluetooth function , so you can use the 3.5mm AUX audio cable to connect your device to the speaker to play music . You can adjust volume on the speaker.

Call Mode

Answer a call: Short press the “ $\blacktriangleright\blacksquare$ ” button.

Reject a call: Long press the “ $\blacktriangleright\blacksquare$ ” button for about 1 second.

Hang up a call: Short press the “ $\blacktriangleright\blacksquare$ ” button when talking .

Charging

It is recommended to charge the speaker fully for the first time.

Please use the DV/5V charger to charge the speaker .

1. Connect the USB charging cable to the USB charge port of the speaker .
2. The indicator will turn red when charging .
3. The indicator will turn blue when charging completed .