







<div data-bbox="214 138 388 205"><h1>Mini Speaker</h1><h2>User Manual</h2></div> <div data-bbox="277 219 331 233"><p>Model#:</p></div> <div data-bbox="222 252 391 451"></div>	<div data-bbox="551 126 817 178"><p>Dear customer: Thank you for purchasing Mini Wireless Speaker. Please read this user guide carefully before operation and save these instructions for future reference.</p></div> <div data-bbox="551 361 793 413"><p>Packaging included:</p><ul style="list-style-type: none">1. Mini Speaker1 pc2. Charging Cable (FM antenna)1 pc3. User manual1 pc</div>	<div data-bbox="985 116 1032 129"><p>FEATURES</p></div> <div data-bbox="980 182 1262 236"><div> Hands Free</div><div> LED Light</div><div> Wireless Transmission</div></div> <div data-bbox="980 278 1056 290"><p>SPECIFICATIONS:</p></div> <div data-bbox="980 305 1211 385"><ul style="list-style-type: none">- Model # : UT2304- FCC ID:2AJ9K-UT2304- Output Power: 3W- Battery: 300mAh- Music Play time: Up to 1.5 hours- Speaker Output Frequency range: 150Hz - 20kHz</div>	<div data-bbox="1366 107 1439 119"><p>FUNCTION KEYS</p></div> <div data-bbox="1447 107 1635 297"></div> <div data-bbox="1366 323 1721 485"><ol style="list-style-type: none">1. ON/OFF button: Long press to turn Power ON/OFF; Short press for Play / Pause; Short twice press to switch to FM mode; Short press to enable automatic search in FM mode.2. Long press to turn down the volume / Short press to skip to previous song or previous FM station.3. Long press to turn up the volume / Short press to skip to next song or next FM station.4. Charging Port5. USB port6.7.8.</div>	<div data-bbox="1787 111 1838 126"><p>ON/OFF</p></div> <div data-bbox="1787 131 2142 185"><p>Turn ON: Press and hold the ON/OFF button till to hearing reminder tone and LED light starts flashing. Turn OFF: Press and hold the ON/OFF button till to hearing reminder tone and the LED lights off.</p></div> <div data-bbox="1787 201 1933 216"><p>BLUETOOTH® PAIRING</p></div> <div data-bbox="1787 220 2142 460"><ol style="list-style-type: none">1. Press and hold the ON/OFF button till to hearing reminder tone and LED light starts flashing, speaker now is in pairing mode.2. Place the speaker and Bluetooth® device (phone or music device) so that they are no further than 1 meter apart.3. Activate the Bluetooth® function on your Bluetooth® device (phone or music device). Please refer to the manufacturer's instruction manual to enable Bluetooth® on your device.4. Select the speaker "Mini Speaker" from the list of available Bluetooth® devices.6. Once paired sucessfully, you will hear the confirmation tone. If pairing is unsuccessful, turn off the speaker first and then re-pair following the above steps.7. Once you have paired the speaker with a device, the speaker will remember this device and will pair automatically when the device's Bluetooth® is activated and in range. The speaker will attempt to automatically connect to the last device it was paired with when switched on. If you want to pair it with a new device, please follow the steps outlined above.</div>	<div data-bbox="2186 116 2265 131"><p>PLAY MUSIC</p></div> <div data-bbox="2186 131 2542 212"><ol style="list-style-type: none">1. Short press "⏸" button to pause music. Short press again to resume music play.2. In Bluetooth Mode, Short press "⏮" button to skip to the previous song. Press and hold this button to turn down the volume.3. In Bluetooth Mode, short press "⏭" button to skip to next song. Press and hold this button to turn up the volume.</div> <div data-bbox="2186 323 2398 338"><p>Hands free Phone Call Operation</p></div> <div data-bbox="2186 341 2449 354"><ol style="list-style-type: none">1. Short press "☎" button to answer an incoming call.</div>
<div data-bbox="111 581 483 624"><p>MODE SWITCH Turn ON the speaker and short press twice "⏻" button to switch through different modes by following below orders: Bluetooth® - FM - Bluetooth®</p></div> <div data-bbox="111 658 483 766"><p>FM RADIO</p><ol style="list-style-type: none">1. Turn ON the speaker, short press twice "⏻" button till to hear "FM Tuner".2. Plug the USB charging cable (included) to the DC 5V charging port of speaker, this cable serves as FM Antenna as well.3. short press "⏻" button and device will automatically search and store all the FM Radio stations4. Short press "⏮" and "⏭" button to change the FM Radio station.5. Press and hold "⏮" and "⏭" button to turn down or turn up the volume.</div>			<div data-bbox="1368 581 1713 662"><p>CHARGING</p><p>The speaker includes a built-in rechargeable battery. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.</p><p>Connect the USB cable to a computer or other USB charging port and the micro USB plug into charging port of the speaker. A red light turns ON during charging and turns OFF after full charged.</p></div> <div data-bbox="1368 696 1686 817"><p>IMPORTANT NOTES</p><ol style="list-style-type: none">1. This product is not a toy.2. Do not drop or damage the speaker.3. Do not use in humid or extrem temperatures.4. Do not place the speaker near an open flame.5. Do not block the sound of the speaker while it is in use.6. Do not use the unit if it has been dropped or damaged in any way.7. If damaged, do not attempt to repair or disassembled the speaker.</div> <div data-bbox="1368 856 1713 881"><p>The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc.</p></div>	<div data-bbox="1797 573 2137 651"><div data-bbox="1906 571 2137 651"><p>This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.</p></div></div> <div data-bbox="1797 669 2137 681"><p>FCC ID:</p></div> <div data-bbox="1797 700 2137 752"><p>Federal Communications Commission (FCC) Statement. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:</p></div> <div data-bbox="1797 771 2137 823"><p>(1) This device may not cause harmful interference, and</p><p>(2) this device must accept any interference received,</p></div> <div data-bbox="1797 842 2137 951"><p>including interference that may cause undesired operation. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide Reasonable protection against harmful interference in a residential installation.</p></div>	<div data-bbox="2205 573 2558 889"><p>This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</p><ul style="list-style-type: none">• Reorient or relocate the receiving antenna.• Increase the separation between the equipment and receiver.• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.• Consult the dealer or an experienced radio/TV technician for help.<p>Warning: Changes or modifications made to this device not expressly approved by UTONG (HK) COMMERCIAL LIMITED, may void the FCC authorization to operate this device. Note: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.</p><p>RF exposure statement: This device complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. The device is installed and operated without restriction.</p></div>

颜色：灰色印刷
材质:100g书写纸，双面印刷
要求:字迹清晰,颜色饱满,裁切位置准确,
无杂色和漏白现象.