



# Shortcuts Button

- 1 Delete the apps you download by pressing and holding down the ok button for two seconds.




## Shortcuts Bottom

② You can clean the memory by holding the home button for two seconds.



## Online Upgrade

- 1, Homepage>Settings>System Settings>System Upgrade. Before you update ,please connect the power adapter and wifi , otherwise, the update will fail or the system will crash.
- 2, If there is no reaction,please return to settings and try again,after finishing update,the system will turn on automatically.
- 3, If it shows the lastest version of software then the system is up to date.




# System Settings

- 1, Boot signal: Close/HDMI
- 2, Device Information: Displays equipment performance and software information.
- 3, System Upgrade: Online Upgrade/U-disk Upgrade
- 4, Restore factory reset : All apps will be deleted once you click this option.
- 5, Fan Settings: Automatic/Manual
- 6, Boot mode: Remote control/Power on



# Attention

For apps already installed on the system (YouTube, Netflix, Prime Video), please do not upgrade to other versions, otherwise the upgrade will be incompatible or the remote control will not work.





# Sound Settings

1,Sound Output: Output of Digital Audio (RAW / PCM / Off)

2,Key Tone: On / Off

3,Sound Effect: Standard/ Vivid / Sports / Movie / Music

4,Boot Sound: On / Off



# Graphic Settings



1, Brightness: Standard Mode/Highlight Mode,/Evergy saving mode.

2, Keystone: Automatic or manual adjustment.

3, Projection : Front,Rear,Celling front and Celling rear mode.



4, Zoom: Stepless zoom and Image ratio.

5, Video Mode: Color mode,warm mode,cool mode and custom mode.





## How to adjust keystone in manual mode

- 1,Turn on manual mode in keystone,then choose trapezoid correction.
- 2,For the top left and right points,press the down button on the remote for adjustment.
- 3,For the bottom left and right points,press the up button on the remote for adjustment.



# Wallpaper Settings


Replace Desktop Background (homepage>settings>wallpaper)



# Wireless screen (Windows)

## Windows with screen operation guide

1. Please confirm your Windows and projector IP addresses are connected to the same LAN.
2. Use the following link to download and install: <http://cdn.sharemax.cn/app/EShareClient-STD.exe>
3. Click Esharecent-STD, and the name and IP address of the projection device will appear. Click "Start Screen Transmission" to begin using the wireless screen.




# Airplay (iPhone)

## iPhone AirPlay mirror operation guide

Supported by the following devices: iPhone 5 and above, iPad 2 and above, iPod Touch (5th generation and above).

1. Connect your iPhone and projector to the same --WIFI-- network (5G first)




# Airplay (iPhone)

## iPhone AirPlay mirror operation guide

Supported by the following devices: iPhone 5 and above, iPad 2 and above, iPod Touch (5th generation and above).


2. Click to open the projected Airplay, and then Eshare-\*\*\*\* will be displayed in the lower left corner.
3. Slide your finger from the bottom of the iPhone screen to the top, bringing up a new menu, and open the iPhone control center (Slide from the top down for iPhone X),
4. Click AirPlay Mirroring and the device list will automatically search for the projected devices within the same network
5. From the device list, click the name of the projected device you want to connect to (Eshare-\*\*\*\*) to successfully cast the screen.



# Airplay (iPhone)

## Use mobile hotspot for AirPlay mirror operation guide

1. For use without having a LAN or wifi available, first turn on "Settings" -- "Personal Hot spot" -- "Allow others to join" on the iPhone, select and turn on
2. Click "Settings" of the projector -- turn on "WIFI", search for the hotspot name of iPhone, and find and connect.



3. Swipe your iPhone from the bottom up and open the iPhone control center (Slide from the top down for iPhone X).
4. Click "AirPaly Mirroring" and the device list will automatically search for the internal projection device in the same network.
5. From the device list, click the name of the projected device you want to connect to (Eshare-\*\*\*\*) to successfully cast the screen

# iPhone AirPlay reverse

## Screen Projection operation Guide

1. Click to open the projected Airplay, then follow the prompts on the page to scan the QR code of your iPhone, download and install the corresponding Eshare APP.



2. Open the Eshare app on the mobile phone, and the device list will automatically search for the internal projection device of the same network.
3. Click the projection device (Eshare-\*\*\*\*), "one-click screen transmission" and "Reverse screen transmission" will appear simultaneously.
4. Click "Reverse Screen Transmission".


## Wireless screen

Android with multi-screen interactive models with screen tutorial  
(Android phone)

Note: It is recommended to use the built-in Android screen and Eshare android screen. The voice cannot be transmitted (the system audio acquisition permission cannot be obtained).


# Android Miracast operation guide

- ① The android phone and the projector connect the WIFI.
- ② Enter settings and click miracast.




# Android Miracast operation guide

- ③ Open “More Connections or Screen Projection for Android Phone” on the mobile phone (there are a variety of models of Android mobile phones which may have different names, and the mobile phone to be referred is HUAWEI mobile phone).
- ④ The phone and projector will seach for same model in a few seconds and connect successfully.





## WIFI Connection

Homepage>Settings>Wifi >turn on wifi option



## Bluetooth Connection

Homepage>Settings>Bluetooth>Open Bluetooth



# HDMI

## Connect External Multi-media Interface



Connect the HD cord to the projector and click HDMI on the home screen which will appear in sync within five seconds .

Notes: It can be combined with Amazon Fire TV Stick to connect the projector.




## Select language

Homepage>Settings>General settings>Language




# File Explorer

Please check the files in File Explorer when you play in your USB.



# Remote Control

## Instruction of Buttons



Note:1. Please keep the remote control aiming at the projector screen.  
2. Please take out the battery if the remote control is not used for a long time.

## How to use the external mouse?



1,Click the left button on mouse to enter the screen you have selected.

2,Click the right button on mouse to exit the screen you have selected.

## Focus

Slide the focus adjust to the left or right to make the picture clear.



## Connection & Key

Device port



## FCC Warning:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.