


# Brookstone®

## Speaker Candle

STREAM HOLIDAY MUSIC  
TO ANY ROOM



Fold

### LITHIUM-ION BATTERY WARNINGS

This device contains a non-removable Lithium-Ion battery. The battery must be recycled or disposed of properly. Contact your local waste management office for information on battery recycling or disposal.

Fold

### FCC INFORMATION

This equipment has been tested and found to comply with the limits for a Class B Digital Device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the distance between accept any interference received, including interference that may cause undesired operation.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an

Fold

experienced radio/TV technician for help.

This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This equipment may not cause harmful interference.
2. This equipment must accept any interference received, including interference that may cause undesired operation.

Modifications not authorized by the manufacturer may void the user's authority to operate this device. This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Fold

### TROUBLESHOOTING

#### BLUETOOTH NOT CONNECTING

- Ensure your device is within 33 feet of the speaker and reconnect your device to "Candle Speaker."

#### AUDIO IS NOT CLEAR

- Power the speaker off and then back on.
- Adjust your device's equalizer.
- Check the volume level on your device.

#### SPEAKER DOES NOT PLAY AUDIO

- Make sure the speaker is charged.
- Power the speaker off and then back on.
- Confirm device is paired.

**NOTE:** The speaker remembers the last device paired. If you would like to use another device, pair that device manually.

Fold

### CARE AND MAINTENANCE:

Clean the candle with a soft, dry cloth. Do not use harsh cleaners to clean the candle. Please note the wax candle is made from real wax and should be handled and stored with care.

Fold

### SAFETY INSTRUCTIONS

- This is an artificial candle. Do not light the candle.
- The candle is a decorative item and not a toy.
- Place the candle on easy to clean, durable surfaces. Product contains wax and oil and may stain delicate surfaces.
- The candle must not be exposed to extreme temperatures, direct sunlight and moisture.

### SPECIFICATIONS

Power Supply: DC 5V/ 1A (Input)

Range: Class 2, up to 33 ft (10 m)

Compatibility: Bluetooth 2.1 device with A2DP/AVRCP

Speaker: 4 Ohm 2.5"

Power Output: 3W

Frequency Response: 200Hz ~ 10KHz

Battery Life: Approx. 6 hours

Charging Time: Approx. 4hours

Product Weight: Approx.1.0 lb

Product Dimensions:

Approx. 3.75" (dia) x 5.7" (h)

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Brookstone is under license.

© Brookstone 2016

# Brookstone®

A WORLD OF INNOVATION

Since 1965, people have come to Brookstone to see what's new, discover smart solutions to everyday problems—and have some fun. At Brookstone, we believe there's always a better way to do things. And we created a world of innovation to prove it.

Merrimack, New Hampshire, USA 03054  
800-846-3000 • Brookstone.com


319819

Fold

## CHARGING THE SPEAKER

1. Connect the USB Cable (included) to the Micro USB Port on the speaker.
2. With the speaker powered off, plug the other end of the USB Cable into a USB Port on your computer or 5V 1A USB adapter (not included).
3. The LED Indicator light will illuminate red while charging and the light will turn blue when the speaker is fully charged. Charges in approximately 4 hours for up to 6 hours of listening enjoyment.

NOTE: When battery power is low, an alert tone will sound.



Fold

## OPERATION

The control switch is located on the bottom of the Candle Speaker.

1. C (Candle function only)
2. OFF (Unit Off)
3. BT + C (Bluetooth Speaker and Candle function ON)

When switching to "C", the candle function is ON with automatic timer setting of 5 hours. The candle will stay ON for 5 hours and then OFF for 19 hours. The candle will turn on every day at the same time it was originally set.

Set the switch to "OFF" to turn off the candle and speaker function.

When switching to "BT+C", the Bluetooth Speaker function and Candle function is ON.



Fold

## PAIRING YOUR DEVICE FOR AUDIO

1. To pair your device make sure your device is within 33 feet of the Candle Speaker. Refer to your device's owner's manual for details if necessary.
2. Turn the switch of the candle speaker to "BT+C".
3. The pairing mode tone will sound and the speaker is ready to pair.
4. Once the Candle Speaker is in pairing mode and your device is ready to pair, select "Candle Speaker" on your device. If prompted, use 0000 as a PIN for the pairing code. Once the Candle Speaker is selected, a tone will sound to confirm pairing is complete.
5. After the initial pairing of your device, the Candle Speaker should automatically pair with your device the next time the unit is powered on. Depending upon your device, you may have to select "Candle Speaker" in your device's Bluetooth® menu.
6. To enter manual pairing mode to pair with a new device, switch the Candle Speaker to "OFF" and to "BT+C" again to activate the Bluetooth pairing mode.
7. When "BT+C" mode is ON, if there is no Bluetooth connection established or the connection is lost for over 30min, the Candle Speaker will automatically turn off the Bluetooth function to conserve battery life. The flame light will remain lit. Re-set the Bluetooth function by moving the switch to "OFF" and then to "BT+C" again to activate Bluetooth functions.
8. Volume control and playback function can only be controlled through the paired device.

Fold

## ONE (1) YEAR LIMITED WARRANTY

Brookstone® warrants this product against defects in materials and/or workmanship under normal use for a period of ONE (1) YEAR from the date of purchase by the original purchaser ("Warranty Period"). If a defect arises and a valid claim is received within the Warranty Period, at its option, Brookstone will either 1) repair the defect at no charge, using new or refurbished replacement parts, or 2) replace the product with a new product that is at least functionally equivalent to the original product, or 3) provide a store credit in the amount of the purchase price of the original product. A replacement product or part, including a user-installable part installed in accordance with instructions provided by Brookstone, assumes the remaining warranty of the original product. When a product or part is exchanged, any replacement item becomes Brookstone's property. When a store credit is given, the original product must be returned to Brookstone and becomes Brookstone's property.

**Obtaining Service:** To obtain warranty service, call Brookstone Limited Warranty Service at 1-800-292-9819. Please be prepared to describe the product that needs service and the nature of the problem. A purchase receipt is required. All repairs and replacements must be authorized in advance. Service options, parts availability and response times will vary. You are responsible for delivery and the cost of delivery of the product or any parts to the authorized service center for replacement, per our instructions.

**Limits and Exclusions:** Coverage under this Limited Warranty is limited to the United States of America, including the District of Columbia and the U.S. Territories of Guam, Puerto Rico, and the U.S. Virgin Islands. This Limited Warranty applies only to products manufactured for Brookstone that can be identified by the "Brookstone" trademark, trade name, or logo affixed to them or their packaging. The Limited Warranty does not apply to any non-Brookstone products. Manufacturers or suppliers other than Brookstone may provide their own

Fold

warranties to the purchaser, but Brookstone, in so far as permitted by law, provides these products "as is." This warranty does not apply to: a) damage caused by failure to follow instructions relating to product's use or the installation of components; b) damage caused by accident, abuse, misuse, fire, floods, earthquake or other external causes; c) damage caused by service performed by anyone who is not a representative of Brookstone; d) accessories used in conjunction with a covered product; e) a product or part that has been modified to alter functionality or capability; f) items intended to be periodically replaced by the purchaser during the normal life of the product including, without limitation, batteries or light bulbs; g) any product sold "as is" including, without limitation, floor demonstration models and refurbished items; or h) a product that is used commercially or for a commercial purpose.

**BROOKSTONE SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT, OR ARISING OUT OF ANY BREACH OF THIS WARRANTY.** TO THE EXTENT PERMITTED BY APPLICABLE LAW, BROOKSTONE DISCLAIMS ANY AND ALL STATUTORY OR IMPLIED WARRANTIES, INCLUDING, WITHOUT LIMITATION, WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND WARRANTIES AGAINST HIDDEN OR LATENT DEFECTS. IF BROOKSTONE CANNOT LAWFULLY DISCLAIM STATUTORY OR IMPLIED WARRANTIES, THEN TO THE EXTENT PERMITTED BY LAW, ALL SUCH WARRANTIES SHALL BE LIMITED IN DURATION TO THE DURATION OF THIS EXPRESS WARRANTY.

Some states disallow the exclusion or limitation of incidental or consequential damages or how long an implied warranty lasts, so the above exclusions or limitations may not apply to you. This warranty gives you specific legal rights and you may also have other rights, which vary from state to state.