



561128 Label Picture Location



The label is located on the lower half of the housing, opposite end from the connectors and opposite side from the Maven logo.