


VR SHINECON

USER GUIDE



1. Connect to the remote control, the default mode for the VR mode.
2. In VR mode, the user can control the current popular VR APP, such as magic VR, Storm magic mirror, 3D playing, Orange VR, PlayGlass, etc
3. In iOS mode, if the user finds the button is invalid, then in the phone's input status, you can long press the mouse button, call the soft keyboard, and switch typewriting of the system to "English".
4. In the multimedia mode, it can operate most of the music player software in the market and the system equipped audio player, to realize volume addition and subtraction, selections, pause and other functions.

4. Matters needing attention

1. Part of Android device has automatic connection function when detecting Bluetooth device used for the last time, when you find that matching can not be achieved, Please check whether the Android device or the product has been connected to other devices, if so, please remove this connection before matching.
2. If once connected to this product, if difficulties in connection after this product matching with other devices, Please re connection and matching.
3. Signal interference problem exists in Bluetooth and WiFi of some phones, proposed to close the WiFi before the connection.
4. When the unexpected situation leads to abnormal, please take out the battery and reload.
5. When the indicator light is not enough, the battery power is not enough, this time the user should replace the battery.

5. Product specification parameters

Transmission media: Bluetooth 3.0
Carrier frequency: 2.4~2.483GHZ
Working voltage: 2.4~3.6V
Maximum receiving distance: 10 meters
Battery type: Standard AAA7 alkaline battery
Battery quantity: 2 sections
Work environment: -10° ~ 70°

Thank you for your purchase of our "SC-RA8 multi function Bluetooth VR handle" product, please check the packing list:



(1pc manual)



(1pc device)



Attention to our WeChat and official website




Manufacturer:Dongguan City VR Shinecon Industrial Co., Ltd.



1. Product introduction

Thank you for purchasing our products, this is a portable VR handle, which can be used for Remote mobile phone, panel computer, with the functions of wireless mouse, game handle, music control, and it can be applied to Apple (iOS) system, Android (Android) system. This product is rich in function, with 3 modes of VR mode, mouse mode (only for Android devices), multimedia mode.

2. Basic Function instructions



3. Operation instructions

• On/off

1. Android mode boot: Long press the return key (Android) for boot LED indicator light, and then flashing (Flashing indicates no connection to any device), Name of "available device" for Android devices searched is:

5. After-sale service

• Important tips, please read:

All the packing of the goods to be returned shall be kept, you can require accessories from us by WeChat customer service, Customer service phone, and official website.

• But, the following circumstances do not belong to the scope of "Three guarantees" :

1. Lack of valid invoices or not in the validity period of "Three guarantees"
2. Damage caused by use, maintenance, custody not in accordance with the requirements of the product specification.
3. Damage caused by fire, flood, lightning, and other force majeure factors
4. Failure caused by man-made factors, such as disassembling and refitting without permission.
5. Products can not be used due to User's own mobile phone adaptation, network environment.

VR Shinecon-xxxx (note: xxxx is a random combination of 4 digits and letters, such as 2B5T), Please click on the device at this time, prompt "pairing", after the matching is successful, it will be displayed in the matched device list. At this time the indicator light continues to be in a state of slow blink.

2. Apple mode boot: Long press the menu button (iOS) for boot, the matching process, please make reference to the above Android boot process, the name of the Bluetooth device that is searched in the Apple device: VR Shinecon-iOS-xxxx (note: xxxx is a random combination of 4 digits and letters, such as 2B5T).

3. Turn off : Long press the menu button (iOS) till indicator light, flashing, quenching, at this time the remote shutdown.

• Each mode switch and button function operation of the system see below table:

Android devices				
		VR mode	System music	Mouse mode
Up and down rocker		Select items to move up and down	—	Up and down movement of the mouse
Right and left rocker		Selected item left or right to move	Song selecting	Right and left movement of the mouse
	Short press	Back	Volume +	Back
	Long press	Enter multimedia mode	Exit multimedia mode	Enter multimedia mode
	Short press	home page	Volume-	Hide mouse arrow
	Long	power off	power off	power off
Mouse	Short press	—	—	—
	Long press	Enter mouse mode	Enter mouse mode	Exit mouse mode
OK		OK	OK	OK

iOS devices				
		VR mode	Mouse mode	
Up and down rocker		Select items to move up and down	Up and down movement of the mouse	
Right and left rocker		Selected item left or right to move	Right and left movement of the mouse	
	Short press	Back	Back	Back
	Long press	Enter multimedia mode	Enter multimedia mode	Enter multimedia mode
	Short press	home page	Hide mouse arrow	
	Long	power off	power off	power off
Mouse	Short press	—	—	—
	Long press	Enter mouse mode	Exit mouse mode	Exit mouse mode
OK		OK	OK	OK

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.