

正面

8.Accessoires

AC/DC power adapter, English user manual, HDMI cable, HDD metal case (if you order).

9.Order more GOLE products from Aliexpress:

Store : <http://www.aliexpress.com/store/2173013>

Tips: The 5inch touch panel we designed is just a auxiliary display, better performance request connection with TV or bigger monitor and pairing keyboard & mouse.

Correct disposal of this Product

Waste Electrical & Electronic Equipment (WEEE)

Your product is designed and manufactured with high quality materials and components which can be recycled and reused.

This symbol means that electrical and electronic equipment, at their end-of-life should be disposed of separately from your household waste.

Please dispose of this equipment at your local community waste collection/recycling center.


There are separate collection systems for used electrical and electronic products. Please help us to conserve the environment we live in!

This product comply with European and USA safety as well as electrical interference directives.




MADE IN CHINA


Copyright © 2016 GOLE All rights reserved.



d.How to go to tablet desktop on Windows OS ?


Click the icon “tablet mode” ”, then can switch to tablet desktop as per below picture.






b.Where is language setting ?

We default English under Android OS, if you need switch other languages, kindly enter into setting and find Language, there have multi language in option.





5.Power supply

Kindly use GOLE1 AC/DC power adapter (5V/3A) qualified to supply power for the device, any damage to device resulted from unqualified or inappropriate power adapter will be born by user.

**Warning :**

Once the device connect with hard disc, please make sure to use GOLE1 AC/DC power adapter (5V/3A) to supply power in order to guarantee the device working well.

Please pull out the plug of power adapter if you do not use the device for long time.

6.Lithium battery charge

This device include lithium battery, the charging time will 1.5-2 hours if use GOLE1 power adapter under the device power off, do not charge over 3 hours.

And also can charge by power bank 5V/2A under the device power off, the charge time will be 1.5-2 hours, do not charge over 3 hours.

7.Specification and features

|                      |                                                                                                              |                    |
|----------------------|--------------------------------------------------------------------------------------------------------------|--------------------|
| CPU                  | Intel Cherry trail T3(Quad-core) Z8300                                                                       |                    |
| GPU                  | Intel Gen 8-LP                                                                                               |                    |
| Screen               | 5" 720x1280 IPS                                                                                              |                    |
| Touch Panel          | G+P, 5 points touch                                                                                          |                    |
| RAM                  | 2GB LPDDR3                                                                                                   | 4GB LPDDR3(option) |
| ROM                  | eMMC 32GB                                                                                                    | eMMC 64GB(option)  |
| Dual OS              | Compatible with both Windows 10 and Android 5.1                                                              |                    |
| Wireless             | WIFI 802.11 B/G/N/AC (Dual bands)                                                                            |                    |
| Bluetooth            | BT 4.0                                                                                                       |                    |
| Windows OS languages | English in default (Multi languages can be downloaded)                                                       |                    |
| Android OS languages | 68 multi languages                                                                                           |                    |
| connector            | HDMI                                                                                                         | 1 (V1.4A)          |
|                      | Ethernet                                                                                                     | 1                  |
|                      | TF card slot                                                                                                 | support 64GB max   |
|                      | USB host                                                                                                     | 3                  |
|                      | USB host 3.0                                                                                                 | 1, high speed      |
|                      | Micro USB                                                                                                    | 1                  |
|                      | Audio                                                                                                        | earphone 3.5mm     |
| Speaker              | 1x8ohm                                                                                                       |                    |
| Button               | power on/off, vol+/-, Home                                                                                   |                    |
| Outer casing         | Aluminum/Golden                                                                                              |                    |
| Measure              | 135.4x90.4x20mm                                                                                              |                    |
| Others               | Support wire & wireless keyboard and mouse, Flash 11, HTML 5, browser, Decoding video 4K, HDMI output 1080P. |                    |

GOLE1

User Manual

反面

>Welcome

Thank you for purchasing our product and very appreciated with your business supporting for GOLE products. Your comments, suggestions as well as feedback are our forward motive power always.

This user manual includes very important security remind and information about the product. For better using and enjoying it, we highly recommend you to read the following information before starting to use it.

Declaration

1. The information in this manual may not, except under written license by The Company, be copied, transmitted, distributed, or stored.

2. Although efforts have been made for correctness and completeness during the preparation of the manual, there is no guarantee that this manual is free from any error or omission. The Company assumes no reliability regarding the errors or omissions that might exist in the manual.

3. For sustainable development, The Company reserves the right to modify and improve any product described in this manual without prior notice.

4. We are not responsible for the lost of your data in your device under any circumstances.

Precautions

For the correct use and good performance of the player, the user must fully understand the manual as well as strictly follow the instructions provided.

1.Avoid leaving your device in high temperature, high humidity or dusty air-environment.

2.Never knock the main machine violently.

3.Never contact with chemicals such as benzene, thinner etc.

4.Do not close to strong magnetic field, electric field etc.

5.Don't spatter water on the device.

6.Don't clean the device by wet dishcloth.

7.Ventilation hole can not be fixed or jammed.

8.Keep away from direct sunlight or heating appliances avoid lithium battery explode.

9.Never privately disassemble, repair or modify the player.

10.If the power plug can not match your power outlet, please ask for professional electric clerk to change.

11.Kindly power off the device in thunder storm weather or do not use it for long time.


12.Using the player and the earpiece during bicycling, car and motorcycle driving is likely to cause danger.

13.Never use higher volume, which may damage your hearing ability.


14.Divide scraped packing, batteries, old electronic products and dispose them properly.

1.GOLE1 Overview


a.Buttons Illustration



b.Connection Port 1




c.Connection Port 2




d. Hard disc case (if you order)

It can connect with GOLE1 device by magnetic 5 pin USB docking as per below.




2.How to enter into operate system ?

After you boot the device, the device will display below menu, you can choose anyone OS Android or Windows.




3.Windows 10 OS

a.On the desktop of Windows 10, click the icon "WintoAnd"  to switch to Android OS, like as below.




b.How to set language under Windows 10 OS ?

Default English from our GOLE1, if you want to change to other language, please go to setting "add language" to download the language which you need as per below.



c. How to recover the system ?

Please enter into setting, then go to Update&Security, find menu "recovery" like as below.



## **FCC Warning**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.