

IMPORTANT SAFETY INSTRUCTIONS

SAVE THESE INSTRUCTIONS

When using the AeroGarden® Grow Light, basic precautions should always be followed. Read all instructions before using your AeroGarden® product.

DANGER! - To reduce the risk of electric shock:

1. The AeroGarden® Grow Light has a specific plug. Do not change or modify the plug in any way

2. Always unplug the AeroGarden Light from electrical outlet before cleaning

WARNING! - to reduce risk of burns, fire, electric shock, or injury to persons:

3. Unplug the AeroGarden Light from outlet before putting on or taking off parts

4. Please take proper precautions when operating an AeroGarden Light near or by individual requiring close supervision, including children

5. Use the AeroGarden Light only for its intended use as described in its instructions

6. Never operate the AeroGarden Light if it has a damaged cord or plug, if it's not working properly, if it has been dropped and damaged, or if it has been dropped in water. If any of these conditions occur/exist, contact www.AeroGardenSupport.com or your country's local distributor for instructions

7. Keep cord away from heated surfaces

8. Never operate furnishing with air openings blocked. Keep air openings free of lint, hair, and the like

9. Never drop or insert any object into any electrical openings

10. Do not use outdoors

11. Do not operate where aerosol (spray) products are being used or where oxygen is being administered

12. Do not touch moving parts, or hot parts, such as pumps, lights, reflective surfaces, and the like

13. To disconnect, remove plug from outlet

14. Do not place or submerge base, cord, plug, or light hood in water or other liquid to clean it

15. Do not allow water to contact hot LED Grow Light

16. Use only approved and supplied parts and accessories. Use of any other kind of accessory is not recommended. Replacement parts can be ordered from AeroGarden.com

17. Do not use the AeroGarden light for other than its intended purpose

18. This product is intended for household and residential use only. This product is not approved for commercial applications

19. If supply cord is damaged, it must be replaced by manufacturer, its service agent, or similarly qualified technician in order to avoid hazard

20. Electrical wiring must be in accordance with local regulations

21. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of appliance by a person responsible for their safety

22. Children should be supervised to ensure that they do not play with the appliance

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. Note: This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: -Reorient or relocate the receiving antenna. -Increase the separation between the equipment and receiver. -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. To maintain compliance with FCC's RF exposure guidelines, this equipment should be installed and operated with a minimum distance of 20cm between the radiator and your body.

This device complies with Industry Canada's license-exempt RSSs. Operation is subject to the following two conditions: (1) This device may not cause interference; and (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et; (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

LIMITED WARRANTY

WHAT IS COVERED – This warranty covers any defects in materials or workmanship, with the exceptions stated below.

HOW LONG COVERAGE LASTS – This warranty runs for one (1) year on the LED Grow Light from the date of original purchase, for the original purchaser/user.

WHAT IS NOT COVERED – The warranty shall not apply to problems arising from: normal wear; failure to adhere to enclosed operating instructions; serial numbered products if the serial number has been removed or defaced; products subject to negligence, accident, improper use, maintenance or storage; products damaged by circumstances beyond AeroGrow International Inc.'s control; loss or damage to removable parts; or products modified (including, but not limited to, modifications through the use of unauthorized parts or attachments) or repaired by anyone other than AeroGrow International, Inc., or its designee. This warranty excludes all incidental or consequential damages.

WHAT AEROGROW WILL DO – AeroGrow International, Inc., at its option, will repair any defect in materials or workmanship or will replace this product with ones of similar features and price. AeroGrow International, Inc.'s sole obligation and your exclusive remedy under this warranty shall be limited to such repair or replacement.

TO RETURN THIS PRODUCT – For any questions or concerns, or for more information, visit our website at www.aerogarden.com. Our customer service representatives are available via Live Chat and Email. Please do not return any product without contacting AeroGrow for return authorization. Unauthorized returns, as well as C.O.D. shipments, will be refused. For more information regarding returns, please see the Returns section at www.AeroGarden.com

Due to continuing improvements, actual product may differ slightly from the product described herein. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. This warranty gives you specific legal rights, and you may have other legal rights that vary from state to state.



AeroGrow International, Inc., P.O. Box 18450, Boulder, CO 80308-1450
©2022 AeroGrow International, Inc. www.aerogarden.com XXXXX-XX
Designed in Boulder, CO. Made in China.



800302

Electrical Ratings:


Adapter: 100-240VAC 50/60Hz

Light Panel: 12VDC 1.2A



Tabletop Grow Light

Quick Start Guide



We Got What You Need!

Growing your favorite houseplant indoors has never been easier. With our innovative grow lights you can customize to your plants needs with our app.

Tabletop Grow Light

Assembly Instructions

- 1 Insert bottom of post into base. Turn base upside down and, using a phillips head screwdriver (not included), lightly screw in the post with the two screws provided. Do not overtighten.
- 2 Once installed, turn the base side up and screw the LED light hood into the top of the post. Tighten gently.
- 3 Connect the power cord adapter to the receiver at the bottom of the post and plug in to start your 10-hour ON light cycle.
- 4 Touch the top of the light hood to manually turn on/dim/off your light. For more custom features (like Light Modes, custom light schedule, and more), download the AeroGarden app on Apple or Google Play app stores.

TIPS and TRICKS

- 1 For best results, maintain about 4" of space between your hood and the top of your plant.
- 2 To reset your light cycle, unplug and plug back your grow light.
- 3 AeroGarden Grow Lights provide customization for your plants. Experiment with light cycles, color modes, and dimming levels that work for you and your plants.
- 4 To reset the light cycle, unplug and plug back in your grow light. Wink, wink! you can unlock full customization using the AeroGarden App.



Additional Settings on your App:

- Easy on/off
- Customizable 0-100% dimming
- Customizable on/off light schedule, including adjustable length of ON time
- Customizable sunrise/sunset setting that provides a gentle dimming of your grow light to simulate sunrise and sunset
- 4 light modes to choose from: full spectrum, white, warm, and cool

What's Included

- LED light hood
- Post
- Power cord & adapter
- Metal base
- (2) screws

Not included: phillips head screwdriver



Good to Know

- Connect your grow light to the AeroGarden app (found on Apple and Google Play app stores) to unlock additional features.
- Your grow light will start its Light ON cycle the moment it is plugged in
- Preset light cycle is 10 hours ON and 14 hours OFF in a 24 hour cycle, turning on at the same time every day. More customization in the app.
- Your grow light's post is about 24 inches long when fully extended
- To avoid damage, do not collapse or extend your post by pulling or pushing by the LED hood