



CAUTION: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.



Diagram illustrating the controls of the JBL Tune 510BT remote control:

- MICROPHONE
- LED INDICATOR LIGHT
- (1) NEXT SONG / VOLUME UP
- (2) POWER/PLAY BUTTON
- (3) PREVIOUS SONG / VOLUME DOWN
- MICRO-USB CHARGE INPUT

Bluetooth® Wireless Earbuds

FEATURES

- Works with most Bluetooth®-enabled smartphones and devices.
- Stream audio wirelessly via Bluetooth technology in high quality from up to 33 ft. away.
- Integrated rechargeable battery provides hours of playing time wherever you go.

CONTENTS	SPECIFICATIONS
<ul style="list-style-type: none"> - Wireless Earbuds with Mic (2) - 1 USB Charging Cable - 1 User Manual 	<ul style="list-style-type: none"> - Power: Internal Polymer Lithium battery - Wireless Capability: Up to 33 ft range
	<ul style="list-style-type: none"> - Driver Unit: 10 mm - Frequency Response: 20Hz - 20KHz - Sensitivity: 95dB ±5dB - Impedance: 16 ohms

The internal battery must be fully charged before first use of the wireless earbuds. To charge, use the included USB charge cable.

1. Insert the smaller micro-USB end of the cable into the CHARGE INPUT on the earbud unit.
2. Insert the larger USB end of the cable into the USB port of a computer OR into a compatible USB DC wall charger (not included) to charge through a standard wall outlet. The indicator lights up red during charging and will turn blue when charging is complete. Unplug from the power source when charging is complete.

NOTE: When battery power is low the LED may blink red and/or there may be an alerting sound, even when music is playing. Fully charge the battery as advised above to resume normal operation.

WIRELESS CARBONATION OPERATION
Wireless Playback Via Bluetooth
 Make sure the battery is charged as explained above.

2. On the controller, press and hold the button (2) until the indicator light flashes blue and red - this means the Bluetooth function is active and ready to connect to your smartphone/Bluetooth audio device. NOTE: If you do not connect the earbuds with a Bluetooth device after 5 minutes of being turned on, the earbuds will turn off automatically. Restart this step to try to connect again.
3. Turn on your smartphone/Bluetooth audio device. It should automatically recognize the earbuds unit and allow you to select it using the name "Tm Bluetooth". If required, enter the password "0000" to complete the wireless connection. When the earbuds are connected, the indicator light on the controller will flash blue and you are set to enjoy wireless audio from within a 33ft range of the audio device.
4. Before playback, first adjust the volume of your audio device to medium level as a safe starting point.

6. To go to the next song, press button (1) once.
 7. To go to the previous song, press button (2) once.
 8. To decrease the volume, click and hold button (3). To decrease the volume, click and hold button (3). The earbuds make a chime sound when they reach maximum volume. You may then adjust the volume or use audio device to make it even louder or softer as you please.
 9. To answer an incoming call, click the ear button (2) once.
 10. To hang up a phone call, click the button (2) once.
 11. To disconnect and shut off the earbuds unit, press and hold the button (2) until the indicator light goes out.
- NOTE:** Low earbuds power and/or low audio device power may cause poor operation and/or no Bluetooth connection.
- CAUTION**
- This is not a toy. Please keep away from small children.
 - Please turn the unit away from water and heat.

- This is not a toy. Please keep away from small children.
- Please keep the unit away from water and heat.
- Do not use indoors, the house.

TECHNICAL SUPPORT

Please do not attempt to fix the product yourself. If you are experiencing any problems with the product, please do not return the product to us. You can contact our technical support representatives and they will assist you with any questions you may have. For assistance operating your product, please consult the User's Manual or feel free to contact World's technical support:

World LLC 45 West 20th St., 11th Floor New York, NY 10011, USA	www.worldinc.com email-support@worldinc.com Please keep instructions for further reference.
--	---

© 2008 World LLC. Trading only.

The Bluetooth® word mark and logo are registered trademarks owned by Bluetooth SIG, Inc., and any of these marks by World LLC under license. All other trademarks and trade names are those of their respective owners. Actual product may differ slightly from image shown.