


FRONT

IJOY

WATERPROOF BLUETOOTH SPEAKER HYDRO
FCC ID:2AJQ7HYDRO



USER MANUAL

for use with **Bluetooth®** enabled devices

YOUR PRODUCT

Thank you for purchasing and using the "IJOY HYDRO" wireless speaker. This product can provide a high quality listening experience through phones, computers, and multimedia. Before using this product, carefully read this manual to in order to operate at maximum benefit. Please ask your local dealer or call us if you have any questions

PACKAGE CONTENTS

IJOY Hydro Speaker x1
Type-C Charging Cable x1
Strap x1
User Manual x1

PAIRING YOUR PRODUCT

1. Place speaker within 30ft of the Bluetooth-enabled device.
2. Press the ON/OFF button to ON. The blue LED flashes quickly to indicate Bluetooth pairing mode.
3. Follow the instructions of your device to search for the speaker.
4. The speaker is called "IJOY HYDRO". If a PIN is required, enter "0000."
5. The blue LED will stay on when pairing is complete.

BATTERY CAUTION

The battery used in this device may present a risk of fire, explosion or chemical burn if used incorrectly. Never use or charge the battery if it appears to be leaking, discolored, deformed, or in any way abnormal. Never disassemble the unit or attempt to remove the battery as that could cause leakage of alkaline solution or other electrolytic substance. Always confirm that the temperature is 5 degrees Celsius before you change the battery. Never expose the battery to any liquid. Never expose the battery to excessive heat such as direct sunlight or fire. Never use the battery pack in an unventilated vehicle where excessive internal temperatures may be encountered. Always keep the battery out of reach of infants and small children.

BATTERY DISPOSAL

Please do not attempt to change the battery yourself. If the battery has died and you do not want us to replace your battery, you should follow the disposal instructions listed here. Never dispose of used batteries/electronics with ordinary solid wastes. Always dispose of used batteries/electronics in accordance with the prevailing community regulations that apply to the disposal of batteries/electronics. If there are no local regulations concerning battery/electronics disposal, please dispose of the device in a waste bin for electronic devices. Many electronics retailers now recycle batteries and other electronic components at no charge.

FCC STATEMENT

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.


Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

BACK

DEVICE FUNCTIONS



ON/OFF , FM Station
Previous Track/Decrease Volume
Next Track/Increase Volume
Play/Pause/Answer/Call/End Call

LED INDICATOR

Charging: Red LED on
Fully Charged: Red LED off
Pairing Mode: Blue LED flashes quickly
Connected: Blue LED stay on
Playing: Blue LED flashes slowly
FM mode: Blue LED flashes slowly

OTHER IMPORTANT SAFETY INFORMATION

Disposal of old electrical & electronic equipment (Applicable in the European Union and other European Countries with separate collection systems.) The trash can symbol (seen on bottom right) on the product or on its packaging indicates that this product shall not be treated as household waste. Instead it shall be handed over the the applicable collection point for recycling of electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health which could otherwise be caused by inappropriate waste handling. For more detailed information about this product, please contact your local household waste disposal service or the shop where you purchased this item.

IMPORTANT REMINDERS

This device can ONLY be charged by 5V adapters/USB ports only. Quick charging devices over 5V may cause heat and fire.



INSTRUCTIONS

- 1) Long Press **O** button to turn on/off the speaker.
- 2) Double press to switch FM mode.
- 3) Press **▶** button to pause/resume playback, answer incoming phone call / end phone call.
- 4) Long press **▶** button to reject incoming call.
- 5) Double quick press **▶** button to redial the last number dialed.
- 6) When in FM mode, long press **▶** button to search station.
- 7) Long Press **—** button to decrease volume.
- 8) Press **—** button to skip to the previous track, or skip to previous station when in FM mode.
- 9) Long Press **+** button to increase volume. Press **+** button to skip to the next track, or skip to next station when in FM mode.

SPECIFICATIONS

Output Power: 3W*1
Driver: ϕ 45*1
Power Supply: DC 5V \approx 1A
Battery Capacity: 1200mah
Playtime: 4 hours for 50% volume
Battery Charging time: About 2-3hour

ONE (1) YEAR LIMITED WARRANTY

Our product is warranted for a One (1) year limited warranty from the date of purchase. The warranty is provided on all material defects and workmanship. Guarantee of 12 months does not apply to decrease in the accumulator's effective capacity caused by its use or age. Effective capacity gradually decreases depending on the method of use of the accumulator. **WE RESERVE THE RIGHT TO CHANGE TECHNICAL SPECIFICATIONS.** For more information please visit, www.goijoy.com

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by QUEST USA CORP. is under license. Other trademarks and trade names are those of their respective owners.

DISTRIBUTED BY QUEST USA CORP.
495 Flatbush Ave Brooklyn, NY 11225

© QUEST SPORT is registered trademark of QUEST USA CORP.
All other trademarks and trade names are property of their respective owners.

Designed by QUEST USA CORP in New York. All rights reserved QUEST USA CORP.
Brooklyn, NY. Limited lifetime warranty. To activate your product warranty go to our website www.goijoy.com & register this product.

Made in China.

FOLD

**ATTENTION VENDOR: PLEASE FOLD ON GREEN LINES AND PRINT DOUBLE SIDED
DO NOT PRINT GREEN LINES WITH MANUAL**