



ROCK SPEAKER SET



USER MANUAL

FCC ID: 2AJQ7ROCK
MODEL: IJ18RCKSPGY-VW

for use with
 enabled devices

•YOUR IJOY PRODUCT

Thank you for purchasing and using the "IJOY ROCK" speaker set. This product can provide a high quality listening experience through phones, computers, and multimedia, charge your devices and takes selfies for that unforgettable moments. Before using this product, carefully read this manual to in order to operate at maximum benefit. Please ask your local dealer or call us if you have any questions.

•PACKAGE CONTENT

1. IJOY ROCK Speaker x2
2. User Manual
3. Micro USB Charging Cable
4. 3.5mm AUX cable

•FEATURES AND SPECIFICATIONS

With TWS function
IPX4 water resistance
AUX in function supported
Output Power: 5W
Frequency Response: 100Hz-20Khz
Power supply: USB, DC 5V 500mA
Distortion: < 1%
S/N: > 75dB
Battery Capacity: 1800mAh
Battery Play Time: 3-4 hours
Battery Charging Time: 2-3hours
Product Size: 220 x 230 x 250mm
Product Weight: 1840g

Distributed by
Quest USA Corp.
495 Flatbush Ave Brooklyn, NY 11225

© GOIJOY & IJOY are registered trademarks of Quest USA Corp. All other trademarks and trade names are property of their respective owners. Designed by GOIJOY & IJOY in New York. All rights reserved Quest USA Corp.

Made in China.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by QUEST USA CORP. is under license. Other trademarks and trade names are those of their respective owners.

•SAFETY INFORMATION

Do not leave this product unattended while connected to the power supply. Keep the unit away from heat sources.
Do not use the unit if it has been dropped or damaged in any way. Repairs to electrical equipment should only be performed by a qualified electrician.
Improper repairs may place the user at serious risk. Do not put objects into any of the openings.
Do not use this unit for anything other than its intended use. Keep the unit out of reach of children.
This appliance is not a toy.
Do not use the handset at excessive levels as damage to hearing may occur. Batteries (battery pack or batteries installed) shall not be exposed to excessive heat such as sunshine, fire etc.

•CHARGING THE SPEAKER

Before using it for the first time we recommend you charge the battery fully. 1. To charge the Bluetooth speaker, connect the supplied micro USB cable to the USB charging port and the other end to your computer or USB charging device.

2. The led indicator will be turn red while charging. Once fully charged, the red led will turn off.

•SINGLE PAIRING THE BLUETOOTH SPEAKER WITH DEVICE

1. Turn on the bluetooth speaker.
2. Open Bluetooth function on your device and search for "IJOY ROCK".
3. If a PIN is required, enter the password 0000' to confirm to finalize pairing.
4. Connect it with your bluetooth enabled device.

•TWS PAIRING THE BLUETOOTH SPEAKER WITH DEVICE

1. Turn on both bluetooth speakers.
2. Make sure both speakers are without paired any device, short press "POWER" button twice on each of two Bluetooth speakers, then both speaker will be automatically connected, once paired successfully, you will hear an indication tone.
3. Open Bluetooth function on your device and search for the Bluetooth device, only one "IJOY ROCK" will be show up in the list instead of two. Pair it with this device.
4. If a PIN is required, enter the password 0000' to confirm to finalize pairing.
5. Connect it with your bluetooth enabled device.

•OTHER IMPORTANT SAFETY INFORMATION


Disposal of old electrical & electronic equipment (Applicable in the European Union and other European Countries with separate collection systems.) The trash can symbol (seen on bottom right) on the product or on its packaging indicates that this product shall not be treated as household waste. Instead it shall be handed over to the applicable collection point for recycling of electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling. For more detailed information about this product, please contact your local household waste disposal service or the shop where you purchased this item.



IMPORTANT REMINDERS

This device can ONLY be charged by 5V adapters/USB ports only. Quick charging devices over 5V may cause heat and fire.

•SPEAKER BUTTON FUNCTIONS



1	Speaker
2	LED Indicator: Blue light flashing: searching for bluetooth signal Blue light solid: Bluetooth connected Red light: charging
3	POWER ON/OFF Switch: Press to turn on the speaker; Press again to turn off the speaker While you playing music, short press to pause it; short press again to resume the music
4	Micro USB Charging Port
5	3.5mm AUX port

•BATTERY DISPOSAL

Please do not attempt to change the battery yourself. If the battery has died, you should follow the disposal instructions listed here. Never dispose of used batteries/electronics with ordinary solid wastes. Always dispose of used batteries/electronics in accordance with the prevailing community regulations that apply to the disposal of batteries/electronics. If there are no local regulations concerning battery/electronics disposal, please dispose of the device in a waste bin for electronic devices. Many electronics retailers now recycle batteries and other electronic components at no charge.

•BATTERY CAUTION

The battery used in this device may present a risk of fire, explosion or chemical burn if used incorrectly. Never use or charge the battery if it appears to be leaking, discolored, deformed, or in any way abnormal. Never disassemble the unit or attempt to remove the battery as that could cause leakage of alkaline solution or other electrolytic substance. Never expose the battery to any liquid. Never expose the battery to excessive heat such as direct light or fire. Always keep the battery out of reach of infants and small children.

Note: Battery life & charging time may vary, based on usage & types of devices used. The product design and specifications may be changed subject of without prior notice!

•FCC ID STATEMENT

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.