

7. Reminder



You can define Caring Reminder to remind yourself time for Sport, Sleep, Event or Dining in the Archon app. Press "+" to add new reminder, after selecting reminding time, turn it on and press save to enable Sync to the Archon Touch. If your mobile is not connected to your Archon Touch, a pop-up screen will appear to request you to link up with your Archon Touch, once Synchronize, reminding time will be saved to the Archon Touch. Archon Touch will vibrate gently and display your input reminder icon to alert you.

8. OTA UPGRADING



Archon Touch support OTA upgrade through Archon App and an upgrading icon will appear on your Archon Touch. If upgrade is successful, your Archon Touch will restart and display time, date and battery status.

9. Goals Achievement

ACHIEVED



If you reach 10,000 steps daily, Archon Touch will vibrate and display achievement icon. You can set your own target in the App.

10. Safety and Care

- Do not use device in the environment of too high or too low temperature, please don't expose the device under strong sunshine or humid environment. The suitable temperature for the device and accessories is 0°C - 45°C.
- Keep the Archon Touch away from fire or any objects that may cause damage or scratch.
- Please do not attempt to repair, modify or disassemble the Archon Touch.
- Please clean the strap by water periodically, do not use abrasive cleanser that may damage the strap.
- Please use the charging clip included in the package to charge the Archon Touch.
- The Archon Touch is IP67 water resistant. Do not bath, shower, swim, dive or go to sauna or steam room with the device.

11. Reset

If you have problem with your Archon Touch or it does not function properly, you can try to reset. When your Archon Touch is in charging condition, insert a small pin into the hole of the charging clip and push to reset.



12. Specifications

Feature	
Model	AT-01
Color	Black/Blue/Green/Pink/Orange/Purple
Display	OLED
Battery Type	Lithium-ion polymer
Battery Capacity	55 mAH
Battery life for working	4-5 days
Water resistant	IP67
Connectivity	Bluetooth smart 4.0 LE
Storage temperature	-20°C to 60°C
Operation temperature	0°C to 45°C
Reminder	Support
Charger	Clip-on-charger 5V (micro-USB)

13. Frequent Question and Answer

Q1. Why my Archon Touch does not show any display out of the package?

The Archon Touch battery maybe empty out of the package, so you have to charge up the Archon Touch before use. Please align the charger positioning pin correctly or otherwise your Archon Touch may be damaged.

Q2. Should I use portable charger (power bank) to charge up my Archon Touch?

No. The current draw for charging the Archon Touch is low and portable charger may recognize it as fully charged, as a result, the Archon Touch can't be charged. We recommend plugging the charging cable to the USB port of your computer or a certified USB wall charger (5V).

Q3. Can I swim, bath or shower with my Archon Touch?

No. Archon Touch is IP67 dust resistant and water resistant but not waterproof. It is protected against wash splashes and raindrops, but not suitable for shower, bath or swim. Do not wash with a pressure washer.

Q4: Why Bluetooth connection to the Archon Touch failed?

Please check if your mobile phone and operating system fall within the range of compatibility range, see point 3. Sometimes, the Bluetooth connection may fail due to mobile phone Bluetooth operation, please turn off the Bluetooth and turn on again, or switch off the phone and on again. Retry Bluetooth connection.

14. Warranty

Original purchaser of any Archon Fitness Wristband can obtain 1 year warranty service from Archon or Distributor starting from the date of purchase. Original purchaser must deliver the faulty product in its original package or packaging with equal degree of protection together valid invoice to address specified by Archon. Details please refer to Archon website.

[www.archonglobal.net \(INTERNATIONAL\)](http://www.archonglobal.net)
[www.archon.com.hk \(HONG KONG\)](http://www.archon.com.hk)

What is not included in Limited Warranty?

- Built-in batteries.
- Aesthetic damage where it does not affect the operation or safety of the product.
- Repair costs that have not been approved.
- Damage or breakdown due to flood, wind or other severe weather conditions.
- Damage or breakdown due to fire or any natural disaster.
- The cost of repairing or replacing a product which fails because anyone neglects, abuses or misuses the product.
- The cost of repairing or replacing a product which has been exposed to insect infestation (or similar phenomenon) or human or animal fluid/matter.
- Software or data.
- Cost of Data Recovery.



The symbol on the product or its packaging indicates that this product must not be disposed of with your other household waste. Instead, it is your responsibility to dispose of your waste equipment by handing it over to a designated collection point for the recycling of waste electrical and electronic equipment. The separate collection and recycling of your waste equipment at the time of disposal will help conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment.

For more information about where you can drop off your waste for recycling, please contact your local authority, or where you purchased your product.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct

the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

TERMS OF USE AND DISCLAIMER

Unless otherwise specifically and expressly stated elsewhere, Archon hereby disclaims all warranties, including without limitation all warranties of merchantability, fitness for a particular purpose, title and non-infringement, and any warranties arising out of course of dealing or usage of trade, whether such warranties are express, implied or statutory. The Archon product, content and Archon service are provided "as is," without warranty of any kind.

Archon shall not be liable for (1) any inaccuracy, failure of or error in the product and software; (2) any loss or damage (including without limitation any direct, indirect, incidental, consequential, special or exemplary damages) arising from any download or use made of the software, or occasioned by any such inaccuracy, error or failure of the software.

We make no warranty that the Archon product, content or Archon service will meet your requirements or be available on an uninterrupted, secure, or error-free basis. We make no warranty regarding the accuracy, quality, timeliness, completeness, truthfulness or reliability of the Archon product, service or any Archon content. You acknowledge and agree that if you rely on any Archon product, content or the Archon service, you do so solely at your own risk.

If you are dissatisfied with any of the product, content, service or other contents of the Archon sites or with these terms and conditions, your sole remedy is to discontinue use of the Archon product, sites, content and service. In no event will Archon or any third parties mentioned at the Archon sites be liable for any damages whatsoever (including, but not limited to, incidental, exemplary, and consequential damages, lost profits, or damages resulting from business interruption or lost data) resulting from the use or inability to use the Archon sites and the content, whether based on contract, warranty, tort, or any other legal theory, and whether or not Archon

is advised of the possibility of such damages.

Archon makes no representations or warranties about the accuracy, reliability, completeness, or timeliness of the content or about the results to be obtained from using the archon product, service and content. Any use of the Archon product, service and content is at your own risk. Changes may be made to Archon sites at any time. Some content on the Archon product, service and sites may be provided by third parties and Archon will not be held responsible for any such content provided by third parties.

Archon does not warrant that the Archon sites will operate error-free or that the Archon sites or their servers are free of computer viruses or other harmful goods. If your use of the Archon sites or the content results in the need for servicing or replacing equipment or loss of profits or data, Archon will not be responsible for those costs.

You agree to comply with all applicable laws when using Archon product, content and service, and you will only use them for lawful purposes.

If any provision of these terms and conditions is held to be invalid or unenforceable, such provision shall be removed and the remaining provisions shall be enforced to the fullest extent under law. Archon's failure to enforce any right or provision in these terms and conditions shall not constitute a waiver of such right or provision unless acknowledged and agreed to by Archon in writing.

ACCOUNT

Full use of the Archon product, content and service requires that you register an account and agree to provide us with a valid email address and strong password. You are responsible for all activity that occurs in association with your account. Archon is not liable for any loss or damages caused by your failure to maintain the confidentiality of your account credentials.

You agree not to impersonate any person or entity or misrepresent your identity or affiliation with any person or entity, including using another person's username, password or other account information, or another person's name, likeness, voice, image or photograph.

You might authorize us to send status updates to your Facebook or Twitter account. Once you direct us to share your data with a third party, that data is governed by the third-party's privacy policy.

Designed by:

Millennium Pacific Concept Limited

INTERNATIONAL

www.archonglobal.net
info@archonglobal.net

HONG KONG

www.archon.com.hk
info@archon.com.hk

Made in China

Version: AT-01 V03