

ITgut Diamond

Quick Start Guide

Thank you very much for being an ITgut Diamond owner. Enjoy listening to your music, videos and games on your speaker , playing wirelessly from your bluetooth device. Supported bluetooth devices include: smartphones, iPhones, iPads and tablets.

This Quick Start Guide includes information on:

- What's included in the pakage
- The buttons & connectors
- Charging the battery
- Pairing & connecting the ITgut Diamond to your bluetooth device
- Connecting to laptops, computers and non- bluetooth device using AUX-IN
- Wireless hands-free personal speakerphone
- Ip5-5 water resistance

In the Pakage

- 1- ITgut Diamond
- 1- Micro-USB charging Cable
- 1- 3.5mm Audio Cable
- 1- Quick Start Guide

Wireless Hands-Free Speakerphone

Make sure your ITgut Diamond has sufficient Charge or connect to a Charging source. Plug one end of the included 3.5mm audio cable into the AUX-IN port on the back of the speaker and plug the other end into the headphone/audio jack on your audio source.

jack(10) on the back of the speaker and plugging the other end into the source. Note: the Play/Pause Button will serve as a Mute/Un-Mute button in AUX-IN mode.

Wired Hands-Free Speakerphone

Jack(10) on the back of the speaker and plugging the other end into the headphones/jack on your audio source.

When connected by Bluetooth to a smartphone the ITgut Diamond will have Wireless Hands-Free speakerphone enabled.

When connected by Bluetooth to a smartphone the ITgut Diamond will have Wireless Hands-Free speakerphone enabled.

Importtant: The ITgut Diamond cannot withstand being dropped into water or being submerged in water or being partially or fully submerged in water or being设计 to handle splash or spray. It is also dust and sand proof. The speaker making it splash proof and rain proof. The speaker is designed to handle shower spray or splash. It is also dust and sand proof.

The ITgut Diamond is IPX5 water resistant:

Importtant: The ITgut Diamond cannot withstand being dropped into water or being submerged in water or being partially or fully submerged in water or being

The Buttons & connectors

1. **On/Off Button** for speakerphone

2. **Pair Device** Button

3. **Pause/Play Button** - Press and release the button to Pause and resume your music

Note: Pause/Play Button may not function with some source devices and music app


4. **VOL + Button**- Press and hold down or press multiple times to increase the volume. note: ensure your source device volume is turned up high

5. **VOL-Button**- Press and hold down or press multiple to decrease the volume


6. **Charge port**

7. **AUX IN Jack**(under the black rubber flap)

top of the flap is attached to the speaker.



- 1: On/Off
- 2: Pair Device
- 3: Play/Pause
- 4: Volume up
- 5: Volume down
- 6: Charge port
- 7: AUX in



Charging the Battery

Plug the micro connector end of the micro USB cable into the **Micro USB Charging Port**.

Plug the other end of the cable into either a USB wall charger for a smartphone or iPhone, or your computer. When charging, the **Charging Indicator Light** will flash red, slowly.

When fully charged the light will turn solid red.

The speaker will take about 5 to 6 hours to fully charge.

Charging to another Bluetooth Device

The ITgut Diamond can connect to and play from one Bluetooth Device at a time. To change to a different Bluetooth Device : Press and hold down the **Bluetooth button** for three seconds to enter pairing mode and the **Bluetooth indicator Light** will flash blue. You can then Pair and connect to the next device.

Important: The ITgut Diamond will automatically try to pair to the last device it was connected to when the speaker is turned on, and that device is within range. If the ITgut Diamond does connect to the last device, the indicator light will be solid blue and you can play. In order to connect to a different device, Press and hold down the **Bluetooth button** for three seconds to enter pairing mode and the **Bluetooth Indicator Light** will flash blue .

Pairing & Connecting the ITgut Diamond to your Bluetooth device

Make sure your IT gut Diamond has sufficient charge or connect to a charging source. Pair and connect wirelessly to your Bluetooth device by following these steps:

Step 1 - Turn on the speaker by pressing and releasing the **ON/OFF Button**. the **Bluetooth Indicator Light** on the side of the IT gut Diamond will flash blue. This indicates that the speaker is in Pairing mode and is ready to pair and connect to your device.

Step 2 - Enable the Bluetooth function on your device and then search/scan for the IT gut Diamond When ITgut Diamond appears on the bluetooth device list, select it and your device will pair and connect to the speaker. Make sure your device indicates that it is connect to ITgut Diamond in your device list. If your device requests a password, enter

Step 3 - The **Bluetooth Indicator Light** Will turn solid blue to indicate the ITgut Diamond is paired and connected to your device. You can now play wirelessly from your device.

you can adjust the speaker volume from your device and the **VOL + Button** and the **VOL - Button** on the speaker .

Important: to reach high volume make sure the volume on your device is set high and the ITgut Diamond volume is set high.

Note: you can play wirelessly to your speaker up to 30 unobstructed feet away from your device

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.