


Smart Leather Products User Manual

Power On/Off


1. Charge the smart leather products to activate it. It is necessary to charge full at the first time.

2. Open the bluetooth of your cellphone at the setting menu.

3. Power on/off

Power on: Press and hold the power button  on the smart leather product about five seconds until you hear the beep twice.

Power off: Press the power button  about five seconds on the smart leather product until long "beep" sound.



Connect the smart leather product


APP will connect to the smart leather product automatically. If brown button  appears, cellphone has connected with the smart leather product. If APP just display the  button, it means that cellphone has not connected with smart leather products, please click the button  to connect it.

If you open APP, it does not display any icon on the screen of cellphone, please click on the  on upper right corner to search for the smart leather product automatically.

Click the "" button, the smart leather product will ring to indicate that it can work normally.


Smart Find

1. Find the smart leather product: Click the , the cellphone will ring to indicate that where it is.

2. Find the cellphone: Double click the power button  on the smart leather product, the cellphone will ring to let you know where it is.


2-way Anti-lost

If you leave your smart leather products behind, your cellphone will ring to let you know. If you leave your cellphone behind, your smart leather products will beep to let you know. When the cellphone alert, the following red icon will appear, you can click it to close the ring of cellphone. You can also cancel the alerting by clicking on the button of smart leather product.




Location

As shown in the image:



Location list: when you park your car, press the button on smart leather product, it will mark your current location on the map. Press the "Location list" and you will find where your vehicle is with easy tracking when you leave any big or underground parking lot.




Lost history: If the smart leather product is lost, a pin-drop will be marked automatically on map to tell you the site it was lost. Press "lost history" to find the record.

Remark: To delete the list, just scroll left the list and press the "Delete" menu.

Photograph

As shown in the image:



Press the "photograph" button, it will turn to camera mode.

1. Press top right and left to set the flashlight and camera.

2. Press the button on the right button, you can set for burst shooting and interval timer shooting.

Press the button on smart leather product once, it works as remote shutter to take photos.

Do Not Disturb Mode

There are two Do Not Disturb Mode, one is Do Not Disturb Mode (22:00-7:00) at rest time (it is opened default), the other is normal Do Not Disturb Mode. On the "Setting" interface, switch on "Do not disturb", alert function of the smart leather product will be shut down. When on "Do Not Disturb (22:00-7:00)", alert function will be shut down at time 22:00-7:00.

As shown in the image:

Map switch: choose Google map or Baidu map.

Double click setting: setting for alarm or voice recording.

Record list: The recorded voice would be stored under this state.

Simply press Play button to play/pause and scroll left the list to delete it.

Version: Version of current App

Smart Led Light

NO.	Function and Status	Using methods and status instruction
1	Red Led light	Charging
2	Red Led light	Battery need to charge at once

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To assure continued compliance, any changes or modifications not expressly approved by the party.

Responsible for compliance could void the user's authority to operate this equipment. (Example- use only shielded interface cables when connecting to computer or peripheral devices).

This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.