


FCC ID: 2AK9F-90137

TIT02 Smart Watch  
Operation Manual



Thanks for purchasing this product.  
Please read this Manual carefully before use.

Quick Start

1. Know the Device



Physical Button

Press the physical button

1. Turn off screen on the "ScreenOff" interface

2. Turn on screen when screen is off

3. Turn on screen on the "On" interface

2. Power On/Off

Power On

When you start charging the device, it will be turned on automatically.



Power Off

Press and hold the physical button to turn off the device.



Press and hold the physical button to turn off the device.

Downloading and Pairing

1. Download the APP


Scan the following QR code to download "Titan Smart" or search the app and download "Titan Smart" in "App Store" on your phone.



2. Pairing

Scan QR on the left and Bluetooth. Search and select the device in the app.

Finally, bind the device in the APP.




Screen Operations

Swipe the screen up/down

1. To select settings page at the same level, or

2. To view long text or details.



Swipe the screen left/right

1. To select settings page at the same level, or


2. To view long text or details.



Click the screen

1. To go to the next page.

2. To complete the corresponding action (depending on which screen button is clicked).



Click and hold the screen

1. To change the watch face wallpaper.



Model

W10

Screen Type

IPS TFT-LCD

Battery Capacity

300mAh

Charging Voltage

5V/0.2A

Charging Time

2 hours

Battery Life

7 Day

Waterproof Rate

5ATM

Weight of Product

46g

Operating System

Android

Bluetooth Version

4.2

Product Frequency

2400-2480MHz

Bluetooth Version

4.2

Functions

Supporting features such as: multiple exercise modes, remote health, weather, sports, heart rate, breath training, heart rate monitoring, sleep monitoring, stress level, etc. For functions, please refer to the user manual, or refer to the instructions and FAQs for the functions, open the app to access the user guide for details.

Maintenance

1. Please do not use the device in the rain or in the water.

2. Please do not use the device in the rain or in the water.

3. Please do not use the device in the rain or in the water.

4. Please do not use the device in the rain or in the water.

5. Please do not use the device in the rain or in the water.

6. Please do not use the device in the rain or in the water.

7. Please do not use the device in the rain or in the water.

8. Please do not use the device in the rain or in the water.

9. Please do not use the device in the rain or in the water.

10. Please do not use the device in the rain or in the water.

Safety

1. Please do not use the device in the rain or in the water.

2. Please do not use the device in the rain or in the water.

3. Please do not use the device in the rain or in the water.

4. Please do not use the device in the rain or in the water.

5. Please do not use the device in the rain or in the water.

6. Please do not use the device in the rain or in the water.

7. Please do not use the device in the rain or in the water.

8. Please do not use the device in the rain or in the water.

9. Please do not use the device in the rain or in the water.

10. Please do not use the device in the rain or in the water.

名称	TIT02说明书	材质	105g铜板纸
尺寸	70x120mm	装订方式	风琴折
颜色	四色 双面	公差	+/-0.5mm
版本号	4.SM.TIT02XX000 V1.0		