

A QUICK LOOK AT THE SC L



THIS DEVICE COMPLIES WITH FCC RULES PART 15. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS:

- THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE.
- THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRED OPERATION.

FCC CAUTION

ANY CHANGES OR MODIFICATIONS NOT EXPRESSLY APPROVED BY THE PARTY RESPONSIBLE FOR COMPLIANCE COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

THE ANTENNA(S) USED FOR THIS TRANSMITTER MUST NOT BE COLOCATED OR OPERATING IN CONJUNCTION WITH ANY OTHER ANTENNA OR TRANSMITTER.

MAIN OPENING A CLOSER LOOK AT THE MAIN OPENING



Radiation Exposure Statement:
This equipment must be installed and operated in accordance with provided instructions and the antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter.

POWERING UP

CONNECT THE SMART BATTERY TO THE CASE



UNZIP THE SMART BATTERY POCKET. INSIDE YOU WILL SEE A BLACK BOX (USB HOLDER). OPEN THE USB HOLDER AND INSIDE YOU WILL FIND 3 USB CABLES AND 1 MICRO USB CABLE. CONNECT THE YELLOW USB CABLE TO THE USB PORT WITH THE YELLOW RING AROUND IT. INSERT THE REMAINING 2 USB CABLES AND MICRO USB CABLE TO THE PORTS. AFTER CONNECTING THE USB CABLES TO THE USB PORTS, CLOSE THE USB HOLDER AROUND THE BASE OF THE POWER BANK AND PLACE IN THE SMART BATTERY POCKET THE ZIP POCKET CLOSED. ONCE THE USB CABLES ARE CONNECTED, THE BREATHING LIGHTS ON THE NAMEPLATE WILL FLASH.

10 YEAR CLOUD PROTECTION* TERMS AND CONDITIONS

VIRTUAL WORLD WIDE 10 YEAR CLOUD PROTECTION
YOU ARE COVERED WORLD WIDE WITH OUR 24 HOUR 10 YEAR CLOUD PROTECTION



NEVER CALL TO BE PLACED ON HOLD AGAIN



NEVER WASTE YOUR TIME BY DRIVING TO A REPAIR CENTER AGAIN



NEVER PAY FOR REPAIR AGAIN**



SELF REPAIR YOUR LUGGAGE WITHIN 5 MIN

** EXCLUDING AIRLINE ABUSE, MISHANDLING, AND NORMAL WEAR AND TEAR.

ACCESSORIES

ACCESSORIES THAT ARE INCLUDED



SMART BATTERY
USE THE SMART BATTERY TO SUPPLY POWER TO THE SC L IN ORDER TO USE ALL OF ITS REVOLUTIONARY FEATURES.



MICRO USB CABLE
USE THE MICRO USB CABLE TO CHARGE THE SC L THROUGH THE NAMEPLATE OR DIRECTLY TO THE SMART BATTERY.



3 PACKING CUBES
USE THE PACKING CUBES TO ORGANIZE AND SAFELY PACK YOUR ITEMS IN THE SC L.



SIGNATURE COVER
USE THE SIGNATURE COVER TO PROTECT THE FINISH OF THE SC L.

10 YEAR CLOUD PROTECTION* TERMS AND CONDITIONS

SC L WORLD WIDE 10 YEAR CLOUD PROTECTION


THE SC L COMES WITH A WORLD WIDE 10 YEAR - 24 HOUR SELF REPAIR CLOUD PROTECTION THAT IS EFFECTIVE FROM THE DATE OF PURCHASE. SC L IS COVERED BY THE TERMS AND CONDITIONS OF THIS WARRANTY. WITH OUR 10 YEAR CLOUD PROTECTION WE COVER REPAIRS TO YOUR LUGGAGE IN THE UNLIKELY EVENT OF MANUFACTURING OR WORKMANSHIP DEFECTS. HOWEVER, CLOUD PROTECTION DOES NOT COVER ANY DAMAGES CAUSED BY AIRLINE ABUSE, MISHANDLING, OR NORMAL WEAR AND TEAR. TO RECEIVE CLOUD PROTECTION SERVICES AND DETERMINE YOUR COVERAGE ELIGIBILITY, PLEASE NOTIFY AN SC L™ REPAIR CENTER BY UPLOADING YOUR CLAIM DIRECTLY THROUGH THE APP TO REPORT ANY DAMAGES THAT MAY HAVE OCCURRED. THE REPAIR CENTER WILL EVALUATE YOUR LUGGAGE AND DETERMINE IF IT IS DAMAGED, WEAR, OR DEFECTIVE, AND IF YOUR PRODUCT IS CURRENTLY UNDER WARRANTY. ALL CLAIMS MUST BE REPORTED IMMEDIATELY TO AVOID ANY FURTHER DAMAGES OR DELAY IN REPAIR.

TERRITORY COVERAGE

WARRANTIES APPLY TO ANY AND ALL MIA TORO PRODUCTS WORLD WIDE. FOR REPAIRS, FREIGHT IS INCLUDED ONLY FOR DOMESTIC SHIPPING FROM OUR CLAIM CENTER TO CUSTOMER OR REPAIR CENTER. SHIPPING FROM CUSTOMER OR REPAIR CENTER TO OUR CLAIM CENTER IS NOT COVERED. INTERNATIONAL FEES MAY VARY.

* ALL ELECTRONICS ARE COVERED FOR 1 YEAR.





SELF SCALE USING THE SELF SCALE

A TAP THE SELF SCALE ICON TO VIEW THE WEIGHT OF YOUR CASE.

B REST THE CASE ON THE SIDE STUDS THEN TAP MIDDLE CIRCLE TO WEIGH.

STATUS LED LED INDICATIONS

A STATUS LED

1. POWER ON: BOTH THE RED AND GREEN LED WILL FLASH EVERY SECOND FOR 3 TIMES WHEN SYSTEM PLUGS INTO POWER BANK. AFTER 3 TIMES OF FLASHING, BOTH LEDS EXTINGUISH.

2. CONNECT TO APP: WHEN SYSTEM CONNECTS TO APP THEN BOTH STATUS LED LIGHTS IN BREATHING MODE EVERY 10 SECONDS.

3. BATTERY STATUS

I. BATTERY LOW AS BATTERY CAPACITY IS LOWER THAN 30% THEN THE RED LIGHT FLASHES EVERY ONE SECOND AND GREEN LIGHT EXTINGUISHES.

II. CHARGING: BOTH LEDS FLASH EVERY ONE SECOND.

III. BATTERY FULL AS BATTERY CAPACITY IS 100%, THE GREEN LIGHT LED FLASHES EVERY ONE SECOND AND RED LIGHT EXTINGUISHES.

4. AIR MODE: BOTH STATUS LEDS EXTINGUISH WHEN SYSTEM ENTERS "AIR MODE".

GETTING STARTED A QUICK LOOK AT THE APP

A HOME
B FEATURE NAME DISPLAY
C SLIDE MENU
D REMOTE UNLOCK
E CASE SELECTOR
F CONNECTED CASE

ALKALINE BATTERY A CLOSER LOOK AT THE FRONT POCKET

A UNZIP THE LINING ON THE SIDE OF THE CASE (MARKED IN RED). ONCE YOU UNZIP LINING YOU WILL SEE A BLACK BOX UNDER THE TOP HANDLE.

B ON THE BOTTOM OF THE BLACK BOX THERE IS A COVER FOR THE 3 AAA BATTERIES. SLIDE COVER TOWARD YOU TO OPEN AND INSTALL THE 3 AAA BATTERIES.

SELF SCALE USING THE SELF SCALE



A RESET WEIGHT TO ZERO.
B DISPLAY WEIGHT IN LBS OR KGS.
C SET AIRLINE RESTRICTION WEIGHT LIMIT.

10 YEAR CLOUD PROTECTION HOW TO SUBMIT A CLAIM THROUGH APP



A TAP ENTRY FIELD TO PROVIDE ANY ADDITIONAL INFORMATION THAT MAY HELP US WITH THE PROBLEM YOU ARE EXPERIENCING.
B PROVIDE AN ADDRESS OF WHERE YOU WILL BE LOCATED FOR THE NEXT 7 DAYS. IF TRAVELING, PROVIDE A SECONDARY ADDRESS TO ALLOW FOR PROPER SHIPPING TIME ON REPAIRS.

SELF SCALE USING THE SELF SCALE



ONCE YOU REST THE CASE ON THE SIDE STUDS THEN TAP MIDDLE CIRCLE TO WEIGH THE APP WILL LET YOU KNOW IF YOU ARE OVER OR UNDER THE LIMIT THAT WAS SET.

A YOU ARE UNDER LIMIT IS INDICATED BY GREEN RING.
B YOU ARE OVER LIMIT IS INDICATED BY RED RING.

10 YEAR CLOUD PROTECTION HOW TO SUBMIT A CLAIM THROUGH APP



A TAP THE 10 YEAR CLOUD PROTECTION ICON IN THE SLIDE MENU IN THE EVENT YOU NEED TO MAKE A CLAIM.
B ONCE YOU HAVE TAPPED THE ICON IN THE SLIDE MENU YOU WILL HAVE THE OPTION TO REGISTER ADDITIONAL PIECES OR MAKE A CLAIM BY TAPPING THE 10 YEAR CLOUD PROTECTION ICON.

SELF SCALE SETTING WEIGHT LIMIT

10 YEAR CLOUD PROTECTION HOW TO SUBMIT A CLAIM THROUGH APP

A TAP THE TOP ENTRY FIELD TO ENTER THE WEIGHT RESTRICTION. THEN TAP ENTRY FIELD BELOW TO ENTER THE WEIGHT LIMIT.
B ONCE WEIGHT LIMIT IS CREATED YOU WILL SEE IT LISTED ON THE MAIN SCREEN.

A SELECT THE CASE YOU ARE MAKING A CLAIM FOR BY TAPPING ON THE CASE NAME.
B TAP CAMERA ICON TO TAKE AN IMAGE OF YOUR CLAIM TO BE SUBMITTED TO OUR CLAIM CENTER FOR EVALUATION.

SMART BATTERY POWER METER FOR THE SMART BATTERY

CASE PROFILE USING CASE PROFILE

A TAP THE SMART BATTERY ICON TO VIEW THE REMAINING POWER LEFT IN THE SMART BATTERY.
B POWER METER READ OUT FOR SMART BATTERY.

A TAP THE CASE PROFILE ICON IN THE SLIDE MENU TO ACCESS YOUR CASE SETTINGS.
B LOG OUT - TAP TO LOG OUT OF THE SELECTED CASE.
C FORGET DEVICE - TAP TO REMOVE CONNECTION TO SELECTED CASE.
D ANNUAL SUBSCRIPTION - TAP TO RENEW YOUR GLOBAL TRACKER SERVICE. THIS ICON IS ALSO FOUND IN THE SLIDE MENU.

SMART BATTERY POWER METER FOR THE SMART BATTERY

A TAP THE SMART BATTERY ICON TO VIEW THE REMAINING POWER LEFT IN THE SMART BATTERY.

B POWER METER READ OUT FOR SMART BATTERY.

CASE PROFILE USING CASE PROFILE

A TAP THE CASE PROFILE ICON IN THE SLIDE MENU TO ACCESS YOUR CASE SETTINGS.

B LOG OUT - TAP TO LOG OUT OF THE SELECTED CASE.

C FORGET DEVICE - TAP TO REMOVE CONNECTION TO SELECTED CASE.

D ANNUAL SUBSCRIPTION - TAP TO RENEW YOUR GLOBAL TRACKER SERVICE. THIS ICON IS ALSO FOUND IN THE SLIDE MENU.

ANTI THEFT USING THE ANTI THEFT PROXIMITY SENSOR

A TAP THE RING TO SET DISTANCE FOR ALARM TO SOUND.

B METER TO SEE THE DISTANCE OF YOUR SC L.

CASE CHECK FULL DIAGNOSTICS REPORT

A TAP THE CASE CHECK ICON TO VIEW A FULL DIAGNOSTICS REPORT OF YOUR SC L.

B DIAGNOSTICS REPORT FOR THE SC L NOTIFY YOU THAT ALL FEATURES ARE FUNCTIONING PROPERLY.

