

# **Fanhua**

## Instructions

### 1. ON/OFF

Turn on

Mode 1: switch ON/OFF button to 2, and hearing voice reminder reminds “Bluetooth is ready” to turn on the lamp on Mode 1. In Mode 1, connect Bluetooth “FanhuaShendeng” to enable features such as play Bluetooth music.

Mode 2: when ON/OFF button is switch 3, and hearing voice reminder reminds “Bluetooth is ready” to turn on the lamp on Mode 2. In Mode 2, connect Bluetooth “FanhuaShendeng” to enable all the features, including Bluetooth speaker, Music Fountain and LED lighting Projector.

OFF

when ON/OFF button is switch to 1, the lamp is OFF.

### 2 Charging

You need to charge when hearing “Low battery, the lamp will be shut down soon”.

It can be charged by connecting to computer or using charger. (As shown in the Pictures)

LED light will be on to indicate charging. When charging is done, the LED light will be off.

### 3 Features instruction

#### 1 Bluetooth Speaker

Turn on Bluetooth on your smartphone/tablet/Ipad and connect to “fanhuashendeng” to play music. When playing, instead of using your own device, you can also use the remote control to control the speaker.

#### 2 DIY LED Projector

This feature can be used when in MODE 3.

The slides of the projector can be changed and DIY. When the lamp is off, twist anti-clock wise and open the projector cap (As shown in pic 1) and then change slides (As shown in pic 2).

It is advised to use whiteboard marker to write on the slides.

3RGB colors are available for the LED projector. Simply press "red", "Green" or "Blue" button on the remote control to change LED lights. Otherwise, press "shuffle" to shuffle LED colors.

### 3 Dancing Water Fountain

The height of the spout is positively correlated with the volume of the music. Imported fountain oil is used to ensure it will not stick to the bottom and pillar of the music fountain. Imported Acrylic water tank and 4RGB LED light is used to ensure better translucency of colorful LED light show.

Specification:

Name: Fanhua Speakers

Model: FH2014

Material: Environmental friendly transparent PC material and ABS

Power: Up to 8 hours of music play

Up to 4 hours of music + Dancing water fountain

Up to 2 hours of playing when all features are on

Slides: Can be DIY

Color: Bronze

Charging: Via USB 2.0

Bluetooth: Bluetooth 2.1+EDR

Charging time: 3h-4h

Situation of usage: home, office, decoration, gift.

SIZE: 158X158X251MM

**After-sale Service**— Buy it securely and use it trustingly.

1. We promise free replacement within one-week of purchase and free maintenance within 3 month for any quality problems.
2. We provide a life-long maintenance services. After 3 month free maintenance is ended, we will only charge for cost of faulty parts if serviced.

Tips: Terms and conditions applied. Free maintenance will not be applied if you attempt to repair, bend and install by yourself. The product damage caused by the natural disasters and any irresistible factor are not covered by free warranty as well. Please send the Warranty Card along with the product for service

## **USA Regulatory Compliance**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.