




Manufacture:DIJIU Technology (Shenzhen) Co., LTD.

Catalogue

Product description	01
Instructions for use	02
General conditions and treatment	03
How to Charge	04
Product Specifications	05
Service Description	06

01. Product description

1. Structural Diagram



02. Instructions for use

How Wireless sing

1. Turn on the power: the power switch, blue light (normal);
2. Bluetooth connectivity: Bluetooth and turn on your phone to scan, search for "D9" after, The mating connector, the connection can hear the speaker issued a "beep" is heard (Note: If the pairing process Required to enter a password, enter "0000");
3. play music: Open mobile music player, such as "cool dog music" download itself! Favorite songs or accompaniment, start playing, you can adjust the accompaniment volume via the phone;
4. adjust the vocal: adjust the microphone volume and reverb vocal strength to the right place, 5. K song began.

Note:
After connecting a mobile phone with Bluetooth with memory function, boot automatically connect back;
To disconnect, it can set off Bluetooth phone,
If you only listen to music, you can microphone volume to minimum.

How phone recorded songs

1. the connection line recording: recording accessories line out, insert the USB plug into the recording Mouth, when the Bluetooth function is automatically disconnected;
2. connect the phone: the other end of the audio cable connector into the phone's 3.5mm headphone jack,

FIG.



3. open mobile phone software: "Sing," a song or other recording APP, select Their favorite songs, singing by the above method, start recording songs;
4. debugging, and save the song: Press the relevant phone software instructions,

NOTE: Insert the recording cable, Bluetooth will turn off automatically

03. General conditions and treatment

Symptom	cause of issue	Method of exclusion
Power light does not shine	Low battery or charging cable is not plugged	Check charging cable or charging connector
Microphone did not sound	Power is not turned on or tuned the vocal volume	Power is turned on or adjust the vocal volume
No microphone reverb	Reverb switch is not adjusted	Adjusting Reverb switch to the appropriate position
Singing or recording noisy	Ambient noise interference from mobile phones	Quiet place to widen the distance with the use of mobile phones
Poor sound effects in some models of mobile phones	The phone does not match the phone sound chip performance is weak outside the grounds	Restart the phone try to replace the use of mobile phones
Bluetooth audio playback staccato	Bluetooth phone and microphone too far away from obstructions	Near the phone to avoid obstacle
Bluetooth accompanying sound or no sound small	Phone down the volume of music files or source volume is small	Open the phone media volume louder music download
Bluetooth can not connect	Bluetooth too far away from obstructions has been connected to another phone	Avoid obstacles near the phone has been disconnected and even cell phones
Bluetooth music distortion	Sound excessive low battery	Turn down the volume of mobile media to charge the battery
Bluetooth is unable to connect Apple phone sing software	Apple iOS system does not support Bluetooth output	With a cool dog music or QQ music software

04. How to Charge

1. when the battery voltage is too low, the product will automatically shut down;
2. accessories USB charging cable to connect standard mobile phone charger USB interface to charge, when the red light below the power button lights up, indicating that the battery is being charged;
3. the normal charge for 2 hours and fully charged, the red light goes off automatically;
4. the normal time for 3-5 hours of continuous use.

05. Product Specifications

Pickup: Capacitive
 Output Power: 10mW (headphone output)
 5W (speaker output)
 Frequency Range: 100Hz-10KHz
 Maximum SPL: 115db 1KHz THD <1%
 Reverb mode: Echo sound reverberation
 Power supply: Built-in lithium polymer battery
 Battery capacity: 1000 mAh
 Charging power supply: DC5V

06. Service Description

Dear users, thank you very much for using our products, in order to effectively protect your interests, sales agents and companies should clear commitment to product repair, replacement, return (hereinafter: three bags) responsibilities and obligations, please read the following items :

1. "warranty card" is our company to provide free service warranty on its products necessary credentials;

2. in accordance with the principle of who is responsible for selling three bags of products, such as quality problems with the "Warranty Card" and the dealer, the dealer to provide services to customers, our company is the dealer service support;

3. the company promised, date of sale (date to the effective date of the bill, the same below) from quality problems within seven days, the customer can choose to return, replacement or repair; from the date of sale 8 - 15 days after emergence quality problems, customers can choose to replace and maintenance; from the date of sale, quality problems within a year, customers can free maintenance; over the warranty product quality problems to enjoy life-long maintenance (only charge for each service point component materials fee); please customers buy the auto fill good "warranty card";

4. the following circumstances do not enjoy Warranty Services:

- (1) more than three packs of period
- (2) failure to require the use of the product manual, maintenance, custody and damage caused;
- (3) non-commitment to three packs of the split mender of damage;
- (4) No "warranty card";
- (5) Content and Product "warranty card" does not match the physical consciousness or altered;
- (6) damage caused by force majeure;

5. the final interpretation of the above matters belong to the Company

FCC Caution.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.