

English Manual

Bluetooth Speaker CM5305 HRW

Manufacturer:

Shenzhen High Railway Technology Co., Ltd.

- " /  " In TF/Bluetooth mode when short press this button: next song; long press: Volume up. Don't work in AUX mode.
- " \  " In TF/Bluetooth mode when short press this button: previous song; long press: Volume down, Don't work in AUX mode.
- "  " In TF mode, short press this button: Play/Pause; In Bluetooth mode, short press this button: Play/Pause/Answer/End/Cancel dial/Pair. In Bluetooth mode, double click: Last number redial; long press for 2 seconds: reject calls. In TF/AUX mode. press it will be TF card and AUX exchange.

► Bluetooth Pairing

- Make sure the Bluetooth Speaker is in the off state.
- Press ON/OFF key to Bluetooth mode, blue LED will flash 6 times. And short press Play/Pause key, blue and red LED flash alternately.
- Allow your mobile to searching Bluetooth headset state. Typically, this is done by going to “set up”, “connect” or “Bluetooth” menu and then selecting the option to search Bluetooth devices.
- The mobile can see S10 to connect your mobile with this speaker. Press “Yes” or “Confirm” to confirm this action. (Notice: If the connection is sucessful, blue LED will flash. If the pairing is unsuccessful, the LED Blue and Red will still flash alternately)

FCC Warnning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular

installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1)

This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.