

315.00 mm

140.00 mm

Tire Pressure Monitoring System (TPMS)

BOOSTER INSTALLATION INSTRUCTIONS

The booster is designed to amplify the signal from your TPMS system sensors. In situations where length or interference prevents your monitor from receiving a signal, the booster increases the sensors transmitting distance.

PLACEMENT INSTRUCTIONS


Motor Coach Placement:

It is recommended to install the booster in an outside-aft compartment or in your rear closet.



Tractor - Trailer Placement:

It is recommended to install the booster outside between the tractor and towed trailer.



Fifth Wheel Placement:


It is recommended to install the booster in an outside compartment (battery/ generator) under the front bed area.



INSTALLATION INSTRUCTIONS

Be sure to wire the booster into a 12V power source that will be "on" during vehicle operation. The booster will be on as soon as it is connected to power. The red light stays on when power is connected and periodically flashes 3 times during receiving and transmitting.

INSTALLATION OF THE BOOSTER ONLY REQUIRES IT BEING CONNECTED TO A 12V POWER SOURCE AND GROUND - WHEN THE RED LIGHT COMES ON IT IS FUNCTIONING.



105.00 mm

BOOSTER SPECIFICATIONS

Operation Temperature
-20°C ~ +80°C

Storage Temperature
-30°C ~ +85°C

Working Voltage
12~24V

Transmission Power
<18dBm

Frequency
433.92MHz

Size (LxWxH)
127mmx80mmx25mm

Weight
5.19ounces

IMPORTANT

1. Please read instructions before installation.
2. Booster should be mounted securely.
3. The booster is water and dust resistant.
4. Minimize the amount of metal in mounting area.
5. Ensure all wires are mounted securely.
6. Verify booster is operating after installation.
7. The center button is also a RESET button.

RF exposure statement

This equipment complies with the FCC and ISED radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Cet équipement est conforme aux limites d'exposition aux rayonnements de la FCC et de l'ISED établies pour un environnement non contrôlé. Cet émetteur ne doit pas être co-localisé ou fonctionner en conjonction avec une autre antenne ou un autre émetteur.

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

IC WARNING

This device contains licence-exempt transmitter(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

1. L'appareil ne doit pas produire de brouillage;
2. L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.