

# PhotoSpring Classic (PSF-101) User Manual

## Welcome to your PhotoSpring

Start enjoying all your photos and videos and rediscover the moments you've been missing



## Getting started with your PhotoSpring

Thank you for being part of the PhotoSpring community.

Please follow these steps to get your PhotoSpring ready for setup so you can start sending and enjoying your photos and videos every day.

- 1) Check receipt of all items
  - PhotoSpring Digital Photo Frame
  - Kickstand
  - AC power adapter
- 2) Place frame face down and attach the kickstand for your desired orientation
- 3) Stand up your PhotoSpring
- 4) Connect AC power adapter
- 5) Wait for PhotoSpring start-up and display the Welcome screen
- 6) Tap on the Welcome screen and follow on-screen instructions to set-up your PhotoSpring

## Ready for Setup

Have smartphone or computer ready to assist with setup. Tap on Welcome screen to start.

On-screen instructions will help you:

- 1) Connect to your WiFi
- 2) Download and install the latest version
- 3) Name your frame and connect email
- 4) Choose sending and other settings
- 5) Get ready to receive photos and videos

## Ways to send photos and videos:

Frame Email – Create Frame Email on PhotoSpring to send photos by email (no account required)

Smartphone / Tablet App – Use PhotoSpring app to send directly from smartphone or tablet

Web Browser – Web page allows you to send from your computer.

\* App and Web Browser requires free PhotoSpring account.

Download PhotoSpring App or go to: [my.photospring.com](http://my.photospring.com)

## PhotoSpring Screen Flow and Basic Features Overview

PhotoSpring will always default to **Slideshow**.

<p>From <b>Slideshow</b> tap on photo to enter <b>Photo Info</b> screen to see these options:</p> <ul style="list-style-type: none"><li>- Go to Playlist screen</li><li>- Tap photo to resume Slideshow</li><li>- Show Menu dropdown</li><li>- Swipe left/right change photo</li><li>- Email photos</li><li>- Pause Slideshow</li><li>- Edit photo information</li><li>- Apply action to photo</li><li>- Set clock and WiFi</li></ul>	<p><b>Playlist</b> screen (enter from <b>Photo Info</b>):</p> <ul style="list-style-type: none"><li>- Go to Albums screen</li><li>- Go to Select Items screen</li><li>- Tap photo to start Slideshow</li><li>- Show Menu dropdown</li><li>- Scroll up and down</li><li>- Select Filters options</li><li>- Select Sort options</li></ul>
<p><b>Albums</b> screen (enter from <b>Playlist</b>)</p> <ul style="list-style-type: none"><li>- Tap album to select as Playlist</li><li>- Show Menu dropdown</li><li>- Scroll page up and down</li><li>- Swipe left/right in each row</li><li>- Manage album options</li><li>- Add new album</li></ul>	<p><b>Select Items</b> screen (enter from <b>Playlist</b>)</p> <ul style="list-style-type: none"><li>- Select multiple items or Select All</li><li>- Apply action to selection<ul style="list-style-type: none"><li>Email photos</li><li>Add to Favorites</li><li>Add to Album (create new album)</li></ul></li></ul>

**Have questions? Need help?**

**We're here for you.**

For FAQ and information please visit website:

[support.photospring.com](http://support.photospring.com)

Or email us with specific questions:

[support@photospring.com](mailto:support@photospring.com)



## FCC warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.