


User Manual



1, Short press : volume up. Long press : next song

2, Short press: boot up, play/pause. Long press: power off. When there is a call, short press to answer/hang off the phone

3, Short press : volume down. Long press: last song

4, Short press: LED dimmed. There are 5 LED light modes. Long press can change the LED light mode

5, Short press : LED Brighten. Long press : power off

6, MODE button. Short press to change play mode

7, USB port, support MAX 32GB, compatible with WAV/FLAC/MP3 files. Work for iOS/Android system, Max Output 5V 2A.

8, AUX port, 3.5mm standard earphone port, workable for mobiles/MP3/PC/Tablets , When put into LINE cable, the speaker will be in LINE mode after boot in. If you want to change mode, please pull out the Line cable.

9, Micro 5P USB port, support card reader function when speaker connect to computer, download the music into TF card. It can be used as USB sound card to play music from computer while downloading.

10. TF card mode, support MAX 32G flash, Compatible with : WAV/FLAC/MP3 music files

11. LED indication

Blue: playing music

Red: Charging mode. Long bright when charging. When fully charged the LED will turn off.

12. Microphone input port, when receiving a call, the voice received by the microphone.

Reminder: When there is a warning sound when playing, it is power low, please charge the speaker (charging voltage: 5V, charging current: do not lower than 1500mAh) When playing music to automatically shut down, the bed lamp may not be light, please charge it full when use again.

Bluetooth connection

1. Turn on the speaker. After switching to Bluetooth mode through the M key, bluetooth access to automatically connected state

(the phone connected to the last shutdown when connected to the phone) at this time the blue light flash;

2. Mobile / computer / other devices / open Bluetooth, and then click on the search, in the search to the machine inside the choice of MY550BT, waiting for about three to ten seconds of time, (different brands, different regions of the system will be different)

3. Listen to music at the same time, if there is an incoming call, direct short press the switch button can answer, this is a hands free speaker model, if not required, directly on the phone to switch to answer interface mode switch to the receiver can be.

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- - Consult the dealer or an experienced radio/TV technician for help.