

FRONT

76*127mm

7318 Ambient Fantastic Panel Clock With 15W Wireless Charger



USER GUIDE



CAUTION

To ensure safe and proper use, read all safety information before using the device. Only use with manufacturer-approved batteries, chargers, accessories, and supplies.

•THIS DEVICE IS NOT A TOY, do NOT allow children or pets to use or play with this device.

- Do not disassemble, modify, or repair the device.
- Do not expose the unit to extreme temperatures (heat or cold), open flames, humid, or wet conditions.
- Do not submerge in water.
- If using with a USB adapter, make sure the adapter is not damaged.
- Do not allow the USB port or the connectors of the supplied USB cable to be exposed to dust, or water, or come into contact with any conductive materials such as liquids, metallic powders, etc.

In the Box

- Ambient LED Clock
- USB Power Cable
- User Manual

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.


NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:


- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum 20cm distance between the radiator and your body. Use only the supplied antenna.

Location of Controls



BACK



Getting Started

Power on the Clock

Plug the small connector (USB Type-C) of the included USB power cable into the USB Type-C input port on the back of the clock. Plug the large connector (USB Type-A) into the USB port on a computer or 5V USB Adapter (not included) and plug into a wall outlet.

The clock display will turn on when the clock is connected to power.

Using the Clock

1. Long press the button enter settings mode, the **HOUR** will flash. Adjust the **HOUR** using the and buttons.
2. Short press the button to confirm the **HOUR** and the **MINUTES** will flash. Adjust the minutes using the and buttons.
3. Short press the the button to confirm and back to clock display.

Using the LED Lights

1. In clock display, short press and buttons to adjust the brightness between **LOW/ MEDIUM/ HIGH**.
2. Short press the button to adjust the light mode:
 - **Single color**: Short press to adjust single color, total seven single color.
 - **RGB color flashing 1**: The light will flash between seven color (HOUR and MINUTES are the same color).
 - **RGB color flashing 2**: The light will flash between seven color (HOUR and MINUTES are different color).

Charging your devices

Use two USB output ports (USB Type-A or USB Type-C) on the front of the dock to charge your mobile devices.

Specifications:

ILNOVA 7318

Input USB-C: 9V/3A

Output USB-A: 5V/1A

Output USB-C: 5V/1A

Wireless: 15W

7318 Wireless Şarj & Masaüstü Saat 15W Kablosuz Şarj



KULLANIM KILAVUZU



UYARI

Güvenli ve doğru kullanım için cihazı kullanmadan önce tüm güvenlik bilgilerini okuyun. Sadece üretici onaylı piller, aksesuarlar ve malzemeler kullanın.


BU CİHAZ BİR OYUNCAK DEĞİLDİR, çocukların veya evcil hayvanların bu cihazla oynamasına izin vermeyin.

- Cihazı sökmeyin, değiştirmeyin veya tamir etmeye çalışmayın.
- Cihazı aşırı sıcaklıklara (sıcak veya soğuk), açık alevlere, nemli veya ıslak koşullara maruz bırakmayın.
- Cihazı suya batırmayın.
- Bir USB adaptörü ile kullanıyorsanız, adaptörün hasarlı olmadığından emin olun.
- USB bağlantı noktasının veya sağlanan USB kablusunun bağlantı noktalarının toz, su veya iletken maddelerle temas etmesine izin vermeyin.


Kutu İçeriği

- Ambient LED Saat
- USB Güç Kablo
- Kullanım Kılavuzu

Kontrollerin Yeri



ARKA YÜZ



Bağlatılıyor

Saati Açma

Küçük bağlantı (USB Tip-C) USB güç kablusunun saatin arkasındaki USB Tip-C giriş portuna takın. Büyük bağlantı (USB Tip-A) bir bilgisayarı veya 5V USB Adaptörünün (dahil değildir) USB bağlantı noktasına takın ve bir duvar prizine takın.

Saat güç bağlantısına bağlandığında saat ekranı açılacaktır.

Saati Kullanma

1. Ayar moduna geçmek için düğmesine uzun basın, SAAT yanıp söner. SAAT'i ve düğmeleri ile ayarlayın.
2. düğmesine kısa basarak SAAT'i onaylayın ve DAKİKALAR yanıp sönmeye başlayacaktır. Dakikaları ve düğmeleri ile ayarlayın.
3. düğmesine kısa basarak onaylayın ve saat ekranına geri dönün.

LED Işıkları Kullanma

1. Saat ekranında, ve düğmelerine kısa basarak parlaklığı DÜŞÜK/ORTA/YÜKSEK arasında ayarlayın.
2. Işık modunu ayarlamak için düğmesine kısa basın:
 - Tek renk: Tek renkte ayarlamak için kısa basın, toplam yedi tek renk mevcut.
 - RGB renk yanıp sönmeye 1: Işık yedi renk arasında yanıp sönmeye (SAAT ve DAKİKALAR aynı renk).
 - RGB renk yanıp sönmeye 2: Işık yedi renk arasında yanıp sönmeye (SAAT ve DAKİKALAR farklı renk).

Cihazlarınızı Şarj Etme

Mobil cihazlarınızı şarj etmek için saatin önündeki iki USB çıkış portunu (USB Tip-A veya USB Tip-C) kullanın.

Özellikler:

ILNOVA 7318

Giriş USB-C: 9V/3A

Çıkış USB-A: 5V/1A

Çıkış USB-C: 5V/1A

Kablosuz: 15W