



## Test Setup Photos of the EUT

### Test Setup Photo(s) of Radiated Emissions Measurement

RS232




Fig. 1




Fig. 2





### Test Setup Photo(s) of Radiated Emissions Measurement

RS485




Fig. 3




Fig. 4





## Test Setup Photo(s) of Radiated Emissions Measurement

UART




Fig. 5




Fig. 6





## Test Setup Photo(s) of Radiated Emissions Measurement

USB




Fig. 7




Fig. 8

