

55 mm

100 mm

蓝牙耳机专用说明书

享受自由
追寻你的心

RoHS

12

产品描述

蓝牙版本：V4.1
充电方式：电源适配器输出（DC5V 150mA）
电池指标：高性能聚合物锂电池
蓝牙指标：Class 2
支持协议：
Headset/Handsfree/A2DP/AVRCP/APT-X
持续通话时长：约6小时
持续播放时长：约5小时
待机时长：约160小时

■ 该款蓝牙耳机能接收来自手机、笔记本电脑及其他蓝牙设备的音频。（AV DONGLE:一般DONGLE）
与PC蓝牙DONGLE配对连接后：可以播放电脑的各种音频也可以用来语音聊天，实现无线QQ、MSN、SKYPE。

A 产品示意图

USB充电口

喇叭头

音量+/下一曲

多功能开机键

音量-/上一曲

工作指示灯

B 配对示意图

关机状态下长按多功能键至红蓝灯交替闪烁，蓝牙耳机处于配对模式；
注：如未连接手机蓝牙耳机将在5分钟后自动关机。

打开手机蓝牙搜索“该蓝牙设备型号”并点击连接。
关闭第一台手机的蓝牙功能，重复上述步骤可配对第二台手机。

C 佩戴示意图

首先将耳机轻轻塞入耳朵，然后将耳机调整到舒适位置即可。

D 线扣使用方法示意图

单线扣使用方法

双线扣使用方法

产品重要功能

开机关机

长按约3秒

开机-长按多功能键约3秒，蓝灯跳闪三下；
关机-长按多功能键约3秒，红灯常亮2秒；

接听电话

长按

YES

按手机接听接听或短按耳机多功能键接听或“YES”语音接听

挂断电话

短按

按手机挂断键挂断或短按耳机多功能键挂断

拒接电话

长按约3秒

NO

按手机挂断键拒接或长按多功能键约3秒拒接或“NO”语音拒接

末码拨号

双击

双击多功能键针对最后一个拨出的电话号码进行重拨

音乐播放

短按

在音乐播放状态下短按多功能键可进行播放/暂停

翻曲选择

长按2秒

长按2秒

播放中长按“音量+”约2秒进入下一曲
长按“音量-”约2秒进入上一曲

音量调节

短按

短按

短按“音量+”或“音量-”键，对音量进行调节，每按一次音量增加或减少一格

恢复出厂设置

长按3秒

在充电状态下长按“音量-”3秒，蓝灯闪3下，即可恢复出厂设置

语音切换

双击

注：单语言款式无此项功能

请将蓝牙耳机开机进入配对状态下（红蓝灯交替闪烁）双击音量加按键实现语音切换

注意事项

·请在常温环境中存放以及使用本产品；
·请勿丢掷，避免因跌落造成产品损坏；
·请勿自行拆解、修理和改造本产品；
·请勿使用化学溶剂擦拭本产品；
·如有需要，请使用输出电压DC 5V的USB充电器来充电；
·请勿随意丢弃，或置于高温（温度高于60度）与火中，以免引起危险！
·耳机使用充电电池，在首次使用蓝牙之前，必须给电池充足电。
·将充电线插头插入耳机充电接口。
·充电时，红灯长亮。
·耳机充足电，大约需要1.5-2小时。
·充满电后红灯熄灭，蓝灯长亮。

语音提示

·当开机时，耳机会自动语音提示：“开机”。
·当关机时，耳机会自动语音提示：“关机”。
·当配对成功时，耳机会自动语音提示：“已连接”。
·当电量低时，耳机会自动语音提示：“电量低”。
·当来电时，耳机会语音播报来电号码。

售后服务条例：

1、咨询服务：用户在使用产品前，请仔细阅读本产品的使用说明书
2、包换服务：包换期内（自购机之日起七日内），正常使用出现了非人为故障，请保持产品、配件和包装的完整（若外观不损坏、做保修处理）经检查确认故障后，可选择换货或维修，用户可到当地授权经销商处联系并处理。
3、保修服务：保修期内，正常使用出现的非人为故障，均可享受免费保修服务（主机一年内免费保修，若人为损坏，做收费维修服务）。
4、收费维修服务：产品自购机之日起一年到三年内，出现故障可收费维修，用户需支付维修所产生的元器件费、运费及人工费。
5、以下情况不在三包范围内，本公司提供有偿服务：
①超过三包期限
②涂改三包凭证，或序列号与产品本身不符
③意外因素或人为导致的产品损坏（如：未按使用说明书操作、维护或保管、安装错误造成的故障，接入不合适的电源、进水、摔坏等）
④无效三包凭证及有效发票(能证明产品确属服务期内者除外)。
⑤因不可抗拒如地震、火灾、水灾、雷击等导

致在产品故障或损坏。
⑥未经本公司许可，擅自拆卸、修理或改装。

关于售后服务的说明：
1、购机日期以本凭证或购机发票为准，不能提供有效证明的，以生产日期为准。
2、质量问题不包括用户个人对音质、音色等主观差异。
3、外壳、说明书包装不在保修服务范围内。
4、已停产机型，本公司仅做功能性修复。
5、经销商向您做出的非本公司保证的承诺，本公司不承担任何责任。

经销商	产品型号	经销商名称	
信息	产品序列号	联系电话	
用户信息	用户地址	销售日期	
	通讯地址	联系电话	
	E-mail		

为了维护你的权益，请你认真填写，并妥善保管，作为维修时的认证。

废弃电器和电子设备

本产品或附有如下标示的产品，寿命结束时不应与其他家庭废物一起处理。

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Wireless headset
User Manual

Enjoy the Freedom
Follow Your Heart

RoHS

12

Product Description

Version: Bluetooth V4.1
Charging method: Power supply with output of DC5V 150mA
Battery type: Rechargeable lithium-ion polymer battery
Bluetooth power class: Class 2
Profile supported:
HSP/HFP/A2DP/AVRCP/APT-X
Talk time: Up to 6 hours
Listen time: Up to 5 hours
Standby time: 160 hours

■ Play audio file from a mobile phone, laptop or other Bluetooth device connected with it. (AV dongle: General BT dongle)
■ Play audio files from a PC after connected with its BT dongle, and also support wireless internet voice chat through QQ, MSN and SKYPE.

A Headset overview

USB charge

Earbud

Volume+
Next song

MFB
Volume-
Previous song

Indicator light

B Pairing steps

NOTE: The headset will power off automatically 5 minutes without connection.

Under power-off status, press and hold the MFB until the indicator light flashes red and blue alternatively, then the Headset enters the pairing mode;

Turn on Bluetooth on your mobile, find the Model No. of the Headset, and connect. Turn off Bluetooth of the first mobile, and repeat the step above to connect with the second mobile.

C Wearing

Insert the ear bud, and rotate the headset to achieve an optimal fit.

D Tips on Clips Usage

Hold the cable with one clip

Hold the cable with two clips

Important features

Power on/off

Press and hold 3s

Power on - Press and hold the multi-function button (MFB) for 3s until the BLUE light flashes;
Power off - Press and hold the MFB for 3s till the RED light on for 2s;

Call answer

Press

YES

Call answer - Answer by your phone or press the MFB, or say "yes"

Call end

Press

Call end - End by your phone or press the MFB;

Call reject

Press and hold 3s

NO

Call reject - Reject by your phone or press and hold the MFB for 3s, or say "no"

Last number redial

Double tap

Last number redial - Quickly tap the MFB twice to redial the last dialed phone number;

Play music

Press

Play music - Press the MFB to play/pause music under music playing status;

Track control

Press and hold 2s

Press and hold 2s

Track control - Press and hold the "Volume +" button for 2s to skip to the next song; Press and hold the "Volume -" button for 2s to play the previous song;

Volume adjust

Press

Press

Volume adjust - Press the "Volume +" or "Volume -" button to increase or decrease the volume.

Reset the headset to factory settings

Press and hold 3s

Press and hold the volume "-" button for 3 seconds upon charging the Headset until the blue light flashes 3 times.

Language switching

Double tap

NOTE: Not applicable to headset with only single language prompt

Double tap Volume "+" button to switch between EN and CN language prompt under pairing mode (indicator light flashes red and blue alternatively).

Warning:

· Use and keep the Headset under ambient temperatures;
· Don't throw it in case product damage caused;
· Don't disassemble, repair or alter the Headset;
· Don't clean the Headset with chemical solvent;
· Use a USB charger of DC5V to charge the Headset if necessary;
· Don't discard the Headset at random, or put it into fire or high temperature environment (60 /140) in case of danger.

Voice prompt

● You will hear "power on" when the Headset is powered on.
● You will hear "power off" when the Headset is powered off.
● You will hear "connected" when the Headset is paired.
● You will hear "low battery" when the Headset is in low power status.

Service Regulations:

Service Regulations:
1. Notice: Please carefully read the User Manual before using the Headset.
2. Guaranteed replacement: Within the guaranteed period (7 days after purchasing), replacement or free repairing may be offered for product malfunction caused non-artificially under normal use, provided that the specific malfunction is tested and confirmed. Contact the authorized distributor for replacement handling.
3. Warranty: Within the period of warranty, free repairing service may be offered for malfunction caused non-artificially under normal use (one year warranty for the headset itself).
4. Repairing charge: One to three years after purchasing, the product may be repaired if malfunction occurs, but parts cost, transport freight and labor cost shall be assumed by the customer.
5. The following circumstances are not covered by the free warranty services, but we provide paid services:
① The period of warranty expires;

② The warranty card is altered, or serial number inconsistent;
③ Product damage caused by unforeseen factors or artificially;
④ Invalid warranty card but valid invoice (unless product may be certified within the warranty period);
⑤ Malfunction or damage caused by force majeure, such as earthquake, fire, flood, or thunder-strike;
⑥ Disassemble, repair or alter the product without our permission.

Explanations:
1. The purchasing date shall be subject to the date written in this manual or the invoice, or subject to the production date if no valid certificate is provided.
2. The subjective differences such as the tune and tone are not acknowledged as the quality problem.
3. The product shell, user manual and the package are not covered by warranty.
4. Headset stopped production shall only be provided with repairing service.

5. We will not undertake any liability for undertakings made by the distributor but not our company.

Dealer information	Product model	Dealer name	
	Product sequence number	Contact phone	
User information	User address	Sales date	
	Communication address	Contact phone	
	E-mail		

In order to safeguard your rights and interests, please fill in and take care of it as the certification of maintenance.

Waste electrical and electronic device
This product or products with symbols as follows should not be disposed with other family wastes when such products are end to use.