


CH-100

Users Manual

1. Preparation

- ① First, connect the device to the adapter. Adapter standard input is :
 - ② Please connect your device to the TV via the HDMI cable and press the POWER button to turn it on.
 - ③ Please check the power indicator of the device and the red light indicates that the power is on. Press the power button, the power indicator turns blue to indicate that the device is powered on.


2. Appearance



3. Functional Specification


3.1 Home Interface

Home interface as shown below, you can use Applications, Settings, Favorites and File Browser.




3.2 Access the Applications

Select the application to access the application menu interface.




In this menu, you can select the application you need to use.




3.3 File Management

You can enter the file manager by selecting the file management icon on the main page.



You could check and use files on your device, such as pictures, videos, and etc.



directory:File

1/5


3.4 Settings

Select the settings, enter the setup menu, then select the features and settings you need, such as wireless network, wired network, Bluetooth, time and date settings, language and so on.


3.4.1 Wireless and Network

Wi-Fi Connection

Turn on the Wi-Fi and search the surrounding wireless network.




Select the network you need to connect. If the connected network is encrypted, enter the appropriate network password, then you can connect the network.




Wired network connection

Through the blue WLAN interface on the device, you could connect the dedicated cable in the use place to the device. You could access to the network by configuration or through the PPOE dial-up access to the network.



Bluetooth connection

Turn on the Bluetooth, and search your surrounding Bluetooth devices, such as Bluetooth headset, Bluetooth audio and etc. Then click on the name of the searched Bluetooth device to pair the Hub. You can use the device after the completion of pairing.




Data usage


The network traffic data you used could be checked.

More Settings

You can share your network through this device.




You can configure your Wi-Fi hotspot, or configure Bluetooth to share your network.




3.4.2 Display

You can configure your favorite wallpaper, font size, and so on.




You can adjust the display ratio of the screen to achieve the best display.




3.4.3 Storage

You can view the device's memory information and usage, as shown below,




You can check the built-in storage capacity information, as well as the use of external storage device information.




3.4.4 Application management

Your application information could be checked.




You can manage your application by installing or uninstalling.




3.4.5 Location service

Open this service to share your location information, you can use Google Map, Baidu map, Auto Navi map and the other maps to check your current location through the network positioning.




3.4.6 Security

Through the security services to ensure the system security and the application source.




3.4.7 Language & Input


The system provides language configuration function and make it easy for usersto use it quickly.




You can choose the language for your own system.



You can install the input method keyboard, the system defaults is the Android input method keyboard.




You can configure the installed input keyboard.




3.4.8 Backup & Reset

Log in the Google account and open my data backup. Google system will upload your application data, wireless password and other settings to the Google cloud services. When you log in the Google account in the other Android device, the system will automatically synchronize your personal information and data to the device.




You can empty your Google account, restore your system and app settings by

restoring factory data.




Choose to erase everything, the system will shut down and restart then enter the recovery mode.




3.4.9 Add an account

You can add a Google account, email account and etc.




3.4.10 Date & Time

You can configure the system's date, time and time zone. Or you can select the network to automatically synchronize the date and time.



3.3.11 About Device

You can check the basic information about the system, such as product model, Android version and etc.



FCC Caution.

§ 15.19 Labelling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

§ 15.21 Information to user.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

§ 15.105 Information to the user.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.

CAMMY.COM PTY LTD

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF warning for Mobile device

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.