


## Front



Where payment happens,  
Where **NEWLAND** discovered.



**N750** POS Terminal  
Quick Reference Guide

### Packing List

- 1 POS Terminal
- 1 User Manual
- 1 Power supply  
(AC plug shall be subject to the actual supply in the sales area.)
- 1 Cable

Please check the items when you receive the product and if there is any defect or missing, please contact your terminal provider.  
For any other AC type plug requirement, please contact your terminal provider.

### Introduction

This is a new multi-functional POS terminal- N750. It has different optional configurations and accessories. Please select by yourself according to this document or supplier.

Read this guide to understand and make the best use of your terminal. It presents you the necessary information about use, installation, maintenance, safety and security recommendations.

#### WARNING:

Use only the accessories included with the product to ensure best performance and safety. Maintenance should only be provided by Newland authorized technician. Failure to comply with these instructions will void the manufacturer's responsibility.

#### Overview of the Terminal

Magnetic card reader

Front camera

Contactless card reader

LCD with touch screen

Chip card reader

Function keys(Right)

Microphone

Power button

Scan window  
(The professional scanner is optional, if it's not available the scan window is black)

TYPE-C (Debug only)

Function keys(Left)

Desk-top type

Bracket type (Optional)

## Installation

### Recommendations

The terminal should be kept away from very hot zone and protected from vibrations, dust, damp or electromagnetic radiation (like computer screen, wireless intercom etc.)

#### Environment condition

Operating temperature

-0°C~40°C(3.2°~104°)

Storage temperature

-20°C~70°C (-4°F~158°F)

Relative humidity

5%~95% (Non-condensing)

## Power On /Off

### Notes

Plug in the power supply, and the device will start automatically. After that, you can turn it on and off through the power button.

**Power on:** Press and hold the "power" power key which is located next to the Ic card slot for 2~3 seconds, until the POS terminal is powered on.

**Power off:** Press and hold the "power" power key which is located next to the Ic card slot for 2~3 seconds, the display screen will prompt a window, click the "power off" icon, and then the POS terminal power off.

**Note:** Please unplug the power supply to power off if the terminal is not responding.

## External Connections

### External Connections

Net

USB

Power

Fig.1

Fig.2

Fig.3

Fig.4

Fig.5

Fig.6

Fig.7

Fig.8

Fig.9

Fig.10

Fig.11

Fig.12

Fig.13

Fig.14

Fig.15

Fig.16

Fig.17

Fig.18

Fig.19

Fig.20

Fig.21

Fig.22

Fig.23

Fig.24

Fig.25

Fig.26

Fig.27

Fig.28

Fig.29

Fig.30

Fig.31

Fig.32

Fig.33

Fig.34

Fig.35

Fig.36

Fig.37

Fig.38

Fig.39

Fig.40

Fig.41

Fig.42

Fig.43

Fig.44

Fig.45

Fig.46

Fig.47

Fig.48

Fig.49

Fig.50

Fig.51

Fig.52

Fig.53

Fig.54

Fig.55

Fig.56

Fig.57

Fig.58

Fig.59

Fig.60

Fig.61

Fig.62

Fig.63

Fig.64

Fig.65

Fig.66

Fig.67

Fig.68

Fig.69

Fig.70

Fig.71

Fig.72

Fig.73

Fig.74

Fig.75

Fig.76

Fig.77

Fig.78

Fig.79

Fig.80

Fig.81

Fig.82

Fig.83

Fig.84

Fig.85

Fig.86

Fig.87

Fig.88

Fig.89

Fig.90

Fig.91

Fig.92

Fig.93

Fig.94

Fig.95

Fig.96

Fig.97

Fig.98

Fig.99

Fig.100

Fig.101

Fig.102

Fig.103

Fig.104

Fig.105

Fig.106

Fig.107

Fig.108

Fig.109

Fig.110

Fig.111

Fig.112

Fig.113

Fig.114

Fig.115

Fig.116

Fig.117

Fig.118

Fig.119

Fig.120

Fig.121

Fig.122

Fig.123

Fig.124

Fig.125

Fig.126

Fig.127

Fig.128

Fig.129

Fig.130

Fig.131

Fig.132

Fig.133

Fig.134

Fig.135

Fig.136

Fig.137

Fig.138

Fig.139

Fig.140

Fig.141