

ZAP 4 BUTTON TRANSMITTER USER GUIDE

WARNING

Read this guide carefully before using the product. In case of doubt, consult a qualified technician.

SPECIFICATIONS

Frequency: 433.92 MHz


Modulation: OOK

Protocol: Fixed or Rolling Code


RECORDING OF TRANSMITTER


To record the transmitter, please consult the controller board manual.

BUTTONS



BATTERY REPLACEMENT





After the replacement, discard the battery in an appropriate place.

WARNING:

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRED OPERATION.

NOTE: THE GRANTEE IS NOT RESPONSIBLE FOR ANY CHANGES OR MODIFICATIONS NOT EXPRESSLY APPROVED BY THE PARTY RESPONSIBLE FOR COMPLIANCE. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.